



FortiOS Handbook
Firewall for FortiOS 5.0



FortiOS Handbook - Firewall for FortiOS 5.0

April 03, 2014

01-500-1248222-20140403

Copyright© 2012 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, and FortiGuard®, are registered trademarks of Fortinet, Inc., and other Fortinet names herein may also be trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance metrics contained herein were attained in internal lab tests under ideal conditions, and performance may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to the performance metrics herein. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. Fortinet disclaims in full any guarantees. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.

Technical Documentation	docs.fortinet.com
Knowledge Base	kb.fortinet.com
Customer Service & Support	support.fortinet.com
Training Services	training.fortinet.com
FortiGuard	fortiguard.com
Document Feedback	techdocs@fortinet.com

Table of Contents

Change Log	8
Introduction	9
How this Guide is Organized	9
FortiGate Firewall Components	10
How does a FortiGate Protect Your Network	11
Firewall concepts	13
What is a Firewall?	13
Network Layer or Packet Filter Firewalls	13
Application Layer Firewalls	14
Proxy Servers.....	14
Security Profiles	15
IPv6	16
What is IPv6?	16
IPv6 in FortiOS	18
Dual Stack routing configuration	18
IPv6 Tunnelling.....	19
Tunnelling IPv6 through IPSec VPN.....	20
NAT	20
What is NAT?	20
The Origins of NAT.....	20
Static NAT	21
Dynamic NAT	21
Benefits of NAT	23
NAT in Transparent Mode.....	24
Central NAT Table.....	24
NAT 64 and NAT46	25
NAT 66	25
How Packets are handled by FortiOS	26
FortiGate Modes	27
NAT/Route Mode	28
Transparent Mode.....	28
Quality of Service	28
Traffic policing.....	28
Traffic Shaping	29
Queuing.....	29
Interfaces and Zones	29

Firewall objects	31
Addresses	31
IPv4 Address and Net Mask	32
FQDN Addressing	33
Geography Based Addressing	33
Address Groups	34
Wildcard Addressing	35
Virtual IP Addresses	36
Virtual IP Groups	37
IP Pools	37
Fixed Port	39
Match-VIP	40
Services and TCP ports	40
Categories	41
Protocol Types	41
Service Groups	57
Example Scenario: Using FortiGate services to support Audio/Visual Conferencing	
58	
VIP	58
Creating an address for the subnet	59
Configuring the services	59
Creating the Service Group	61
Creating the IPS Security Profile	62
Policies	63
Firewall schedules	64
Schedule Groups	65
Schedule Expiration	66
Security profiles	66
AntiVirus	67
Web Filtering	67
Application Control	67
Intrusion Protection (IPS)	67
Email Filtering	68
Data Leak Prevention (DLP)	68
VoIP	68
ICAP	68
EndPoint Control	68
Proxy Option Components	69
The use of different proxy profiles and profile options	69
SSL/SSH Inspection	72
Creating a new SSL/SSH Inspection profile	72

Security policies	74
Firewall policies.....	74
What is not expressly allowed is denied.....	75
Policy order	76
Viewing Firewall Policies.....	78
How “Any” policy can remove the Section View	79
Security policy configuration extensions	79
Identity Based Policies	80
Identity-based policy positioning.....	80
Identity-based sub-policies	81
Identity policies an unauthenticated users	81
Device Identity Policies.....	81
VPN Policies	82
IPSec Policies	82
SSL VPN Policies.....	82
Interface Policies.....	83
DoS Protection.....	83
One-Arm IDS.....	87
IPv6 IPS.....	87
Traffic Destined to the FortiGate unit.....	87
Dropped, Flooded, Broadcast, Multicast and L2 packets.....	87
GUI and CLI	88
Local-In Policies.....	88
Security Policy 0	89
Deny Policies	90
Accept Policies	90
IPv6 Policies.....	90
Fixed Port.....	90
Endpoint Security	91
Traffic Logging.....	91
Quality of Service.....	93
Queuing.....	93
Policy Monitor	93
Upper Pane.....	94
Lower Pane	94
Network defense	95
Monitoring.....	95
Blocking external probes	95
Address sweeps.....	95
Port scans	96
Probes using IP traffic options.....	96
Evasion techniques.....	97

Defending against DoS attacks	100
The “three-way handshake”	100
SYN flood.....	100
SYN spoofing	101
DDoS SYN flood	101
Configuring the SYN threshold to prevent SYN floods.....	102
SYN proxy.....	102
Other flood types	102
DoS policies	103
GUI & CLI - What You May Not Know.....	104
Mouse Tricks	104
Changing the default column setting on the policy page	105
Example:	106
Naming Rules and Restrictions	106
Character Restrictions	106
Length of Fields Restrictions	107
Object Tagging and Coloring.....	107
Tags	108
Coloring.....	108
Numeric Values.....	108
Selecting options from a list	109
Enabling or disabling options	109
To Enable or Disable Optionally Displayed Features.....	109
Building firewall objects and policies.....	110
IPv4 Firewall Addresses.....	111
Scenario: Mail Server	111
Scenario: First Floor Network	111
Scenario: Marketing Department.....	112
Verification	113
IPv6 Firewall Addresses.....	113
Scenario: Mail Server	113
Scenario: First Floor Network	114
Verification	114
FQDN address	115
Verification	115
Changing the TTL of a FQDN address	116
New Geography-based Address	116
Wildcard Address	117
IPv4 Address Group.....	118
IPv6 Address Group.....	119
Multicast Address	119
Service Category	120

TCP/UDP/SCTP Service	121
ICMP Service	123
ICMPv6 Service	124
Service Group	125
Virtual IP address	127
VIP Group.....	128
IP Pool.....	129
Central NAT Table.....	130
Firewall Schedule - Recurring.....	131
Firewall Schedule - One-time	133
Schedule Group	134
Proxy Option	135
Oversized Files.....	139
Firewall Address Policy	140
Firewall User Identity Policy.....	142
Firewall Device Identity Policy	145
DoS Policy	147
Multicast forwarding	151
Sparse mode.....	151
Dense mode.....	152
Multicast IP addresses	153
PIM Support.....	154
Multicast forwarding and FortiGate units	154
Multicast forwarding and RIPv2.....	155
Configuring FortiGate multicast forwarding.....	156
Adding multicast security policies	157
Enabling multicast forwarding	157
Multicast routing examples.....	159
Example FortiGate PIM-SM configuration using a static RP.....	159
FortiGate PIM-SM debugging examples	168
Example multicast destination NAT (DNAT) configuration	174
Example PIM configuration that uses BSR to find the RP	176
Index	188

Change Log

Date	Change Description
2014-04-03	Updated IP pools information
2014-01-25	Updated some points on multicasting
2013-11-25	Added content regarding RFC 4582
2013-07-25	Changes based on Mantis numbers: 188766
2013-04-24	Changes based on fix numbers: 0155712,195140,201219 and 201288
2012-11-02	Initial Release.

Introduction

Welcome and thank you for selecting Fortinet products for your network protection. This document is intended to provide the concepts and techniques that will be needed to configure the FortiGate firewall on your FortiGate unit.

Before you start administrating your FortiGate device, certain assumptions have been made in the writing of this manual:

- You have administrative access to the Web based GUI or to the Command Line Interface.
- The FortiGate unit is integrated into your network.
- The operation mode (NAT or Transparent) has been configured.
- Network Interfaces have been configured.
- DNS settings have been configured.
- The system time settings have been configured.
- Firmware is up to date.
- FortiGuard Service licences are current and the device is able to connect to the FortiGuard Servers.
- If you are using FortiGuard Analysis & Management Service, it is properly configured.

How this Guide is Organized

[Firewall concepts](#) explains the ideas behind the components, techniques and processes that are involved in setting up and running a firewall in general and the FortiGate firewall in particular. The premise here is that regardless of how experienced someone is with firewalls as they go through the process of configuring a firewall that is new to them they are likely to come across a term or setting that they may not be familiar with even if it is only in the context of the setting they are working in at the moment. FortiGate firewall are quite comprehensive and can be very granular in the functions that they perform, so it makes sense to have a consistent frame of reference for the ideas that we will be working with.

Some examples of the concepts that will be addressed here are:

- [What is a Firewall?](#)
- NAT
- IPv6

[Firewall objects](#) describes the following firewall objects:

- Addressing
- Services
- Firewall Policies

[Network defense](#) describes various methods of defending your Network using the abilities of the FortiGate Firewall.

[GUI & CLI - What You May Not Know](#) helps you navigate and find the components in the Web-based Manager that you will need to build the functions. This section is does not include any in-depth explanations of what each object does as that is covered in the concepts section.

This section is for showing you where you need to input your information and let you know what format the interface expects to get that information

[Building firewall objects and policies](#) is similar to a cookbook in that it will refer to a number of common tasks that you will likely perform to get the full functionality out of your FortiGate firewall. Because of the way that firewalls are designed, performing many of the tasks requires that firewall components be set up in a number of different sections of the interface and be configured to work together to achieve the desired result. This section will bring those components all together as a straight forward series of instructions.

[Multicast forwarding](#) is a reference guide including the concepts and examples that are involved in the use of multicast addressing and policy forwarding as it is used in the FortiGate firewall.

FortiGate Firewall Components

The FortiGate firewall is made up of a number of different components that are used to build an impressive list of features that have flexibility of scope and granularity of control that provide protection that is beyond that provided by the basic firewalls of the past.

Some of the components that FortiOS uses to build features are:

- Interfaces
- VLANs
- Soft Switches
- Zones
- Predefined Addresses
- IP address based
- FQDN based
- Geography based
- Access Schedules
- Authentication
- Local User based
- Authentication Server based (Active Directory, Radius, LDAP)
- Device Based
- Configurable Services
- IPv4 and IPv6 protocol support

The features of FortiOS include but are not limited to:

- Security profiles, sometimes referred to as Unified Threat Management (UTM) or Next Generation Firewall (NGFW)
- Predefined firewall addresses (this includes IPv4 and IPv6, IP pools, wildcard addresses and netmasks, and geography-based addresses)
- Monitoring traffic
- Traffic shaping and per-IP traffic shaping (advanced)
- Firewall schedules
- Services (such as AOL, DHCP and FTP)
- Logging traffic
- Quality of Service (QoS)
- Identity-based policies
- Endpoint security

The [Firewall concepts](#) expands on what each of the features does and how they relate to the administration of the FortiGate firewall. The section will also try to explain some of the common firewall concepts that will be touched on in the implementing of these features.

[Building firewall objects and policies](#) shows how to perform specific tasks with the FortiGate firewall.

How does a FortiGate Protect Your Network

The FortiGate firewall protects your network by taking the various components and using them together to build a kind of wall or access control point so that anyone that is not supposed to be on your network is prevented from accessing your network in anyway other than those approved by you. It also protects your network from itself by keeping things that shouldn't happen from happening and optimizing the flow of traffic so that the network is protected from traffic congestion that would otherwise impede traffic flow.

Most people have at one time or another played with the children's toy system that is made up of interlocking blocks. The blocks come in different shapes and sizes so that you can build structures to suit your needs and in your way. The components of the FortiGate firewall are similar. You are not forced to use all of the blocks all of the time. You mix and match them to get the results that you are looking for. You can build a very basic structure that's only function is to direct traffic in and out to the correct subnets or you can build a fortress that only allows specific traffic to specific hosts from specific hosts at specific times of day and that is only if they provide the credentials that have been pre-approved and all of the traffic is encrypted so that even when the traffic is out on the Internet it is private from the world. Just like the interlocking blocks, what you build is up to you, but chances are if you put them together the right way there isn't much that can't be built.

Here is one example of how the components could be put together to support the requirements of a network infrastructure design.

- Off the Internal interface you could have separate VLANs. One for each for the departments of Sales, Marketing and Engineering so that the traffic from the users on one VLAN does not intrude upon the hosts of the other VLANs and the department are isolated from one another for security reasons.
- To ease in the administration each of the VLAN sub-interfaces is made a member of a zone so that security policies that apply to all of the hosts on all of the VLANs can be applied to all of them at once.
- Using the addresses component each of the IP address ranges could be assigned a user friendly name so that they could be referred to individually and then for policies that would refer to them all as a whole the individual ranges to be made members of an address group.
- Firewall schedules could be created to address the differing needs of each of the groups so that Sales and Marketing could be allowed access to the Internet during regular business hours and the Engineering department could be allowed access during the lunch break.
- By setting up the outgoing policies to use FortiGuard Web-filtering the employees could be prevented from visiting inappropriate sites and thus enforcing the policies of the HR department.
- A couple of virtual IP addresses with port forwarding could be configured to allow users on the Internet to access a web server on the DMZ subnet using the company's only Public IP address without affecting the traffic that goes to the company's mail server that is hosted on a complete different computer.
- Even though the Web server on the same DMZ has an FTP service to allow for the uploading of web pages to the web server from the Marketing and Engineer teams, by placing a DENY

policy on any FTP traffic from the Internet malicious users are prevented from abusing the FTP service.

- By monitoring the traffic as it goes through the policies you can verify that the policies are in working order.
- By using a combination of ALLOW and DENY policies and placing them in the correct order you could arrange for an outside contractor to be allowed to update the web site as well

These set of configurations is not extensive but it does give an idea of how different components can be mixed and matched to build a configuration that meets an organization's needs but at the same time protect it from security risks.

Firewall concepts

There are a number of concepts that are consistent throughout the firewall industry and having a solid grasp of these ideas and terms can give you a better idea of what your FortiGate firewall is capable of and how it will be able to fit within your networks architecture.

This chapter describes the following firewall concepts:

- What is a Firewall?
- IPv6
- NAT
- How Packets are handled by FortiOS
- FortiGate Modes
- Quality of Service
- Interfaces and Zones

What is a Firewall?

The term firewall originally referred to a wall intended to confine a fire or potential fire within a building. Later uses refer to similar structures, such as the metal sheet separating the engine compartment of a vehicle or aircraft from the passenger compartment.

A firewall can either be software-based or hardware-based and is used to help keep a network secure. Its primary objective is to control the incoming and outgoing network traffic by analyzing the data packets and determining whether it should be allowed through or not, based on a predetermined rule set. A network's firewall builds a bridge between an internal network that is assumed to be secure and trusted, and another network, usually an external (inter)network, such as the Internet, that is not assumed to be secure and trusted.

Network Layer or Packet Filter Firewalls

Stateless Firewalls

Stateless firewalls are the oldest form of these firewalls. They are faster and simple in design requiring less memory because they process each packet individually and don't require the resources necessary to hold onto packets like stateful firewalls. Stateless firewalls inspect each packet individually and check to see if it matches a predetermined set of rules. According to the matching rule the packet is either be allowed, dropped or rejected. In the case of a rejection an error message is sent to the source of the traffic. Each packet is inspected in isolation and information is only gathered from the packet itself. Simply put, if the packets were not specifically allowed according to the list of rules held by the firewall they were not getting through.

Stateful Firewalls

Stateful firewalls retain packets in memory so that they can maintain context about active sessions and make judgements about the state of an incoming packet's connection. This enables Stateful firewalls to determine if a packet is the start of a new connection, a part of an existing connection, or not part of any connection. If a packet is part of an existing connection based on comparison with the firewall's state table, it will be allowed to pass without further processing. If a packet does not match an existing connection, it will be evaluated according to

the rules set for new connections. Predetermined rules are used in the same way as a stateless firewall but they can now work with the additional criteria of the state of the connection to the firewall.



Best Practices Tip for improving performance:

Blocking the packets in a denied session can take more CPU processing resources than passing the traffic through. By putting denied sessions in the session table, they can be kept track of in the same way that allowed sessions are so that the FortiGate unit does not have to redetermine whether or not to deny all of the packets of a session individually. If the session is denied all packets of that session are also denied.

In order to configure this you will need to use 2 CLI commands

```
config system setting
    set ses-denied-traffic enable
    set block-session-timer <integer 1 - 300> (this determines in seconds
        how long, in seconds, the session is kept in the table)
end
```

Application Layer Firewalls

Application layer filtering is yet another approach and as the name implies it works primarily on the Application Layer of the OSI Model.

Application Layer Firewalls actually, for lack of a better term, understand certain applications and protocols. Examples would be FTP, DNS and HTTP. This form of filtration is able to check to see if the packets are actually behaving incorrectly or if the packets have been incorrectly formatted for the protocol that is indicated. This process also allows for the use of deep packet inspection and the sharing of functionality with Intrusion Prevention Systems (IPS).

Application-layer firewalls work on the application level of the TCP/IP stack (i.e., all browser traffic, or all telnet or ftp traffic), and may intercept all packets traveling to or from an application. They block other packets (usually dropping them without acknowledgment to the sender). Application firewalls work much like a packet filter but application filters apply filtering rules (allow/block) on a per process basis instead of filtering connections on a per port basis.

On inspecting all packets for improper content, firewalls can restrict or prevent outright the spread of networked computer worms and trojans. The additional inspection criteria can add extra latency to the forwarding of packets to their destination.

Proxy Servers

A proxy server is an appliance or application that acts as an intermediary for communicating between computers. A computer has a request for information. The packets are sent to the designated resource but before they can get there they are blocked by the proxy server saying that it will take the request and pass it on. The Proxy Server processes the request and if it is valid it passes onto the designated computer. The designated computer gets the packet and processes the request, sending the answer back to the proxy server. The proxy server sends the information back to the originating computer. It's all a little like a situation with two people who refuse to talk directly with each other using someone else to take messages back and forth.

From a security stand point a Proxy Server can serve a few purposes:

- Protects the anonymity of the originating computer
- The two computers never deal directly with each other
- Packets that are not configured to be forwarded are dropped before reaching the destination computer.
- If malicious code is sent it will affect the Proxy server with out affecting the originating or sending computer.

Proxies can perform a number of roles including:

- Content Filtering
- Caching
- DNS proxy
- Bypassing Filters and Censorship
- Logging and eavesdropping
- Gateways to private networks
- Accessing service anonymously

Security Profiles

Unified Threat Management and Next Generation Firewall are terms originally coined by market research firms and refer to the concept of a comprehensive security solution provided in a single package. It is basically combining of what used to be accomplished by a number of different security technologies all under a single umbrella or in this case, a single device. On the FortiGate firewall this is achieved by the use of Security Profiles and optimized hardware.

In effect it is going from a previous style of firewall that included among its features:

- Gateway Network Firewall
- Routing
- VPN

To a more complete system that includes:

- Gateway Network Firewall
- Routing
- VPN
- Traffic Optimization
- Proxy Services
- Content Filtering
- Application Control
- Intrusion Protection
- Denial of Service Attack Protection
- Anti-virus
- Anti-spam
- Data Leak Prevention
- Endpoint Control of Security Applications
- Load Balancing
- WiFi Access Management
- Authentication Integration into Gateway Security
- Logging
- Reporting

Advantages of using Security Profiles

- Avoidance of multiple installations.
- Hardware requirements are fewer.
- Fewer hardware maintenance requirements.
- Less space required.
- Compatibility - multiple installations of products increase the probability of incompatibility between systems.
- Easier support and management.
- There is only one product to learn therefore a reduced requirement of technical knowledge.
- Only a single vendor so there are fewer support contracts and Service Level Agreements.
- Easier to incorporated into existing security architecture.
- Plug and play architecture.
- Web based GUI for administration.

IPv6

What is IPv6?

Internet Protocol version 6 (IPv6) will succeed IPv4 as the standard networking protocol of the Internet. IPv6 provides a number of advances over IPv4 but the primary reason for its replacing IPv4 is its limitation in addresses. IPv4 uses 32 bit addresses which means there is a theoretical limit of 2 to the power of 32. The IPv6 address scheme is based on a 128 bit address or a theoretical limit of 2 to the power of 128.

Possible Addresses:

- IPv4 = 4,294,967,296 (over 4 billion)
- IPv6 = 340,282,366,920,938,463,463,374,607,431,768,211,456 (over 340 undecillion - We had to look that term up. We didn't know what a number followed by 36 digits was either)

Assuming a world population of approximately 8 billion people, IPv6 would allow for each individual to have approximately 42,535,295,865,117,200,000,000,000,000 devices with an IP address. That's 42 quintillion devices.

There is little likelihood that you will ever need to worry about these numbers as any kind of serious limitation in addressing but they do give an idea of the scope of the difference in the available addressing.

Aside from the difference of possible addresses there is also the different formatting of the addresses that will need to be addressed.

A computer would view an IPv4 address as a 32 bit string of binary digits made up of 1s and 0s, broken up into 4 octets of 8 digits separated by a period “.”

Example:

```
10101100.00010000.11111110.00000001
```

To make number more user friendly for humans we translate this into decimal, again 4 octets separated by a period “.” which works out to:

```
172.16.254.1
```

A computer would view an IPv6 address as a 128 bit string of binary digits made up of 1s and 0s, broken up into 8 octets of 16 digits separated by a colon “:”

```
1000000000000001:0000110110111000:101011000001000:1111111000000001:00000000  
00000000:0000000000000000:0000000000000000:0000000000000000
```

To make number a little more user friendly for humans we translate this into hexadecimal, again 8 octets separated by a colon “:” which works out to:

```
8001:0DB8:AC10:FE01:0000:0000:0000:0000:
```

Because any four-digit group of zeros within an IPv6 address may be reduced to a single zero or altogether omitted, this address can be shortened further to:

```
8001:0DB8:AC10:FE01:0:0:0:0
```

or

```
8001:0DB8:AC10:FE01::
```

Some of the other benefits of IPv6 include:

- More efficient routing
- Reduced management requirement
- Stateless auto-reconfiguration of hosts
- Improved methods to change Internet Service Providers
- Better mobility support
- Multi-homing
- Security
- Scoped address: link-local, site-local and global address space

IPv6 in FortiOS

From an administrative point of view IPv6 works almost the same as IPv4 in FortiOS. The primary difference is the use IPv6 format for addresses. There is also no need for NAT if the FortiGate firewall is the interface between IPv6 networks. If the subnets attached to the FortiGate firewall are IPv6 and IPv4 NAT can be configured between the 2 different formats. This will involve either configuring a dual stack routing or IPv4 tunnelling configuration. The reason for this is simple. NAT was developed primarily for the purpose of extending the number of usable IPv4 addresses. IPv6's addressing allows for enough available addresses so the NAT is no longer necessary.

When configuring IPv6 in FortiOS, you can create a dual stack route or IPv4-IPv6 tunnel. A dual stack routing configuration implements dual IP layers, supporting both IPv4 and IPv6, in both hosts and routers. An IPv4-IPv6 tunnel is essentially similar, creating a tunnel that encapsulates IPv6 packets within IPv4 headers that carry these IPv6 packets over IPv4 tunnels. The FortiGate unit can also be easily integrated into an IPv6 network. Connecting the FortiGate unit to an IPv6 network is exactly the same as connecting it to an IPv4 network, the only difference is that you are using IPv6 addresses.

By default the IPv6 settings are not displayed in the Web-based Manager. It is just a matter of enabling the display of these feature to use them through the web interface. To enable them just go to System > Admin > Settings and select IPv6 Support on GUI. Once enabled, you will be able to use IPv6 addresses as well as the IPv4 addressing for the following FortiGate firewall features:

- Static routing
- Policy Routing
- Packet and network sniffing
- Dynamic routing (RIPv6, BGP4+, and OSPFv3)
- IPsec VPN
- DNS
- DHCP
- SSL VPN
- Network interface addressing
- Security Profiles protection
- Routing access lists and prefix lists
- NAT/Route and Transparent mode
- NAT 64 and NAT 66
- IPv6 tunnel over IPv4 and IPv4 tunnel over IPv6
- Logging and reporting
- Security policies
- SNMP
- Authentication
- Virtual IPs and groups
- IPv6 over SCTP
- IPv6-specific troubleshooting, such as ping6

Dual Stack routing configuration

Dual stack routing implements dual IP layers in hosts and routers, supporting both IPv6 and IPv4. A dual stack architecture supports both IPv4 and IPv6 traffic and routes the appropriate

traffic as required to any device on the network. Administrators can update network components and applications to IPv6 on their own schedule, and even maintain some IPv4 support indefinitely if that is necessary. Devices that are on this type of network, and connect to the Internet, can query Internet DNS servers for both IPv4 and IPv6 addresses. If the Internet site supports IPv6, the device can easily connect using the IPv6 address. If the Internet site does not support IPv6, then the device can connect using the IPv4 addresses. In the FortiOS dual stack architecture it is not just the basic addressing functions that operate in both versions of IP. The other features of the appliance such as Security Profiles and routing can also use both IP stacks.

If an organization with a mixed network uses an Internet service provider that does not support IPv6, they can use an IPv6 tunnel broker to connect to IPv6 addresses that are on the Internet. FortiOS supports IPv6 tunnelling over IPv4 networks to tunnel brokers. The tunnel broker extracts the IPv6 packets from the tunnel and routes them to their destinations.

IPv6 Tunnelling

IPv6 Tunnelling is the act of tunnelling IPv6 packets from an IPv6 network through an IPv4 network to another IPv6 network. This is different than Network Address Translation (NAT) because once the packet reaches its final destination the true originating address of the sender will still be readable. The IPv6 packets are encapsulated within packets with IPv4 headers, which carry their IPv6 payload through the IPv4 network. This type of configuration is more appropriate for those who have completely transitional over to IPv6, but need an Internet connection, which is still mostly IPv4 addresses.

The key to IPv6 tunnelling is the ability of the 2 devices, whether they are a host or a network device, to be dual stack compatible. They have to be able to work with both IPv4 and IPv6 at the same time. In the process the entry node of the tunnel portion of the path will create an encapsulating IPv4 header and transmit the encapsulated packet. The exit node at the end of the tunnel receives the encapsulated packet. The IPv4 header is removed. The IPv6 header is updated and the IPv6 packet is processed.

There are two types of tunnels in IPv6:

Automatic tunnels	Automatic tunnels are configured by using IPv4 address information embedded in an IPv6 address – the IPv6 address of the destination host includes information about which IPv4 address the packet should be tunnelled to.
--------------------------	--

Configured tunnels	Configured tunnels must be configured manually. These tunnels are used when using IPv6 addresses that do not have any embedded IPv4 information. The IPv6 and IPv4 addresses of the endpoints of the tunnel must be specified.
---------------------------	--

Tunnel Configurations

There are a few ways in which the tunnelling can be performed depending on which segment of the path between the end points of the session the encapsulation takes place.

Network Device to Network Device	Dual Stack capable devices connected by an IPv4 infrastructure can tunnel IPv6 packets between themselves. In this case, the tunnel spans one segment of the path taken by the IPv6 packets.
---	--

Host to Network Device	Dual Stack capable hosts can tunnel IPv6 packets to an intermediary IPv6 or IPv4 network device that is reachable through an IPv4 infrastructure. This type of tunnel spans the first segment of the path taken by the IPv6 packets.
-------------------------------	--

Host to Host	Dual Stack capable hosts that are interconnected by an IPv4 infrastructure can tunnel IPv6 packets between themselves. In this case, the tunnel spans the entire path taken by the IPv6 packets.
Network Device to Host	Dual Stack capable network devices can tunnel IPv6 packets to their final destination IPv6 or IPv4 host. This tunnel spans only the last segment of the path taken by the IPv6 packets.

Regardless of whether the tunnel starts at a host or a network device, the node that does the encapsulation needs to maintain soft state information, such as the maximum transmission unit (MTU), about each tunnel in order to process the IPv6 packets.

Tunnelling IPv6 through IPSec VPN

A variation on the tunnelling IPv6 through IPv4 is using an IPSec VPN tunnel between two FortiGate devices. FortiOS supports IPv6 over IPSec. In this sort of scenario, two networks using IPv6 behind FortiGate units are separated by the Internet, which uses IPv4. An IPSec VPN tunnel is created between the two FortiGate units and a tunnel is created over the IPv4 based Internet but the traffic in the tunnel is IPv6. This has the additional advantage of making the traffic secure as well.

NAT

What is NAT?

NAT or Network Address Translation is the process that enables a single device such as a router or firewall to act as an agent between the Internet or Public Network and a local or private network. This “agent”, in real time, translates the source IP address of a device on one network interface, usually the Internal, to a different IP address as it leaves another interface, usually the interface connected to the ISP and the Internet. This enables a single public address to represent a significantly larger number of private addresses.

The Origins of NAT

In order to understand NAT it helps to know why it was created. At one time, every computer that was part of a network had to have its own addresses so that the other computers could talk to it. There were a few protocols in use at the time, some of which were only for use on a single network, but of those that were routable, the one that had become the standard for the Internet was IP (Internet Protocol) version 4.

When IP version 4 addressing was created nobody had any idea how many addresses would be needed. The total address range was based on the concept of 2 to the 32nd power, which works out to be 4 294 967 296 potential addresses. Once you eliminate some of those for reserved addresses, broadcast addresses, network addresses, multicasting, etc., you end up with a workable scope of about 3.2 million addressees. This was thought to be more than enough at the time. The designers were not expecting the explosion of personal computing, the World Wide Web or smart phones. As of the beginning of 2012, some estimate the number of computers in the world in the neighborhood of 1 billion, and most of those computer users are going to want to be on the Internet or Search the World Wide Web. In short, we ran out of addresses.

This problem of an address shortage was realized before we actually ran out, and in the mid 1990s two technical papers called RFCs numbered 1631 (<http://www.ietf.org/rfc/rfc1631.txt>) and 1918 (<http://tools.ietf.org/html/rfc1918>), proposed components of a method that would be used

as a solution until a new addressing methodology could be implemented across the Internet infrastructure. For more information on this you can look up IP version 6.

RFC 1631 described a process that would allow networking devices to translate a single public address to multiple private IP addresses and RFC 1918 laid out the use of the private addresses. The addresses that were on the Internet (Public IP addresses) could not be duplicated for them to work as unique addresses, but behind a firewall, which most large institutions had, they could use their own Private IP addresses for internal use and the internal computers could share the external or Public IP address.

To give an idea on a small scale how this works, imagine that a company has a need for 200 computer addresses. Before Private IP addresses and NAT the company would have purchased a full Class C address range which would have been 254 usable IP addresses; wasting about 50 addresses. Now with NAT, that company only needs 1 IP address for its 200 computers and this leaves the rest of the IP addresses in that range available for other companies to do the same thing.

NAT gives better value than it would first appear because it is not 253 companies that can use 254 addresses but each of those 254 companies could set up their networking infrastructures to use up to thousands of Private IP addresses, more if they don't all have to talk to the Internet at the same time. This process enabled the Internet to keep growing even though we technically have many more computers networked than we have addresses.

Static NAT

In Static NAT one internal IP address is always mapped to the same public IP address.

In FortiGate firewall configurations this is most commonly done with the use of Virtual IP addressing.

An example would be if you had a small range of IP addresses assigned to you by your ISP and you wished to use one of those IP address exclusively for a particular server such as an email server.

Say the internal address of the Email server was 192.168.12.25 and the Public IP address from your assigned addresses range from 256.16.32.65 to 256.16.32.127. Many readers will notice that because one of the numbers is above 255 that this is not a real Public IP address. The Address that you have assigned to the interface connected to your ISP is 256.16.32.66, with 256.16.32.65 being the remote gateway. You wish to use the address of 256.16.32.70 exclusively for your email server.

When using a Virtual IP address you set the external IP address of 256.16.32.70 to map to 192.168.12.25. This means that any traffic being sent to the public address of 256.16.32.70 will be directed to the internal computer at the address of 192.168.12.25

When using a Virtual IP address, this will have the added function that when ever traffic goes from 192.168.12.25 to the Internet it will appear to the recipient of that traffic at the other end as coming from 256.16.32.70.

You should note that if you use Virtual IP addressing with the Port Forwarding enabled you do not get this reciprocal effect and must use IP pools to make sure that the outbound traffic uses the specified IP address.

Dynamic NAT

Dynamic NAT maps the private IP addresses to the first available Public Address from a pool of possible Addresses. In the FortiGate firewall this can be done by using IP Pools.

Overloading

This is a form of Dynamic NAT that maps multiple private IP address to a single Public IP address but differentiates them by using a different port assignment. This is probably the most widely used version of NAT. This is also referred to as PAT (Port Address Translation) or Masquerading.

An example would be if you had a single IP address assigned to you by your ISP but had 50 or 60 computers on your local network.

Say the internal address of the interface connected to the ISP was 256.16.32.65 (again an impossible address) with 256.16.32.64 being the remote gateway. If you are using this form of NAT any time one of your computers accesses the Internet it will be seen from the Internet as 256.16.32.65. If you wish to test this go to 2 different computers and verify that they each have a different private IP address then go to a site that tells you your IP address such as www.ipchicken.com. You will see that the site gives the same result of 256.16.32.65, if it existed, as the public address for both computers.

As mentioned before this is sometimes called Port Address Translation because network device uses TCP ports to determine which internal IP address is associated with each session through the network device. For example, if you have a network with internal addresses ranging from 192.168.1.1 to 192.168.1.255 and you have 5 computers all trying to connect to a web site which is normally listening on port 80 all of them will appear to the remote web site to have the IP address of 256.16.32.65 but they will each have a different sending TCP port, with the port numbers being somewhere between 1 and 65 535, although the port numbers between 1 to 1024 are usually reserved or already in use. So it could be something like the following:

192.168.1.10	256.16.32.65:	port 486
192.168.1.23	256.16.32.65:	port 2409
192.168.1.56	256.16.32.65:	port 53763
192.168.1.109	256.16.32.65:	port 5548
192.168.1.201	256.16.32.65:	port 4396

And the remote web server would send the responding traffic back based on those port numbers so the network device would be able to sort through the incoming traffic and pass it on to the correct computer.

Overlapping

Because everybody is using the relative same small selection of Private IP addresses it is inevitable that there will be two networks that share the same network range that will need to talk with each other. This happens most often over Virtual Private Networks or when one organization ends up merging with another. This is a case where a private IP address may be translated into a different private IP address so there are no issues with conflict of addresses or confusion in terms of routing.

An example of this would be when you have a Main office that is using an IP range of 172.16.0.1 to 172.20.255.255 connecting through a VPN to a recently acquired branch office that is already running with an IP range of 172.17.1.1 to 172.17.255.255. Both of these ranges are perfectly valid but because the Branch office range is included in the Main Office range any time the system from the Main office try to connect to an address in the Branch Office the routing the system will not send the packet to the default gateway because according to the routing table the address is in its own subnet.

The plan here would be to NAT in both directions so that traffic from neither side of the firewall would be in conflict and they would be able to route the traffic. Everything coming from the Branch Office could be assigned an address in the 192.168.1.1 to 192.168.1.255 range and everything from the Main office going to the Branch Office could be assigned to an address in the 192.168.10.1 to 192.168.10.255 range.

Benefits of NAT

More IP addresses Available while Conserving Public IP Addresses

As explained earlier, this was the original intent of the technology and does not need to be gone into further.

Financial Savings

Because an organization does not have to purchase IP addresses for every computer in use there is a significant cost savings due to using the process of Network Address Translation.

Security Enhancements

One of the side benefits of the process of NAT is an improvement in security. Individual computers are harder to target from the outside and if port forwarding is being used computers on the inside of a firewall are less likely to have unmonitored open ports accessible from the Internet.

Ease of Compartmentalization of Your Network

With a large available pool of IP addresses to use internally a network administrator can arrange things to be compartmentalized in a rational and easily remembered fashion and networks can be broken apart easily to isolate for reasons of network performance and security.

Example:

You have a large organization that for security reasons has certain departments that do not share network resources.

You can have the main section of the organization set up as follows;

Network Devices	192.168.1.1 to 192.168.1.25
Internal Servers	192.168.1.26 to 192.168.1.50
Printers	192.168.1.51 to 192.168.1.75
Administration Personnel	192.168.1.76 to 192.168.1.100
Sales People	192.168.1.101 to 192.168.1.200
Marketing	192.168.1.201 to 192.168.1.250

You could then have the following groups broken off into separate subnets:

Accounting	192.168.100.1 to 192.168.100.255
Research and Development	172.16.1.1 to 172.16.255.255
Executive Management	192.168.50.1 to 192.168.50.255
Web sites and Email Servers	10.0.50.1 to 10.0.50.255

These addresses do not have to be assigned right away but can be used as planned ranges.

NAT in Transparent Mode

Similar to operating in NAT mode, when operating a FortiGate unit in Transparent mode you can add security policies and:

- Enable NAT to translate the source addresses of packets as they pass through the FortiGate unit.
- Add virtual IPs to translate destination addresses of packets as they pass through the FortiGate unit.
- Add IP pools as required for source address translation

A FortiGate unit operating in Transparent mode normally has only one IP address - the management IP. To support NAT in Transparent mode, you can add a second management IP. These two management IPs must be on different subnets. When you add two management IP addresses, all FortiGate unit network interfaces will respond to connections to both of these IP addresses.

Use the following steps to configure NAT in Transparent mode

1. Add two management IPs
2. Add an IP pool to the WAN1 interface
3. Add an Internal to WAN1 security policy

You can add the security policy from the web-based manager and then use the CLI to enable NAT and add the IP pool.

The usual practice of NATing in transparent mode makes use of two management IP addresses that are on different subnets, but this is not an essential requirement in every case.

If there is a router between the client systems and the FortiGate unit you can use the router's capabilities of tracking sessions to assign NATed addresses from an IP pool to the clients even if the assigned address don't belong to a subnet on your network.

Example:

Client computer has an IP address of 1.1.1.33 on the subnet 1.1.1.0/24

Router "A" sits between the client computer and the FortiGate (in Transparent mode) with the IP address of 1.1.1.1 on the client's side of the router and the IP address of 192.168.1.211 on the FortiGate's side of the router.

Use NAT to assign addresses from an address pool of 9.9.9.1 to 9.9.9.99 to traffic coming from gateway of 192.168.1.211.

To enable the return traffic to get to the original computer, set up a static route than assigns any traffic with a destination of 9.9.9.0/24 to go through the 192.168.1.211 gateway. As long as the session for the outgoing traffic has been maintained, communication between the client computer and the external system on the other side of the FortiGate will work.

Central NAT Table

The central NAT table enables you to define, and control with more granularity, the address translation performed by the FortiGate unit. With the NAT table, you can define the rules which dictate the source address or address group and which IP pool the destination address uses.

While similar in functionality to IP pools, where a single address is translated to an alternate address from a range of IP addresses, with IP pools there is no control over the translated port. When using the IP pool for source NAT, you can define a fixed port to guarantee the source port number is unchanged. If no fix port is defined, the port translation is randomly chosen by the FortiGate unit. With the central NAT table, you have full control over both the IP address and port translation.

The FortiGate unit reads the NAT rules in a top-down methodology, until it hits a matching rule for the incoming address. This enables you to create multiple NAT policies that dictate which IP pool is used based on the source address. The NAT policies can be rearranged within the policy list as well. NAT policies are applied to network traffic after a security policy.

NAT 64 and NAT46

NAT64 and NAT46 are the terms used to refer to the mechanism that allows IPv6 addressed hosts to communicate with IPv4 addressed hosts and vice-versa. Without such a mechanism an IPv6 node on a network such as a corporate LAN would not be able to communicate with a web site that was still in a IPv4 only environment and IPv4 environments would not be able to connect to IPv6 networks.

One of these setups involves having at least 2 interfaces, 1 on an IPv4 network and 1 on an IPv6 network. The NAT64 server synthesizes AAAA records, used by IPv6 from A records used by IPv4. This way client-server and peer to peer communications will be able to work between an IPv6 only client and an IPv4 server without making changes to either of the end nodes in the communication transaction. The IPv6 network attached to the FortiGate unit should be a 32 bit segment, (for instance 64:ff9b::/96, see RFC 6052[Set up a link to <http://tools.ietf.org/html/rfc6052>], RFC 6146[set up a link <http://tools.ietf.org/html/rfc6146>]). IPv4 address will be embedded into the communications from the IPv6 client.

Because the IPv6 range of addresses is so much larger than the IPv4 range, a one to one mapping is not feasible. Therefore the NAT64 function is required to maintain any IPv6 to IPv4 mappings that it synthesizes. This can be done either statically by the administrator or automatically by the service as the packets from the IPv6 network go through the device. The first method would be a stateless translation and the second would be a stateful translation. NAT64 is designed for communication initiated from IPv6 hosts to IPv4 addresses. It is address mapping like this that allows the reverse to occur between established connections. The stateless or manual method is an appropriate solution when the NAT64 translation is taking place in front of legacy IPv4 servers to allow those specific servers to be accessed by remote IPv6-only clients. The stateful or automatic solution is best used closer to the client side when you have to allow some specific IPv6 clients to talk to any of the IPv4-only servers on the Internet.

There are currently issues with NAT64 not being able to make everything accessible. Examples would be SIP, Skype, MSN, Goggle talk, and sites with IPv4 literals. IPv4 literals being IPv4 addresses that are imbedded into content rather than a FQDN.

Policies that employ NAT64 or NAT46 can be configured from the web-based manager as long as the feature is enabled using the Features setting found at *System > Config > Features*.

- To create a NAT64 policy go to *Policy > Policy > NAT64 Policy* and select *Create New*.
- To create a NAT46 policy go to *Policy > Policy > NAT46 Policy* and select *Create New*.

The difference between these NAT policies and regular polices is that there is no option to use the security profiles and sensors.

NAT 66

NAT 66 is Network Address Translation between 2 IPv6 network. The basic idea behind NAT 66 is no different than the regular NAT between IPv4 networks that we are all used to. The difference are in the mechanics of how it is performed, mainly because of the complexity and size of the addresses that are being dealt with.

In an IPv4 world, the reason for the use of NAT was usually one or a combination of the following 3 reasons:

- Improved security - actual addresses behind NAT are virtually hidden
- Amplification of addresses - hundreds of computers can use as little as a single public IP address
- Internal address stability - there is control of internal addressing. The addresses can stay the same even if Internet Service Providers change.

In these days of security awareness the protective properties of NAT are not something that are not normally depended on by themselves to defend a network and with the vastly enlarged IPv6 address scope there is no longer a need to amplify the available addresses. However, the desire to have internal address control still exists. The most common reason for using NAT66 is likely to be the maintaining of the existing address scheme of the internal network despite changes outside of it. Imagine that you have an internal network of 2000 IP addresses and one day the company changes its ISP and thus the addresses assigned to it. Even if most of the addressing is handled by DHCP, changing the address scheme is going to have an impact on operations.

Addressing stability can be achieved by:

- Keeping the same provider - this would depend on the reason for the change. If the cost of this provider has become too expensive this is unlikely. If the ISP is out of business it becomes impossible.
- Transfer the addresses from the old provider to the new one - There is little motivation for an ISP to do you a favor for not doing business with them.
- Get your own autonomous system number - this can be too expensive for smaller organizations.
- NAT - this is the only one on the list that is in the control of IT.

There are differences between NAT66 and IPv4 NAT. Because there is no shortage of addresses most organizations will be given a /48 network that can be translated into another /48 network. This allows for a one to one translation, no need for port forwarding. This is a good thing because port forwarding is more complicated in IPv6. In fact, NAT66 will actually just be the rewriting of the prefix on the address.

Example:

If your current IPv6 address is

```
2001:db8:cafe::/48
```

you could change it to

```
2001:db8:fea7::/48
```

There is an exception to the one to one translation. NAT66 cannot translate internal networks that contain 0xffff in bits 49 through 63 - this is due to the way checksums are calculated in TCP/IP: they use the one's-complement representation of numbers which assigns the value zero to both 0x0000 and 0xffff.

How Packets are handled by FortiOS

To give you idea of what happens to a packet as it makes its way through the FortiGate unit here is a brief overview. This particular trip of the packet is starting on the Internet side of the FortiGate firewall and ends with the packet exiting to the Internal network. An outbound trip would be similar. At any point in the path if the packet is going through what would be considered a filtering process and if fails the filter check the packet is dropped and does not continue any further down the path.

This information is covered in more detail in other in the Troubleshooting chapter of the FortiOS Handbook in the Life of a Packet section.

The incoming packet arrives at the external interface. This process of entering the device is referred to as **ingress**.

Step #1 - Ingress

1. Denial of Service Sensor
2. IP integrity header checking
3. IPSec connection check
4. Destination NAT
5. Routing

Step #2 - Stateful Inspection Engine

1. Session Helpers
2. Management Traffic
3. SSL VPN
4. User Authentication
5. Traffic Shaping
6. Session Tracking
7. Policy lookup

Step #3 - Security Profiles scanning process

1. Flow-based Inspection Engine
2. IPS
3. Application Control
4. Data Leak Prevention
5. Email Filter
6. Web Filter
7. Anti-virus
8. Proxy-based Inspection Engine
9. VoIP Inspection
10. Data Leak Prevention
11. Email Filter
12. Web Filter
13. Anti-virus
14. ICAP

Step #4 - Egress

1. IPSec
2. Source NAT
3. Routing

FortiGate Modes

The FortiGate unit has a choice of modes that it can be used in, either NAT/Route mode or Transparent mode. The FortiGate unit is able to operate as a firewall in both modes, but some of

its features are limited in Transparent mode. It is always best to choose which mode you are going to be using at the beginning of the set up. Once you start configuring the device, if you want to change the mode you are going to lose all configuration settings in the change process.

NAT/Route Mode

NAT/Route mode is the most commonly used mode by a significant margin and is thus the default setting on the device. As the name implies the function of NAT is commonly used in this mode and is easily configured but there is no requirement to use NAT. The FortiGate unit performs network address translation before IP packets are sent to the destination network.

These are some of the characteristics of NAT/Route mode:

- Typically used when the FortiGate unit is a gateway between private and public networks.
- Can act as a router between multiple networks within a network infrastructure.
- When used, the FortiGate unit is visible to the networks that is connected to.
- Each logical interface is on a distinct subnet.
- Each Interface needs to be assigned a valid IP address for the subnet that it is connected to it.

Transparent Mode

Transparent mode is so named because the device is effectively transparent in that it does not appear on the network in the way that other network devices show as a nodes in the path of network traffic. Transparent mode is typically used to apply the FortiOS features such as Security Profiles etc. on a private network where the FortiGate unit will be behind an existing firewall or router.

These are some of the characteristics of Transparent mode:

- The FortiGate unit is invisible to the network.
- All of its interfaces are on the same subnet and share the same IP address.
- The FortiGate unit uses a Management IP address for the purposes of Administration.
- Still able to use NAT to a degree, but the configuration is less straightforward

In Transparent mode, you can also perform NAT by creating a security policy or policies that translates the source addresses of packets passing through the FortiGate unit as well as virtual IP addresses and/or IP pools.

Quality of Service

The Quality of Service (QoS) feature allows the management of the level of service and preference given to the various types and sources of traffic going through the firewall so that the traffic that is important to the services and functions connecting through the firewall gets the treatment required to ensure the level of quality that is required. QoS can be helpful for organizations that are trying to manage their voice and streaming multi-media traffic, which can rapidly consume bandwidth. Both voice and streaming multi-media are sensitive to latency. FortiGate units support QoS using traffic policing, traffic shaping, and queuing.

Traffic policing

Packets are dropped that do not conform to bandwidth limitations

Traffic Shaping

Assigning minimum levels of bandwidth to be allocated to specific traffic flows to guarantee levels of service or assigning maximum levels of bandwidth to be allocated to specific traffic flows so that they do not impede other flows of traffic.

This helps to ensure that the traffic may consume bandwidth at least at the guaranteed rate by assigning a greater priority queue if the guarantee is not being met. Traffic shaping also ensures that the traffic cannot consume bandwidth greater than the maximum at any given instant in time. Flows that are greater than the maximum rate are subject to traffic policing.

Queuing

Assigning differing levels of priority to different traffic flows so that traffic flows that are adversely effected by latency are prevented from being effected by traffic flows that are not subject to the effects of latency. All traffic in a higher priority traffic queue must be completely transmitted before traffic in lower priority queues will be transmitted.

An example of where you would want to use something like this is if you had competing traffic flows of Voice over IP traffic and email traffic. The VoIP traffic is highly susceptible to latency issues. If you have a delay of a few seconds it is quickly noticeable when it is occurring. Email on the other hand can have a time delay of much longer and it is highly unlikely that it will be noticed at all.



By default, the priority given to any traffic is high, so if you want to give one type of traffic priority over all other traffic you will need to lower the priority of all of the other traffic.

For additional information about QoS, see the Traffic Shaping chapter of the FortiOS Handbook.

Interfaces and Zones

A Firewall is a gateway device that may be the nexus point for more than 2 networks. The interface that the traffic is coming in on and should be going out on is a fundamental concern for the purposes of routing as well as security. Routing, policies and addresses are all associated with interfaces. The interface is essentially the connection point of a subnet to the FortiGate unit and once connected can be connected to other subnets.

Physical interfaces or not the only ones that need to be considered. There are also virtual interfaces that can be applied to security policies. VLANs are one such virtual interface. Interfaces if certain VPN tunnels are another.

Policies are the foundation of the traffic control in a firewall and the Interfaces and addressing is the foundation that policies are based upon. Using the identity of the interface that the traffic connects to the FortiGate unit tells the firewall the initial direction of the traffic. The direction of the traffic is one of the determining factors in deciding how the traffic should be dealt with. You can tell that interfaces are a fundamental part of the policies because, by default, this is the criteria that the policies are sorted by.

Zones are a mechanism that was created to help in the administration of the firewalls. If you have a FortiGate unit with a large number of ports and a large number of nodes in you network the chances are high that there is going to be some duplication of policies. Zones provide the option of logically grouping multiple virtual and physical FortiGate firewall interfaces. The zones can then be used to apply security policies to control the incoming and outgoing traffic on those interfaces. This helps to keep the administration of the firewall simple and maintain consistency.

For example you may have several floors of people and each of the port interfaces could go to a separate floor where it connects to a switch controlling a different subnet. The people may be on different subnets but in terms of security they have the same requirements. If there were 4 floors and 4 interfaces a separate policy would have to be written for each floor to be allowed out on to the Internet off the WAN1 interface. This is not too bad if that is all that is being done, but now start adding the use of more complicated policy scenarios with Security Profiles, then throw in a number of Identity based issues and then add the complication that people in that organization tend to move around in that building between floors with their notebook computers. Each time a policy is created for each of those floors there is a chance of an inconsistency cropping up. Rather than make up an additional duplicate set of policies for each floor, a zone can be created that combines multiple interfaces. And then a single policy can be created that uses that zone as one side of the traffic connection.

Firewall objects

As was mentioned earlier, the components of the FortiGate firewall go together like interlocking building blocks. The Firewall objects are a prime example of those building blocks. They are something that can be configured once and then used over and over again to build what you need. They can assist in making the administration of the FortiGate unit easier and more intuitive as well as easier to change. By configuring these objects with their future use in mind as well as building in accurate descriptions the firewall will become almost self documenting. That way, months later when a situation changes, you can take a look at a policy that needs to change and use a different firewall object to adapt to the new situation rather than build everything new from the ground up to accommodate the change.

This chapter includes information about the following Firewall objects:

- [Addresses](#)
- [Services and TCP ports](#)
- [Firewall schedules](#)
- [Security profiles](#)

Addresses

Firewall addresses define sources and destinations of network traffic and are used when creating policies. When properly set up these firewall objects can be used with great flexibility to make the configuration of firewall policies simpler and more intuitive. The FortiGate unit compares the IP addresses contained in packet headers with a security policy's source and destination addresses to determine if the security policy matches the traffic.

The addresses in the FortiGate unit can include:

- IPv4 addresses
- IPv6 addresses
- IPv4 Address Groups
- IPv6 Address Groups
- IP Pools
- Virtual IP Addresses
- Geography based addresses
- Wildcard addresses and netmasks
- Fully Qualified Domain Name addresses

When setting up an address one of the parameters that is asked for is the interface. This means that the system will expect to see that address only on the interface that you select. You can only select one interface. If you expect that the address may be seen at more than one interface you can choose the "any" interface option. Whenever, possible it is best to choose a more specific interface than the "any" option because in the GUI configuration of firewall policies there is a drop down field that will show the possible addresses that can be used. The drop down will only show those addresses that can be on the interface assigned for that interface in the policy.

Example:

- You have an address called “XYZ”
- “XYZ” is set to the WAN1 interface because that is the only interface that will be able to access that address.
- When you are selecting a Source Address in the Web-based Manager for a policy that is using the DMZ the address “XYZ” will not be in the drop-down menu.

When there are only 10 or 20 addresses this is not a concern, but if there are a few hundred addresses configured it can make your life easier.

Addresses, address groups, and virtual IPs must have unique names to avoid confusion in firewall policies. If an address is selected in a policy, the address cannot be deleted until it is deselected from the policy.



Addressing Best Practices Tip

The other reason to assign a specific interface to addresses is that it will prevent you from accidentally assigning an address where it will not work properly. Using the example from earlier, if the “XYZ” address was assigned to the “Any” interface instead of WAN1 and you configure the “XYZ” address.

IPv4 Address and Net Mask

When representing hosts by an IP address with a netmask, the IP address can represent one or more hosts. For example, a firewall address can be:

- A single host such as a single computer with the address 192.45.46.45
- A range of hosts such as all of the hosts on the subnet 192.45.46.1 to 192.45.46.255
- All hosts, represented by 0.0.0.0 which matches any IP address

The netmask corresponds to the subnet class of the address being added, and can be represented in either dotted decimal or CIDR format. The FortiGate unit automatically converts CIDR formatted netmasks to dotted decimal format. Example formats:

- Netmask for a class A subnet of 16,777,214 usable addresses: 255.0.0.0, or /8
- Netmask for a class B subnet of 65,534 usable addresses: 255.255.0.0, or /16
- Netmask for a class C subnet of 254 usable addresses: 255.255.255.0, or /24
- Netmask for subnetted class C of 126 usable addresses: 255.255.255.128, or /25
- Netmask for subnetted class C of 62 usable addresses: 255.255.255.128, or /26
- Netmask for subnetted class C of 30 usable addresses: 255.255.255.128, or /27
- Netmask for subnetted class C of 14 usable addresses: 255.255.255.128, or /28
- Netmask for subnetted class C of 6 usable addresses: 255.255.255.128, or /29
- Netmask for subnetted class C of 2 usable addresses: 255.255.255.128, or /30
- Netmask for a single computer: 255.255.255.255, or /32
- Netmask used with 0.0.0.0 to include all IP addresses: 0.0.0.0, or /0

So for a single host or subnet the valid format of IP address and netmask could be either:

x.x.x.x/x.x.x.x, such as 192.168.1.0/255.255.255.0

or

x.x.x.x/x, such as 192.168.1.0/24

It is also possible to describe a range of IP addresses with a subnet. This would be a continuous set of IP addresses within a subnet. It does not have to include the whole subnet. The formats would be (the * being used as a wildcard character):

x.x.x.x-x.x.x.x, such as 192.168.110.100-192.168.110.120

x.x.x.[x-x], such as 192.168.110.[100-120]

x.x.x.*, such as 192.168.110.*

FQDN Addressing

By using Fully Qualified Domain Name (FQDN) addressing you can take advantage of the dynamic ability of the service to keep up with address changes without having to manually change the addresses on the FortiGate. FQDN addresses are most often used with external web sites but they can be used for internal web sites as well if there is a trusted DNS server that can be accessed. FQDN addressing also comes in handy for large web sites that may use multiple addresses and load balancers for their web sites. The FortiGate firewall automatically maintains a cached record of all the addresses resolved by the DNS for the FQDN addresses used.

For example, if you were doing this manually and you wanted to have a security policy that involved Google you could track down all of the IP addresses that they use across multiple countries. Using the FQDN address is simpler and more convenient.

When representing hosts by an FQDN, the domain name can also be a subdomain, such as mail.example.com.

Valid FQDN formats include:

- <host_name>.<top_level_domain_name> such as example.com
- <host_name>.<second_level_domain_name>.<top_level_domain_name>, such as mail.example.com

The FortiGate firewall keeps track of the DNS TTLs so as the entries change on the DNS servers the IP address will effectively be updated for the FortiGate. As long as the FQDN address is used in a security policy, it stores the address in the DNS cache.



There is a possible security downside to using FQDN addresses. Using a fully qualified domain name in a security policy means that your policies are relying on the DNS server to be accurate and correct. DNS servers in the past were not seen as potential targets because the thinking was that there was little of value on them and therefore are often not as well protected as some other network resources. People are becoming more aware that the value of the DNS server is that in many ways it controls where users and computers go on the Internet. Should the DNS server be compromised, security policies requiring domain name resolution may no longer function properly.

Geography Based Addressing

Geography based addressing enables you to design policies based on addresses that are associated with a country.

This feature can be used to make either inclusive or exclusive policies. For instance, if you have a SSL VPN where the users will only be connecting from a single country, but you don't know from where in that country, you can filter out any connections coming in that are from outside that country.

On the other side of the equation, if you find that you are constantly being attacked by malicious intruders from a few countries that you have no dealings with you can block access to them before any traffic comes through.

The matching of geographical country designations to an IP address is achieved by collecting data from any IP addresses that connect to any of the FortiGuard Servers throughout the world. As a secondary task, when a FortiGuard server connects to an IP it also does a search on the Country of origin for the address and updates the database.

There is no single comprehensive list of IP addresses and their locations available because IP addresses can be transferred between ISPs or countries and some organization may not keep complete or up-to-date records regarding locations. FortiGuard Services are constantly updating their database of addresses matched to locations, but the database is dynamic and there may be addresses that have not been resolved to a location. While this means that there can be gaps in the completeness of the database it is possible to fill them in manually by means local to your FortiGate unit.

IPv6 does not support geography-based addressing. This feature is for IPv4 addresses only.



Best Practices Tip:

Based on the limitation of the IP address matched to country database, it is best to use this type of address in a group with other addresses to fill in the gaps. For instance, if you are a company in Country “A” and all of your employees that will be using the SSL-VPN connection are in that country, the best practice would be to create an address group that includes the geographical address of Country “A”. As valid addresses appear that are not allowed, you can add these other IPs to that group using IP addresses or IP range addresses without having to change the policy itself.

If you are trying to block addresses the principle works just the same. Your logs show that someone from IP address x.x.x.x has been trying to connect inappropriately to your network. You use a IP locator web site to determine that they have been attempting to connect from Country “X”. Up until now they have not been successful, but you don’t deal with the country they are connecting from so don’t mind blocking the whole country. Create an address group that is designed for Blocking Access to any addresses in it, then add the geographical address for Country “X”. Even if the policy does not block every single IP address from that country you have greatly increased your odds of blocking potential intrusion attempts. As your logs show other attempts you can look them up in an IP locator web site and if they are from the same country you can add the IP address for the subnet that they are connecting from.

Address Groups

Address groups are designed for ease of use in the administration of the device. If you have a number of addresses or address ranges that will commonly be treated the same or require the same security policies, you can put them into address groups, rather than entering multiple individual addresses in each policy refers to them.

The use of groups is not required. If you have a number of different addresses you could add them individually to a policy and the FortiGate firewall will process them just as quickly and efficiently as if they were in a group, but the chances are that if you have used a group once you could need to use it again and depending on the number of addresses involved entering them individually for each policy can become tedious and the likelihood of an address being missed becomes greater. If you have a number of policies using that combination of addresses it is much easier to add or subtract addresses from the group than to try and remember all of the firewall policies that combination of addresses was used in. With the group, you only have to make the one edit and it is used by any firewall policy using that address group.

Because security policies require addresses with homogenous network interfaces, address groups should contain only addresses bound to the same network interface, or to Any.

For example, if address 1.1.1.1 is associated with port1, and address 2.2.2.2 is associated with port2, they cannot be in the same group. However, if 1.1.1.1 and 2.2.2.2 are configured with an interface of Any, they can be grouped, even if the addresses involve different networks.

IPv4 address groups and IPv6 address groups are created and treated separately. You cannot mix IPv4 firewall addresses and IPv6 firewall addresses in the same address group. Because the Internet is currently based on IPv4 addresses IPv6 address groups cannot include FQDN or Geography based addresses.

Wildcard Addressing

Wildcard addresses are addresses that identify ranges of IP addresses, reducing the amount of firewall addresses and security policies required to match some of the traffic on your network. Wildcard addresses are an advanced feature, usually required only for complex networks with complex firewall filtering requirements. By using these wildcard addresses in the firewall configuration, administrators can eliminate creating multiple, separate IP based address objects and then grouping them to then apply to multiple security policies.

A wildcard address consists of an IP address and a wildcard netmask, for example, 192.168.0.56 255.255.0.255. In this example, the IP address is 192.168.0.56 and the wildcard netmask is 255.255.0.255. The IP address defines the networks to match and the wildcard netmask defines the specific addresses to match on these networks.

In a wildcard netmask, zero means ignore the value of the octet in the IP address, which means the wildcard firewall address matches any number in this address octet. This also means that the number included in this octet of IP address is ignored and can be any number. Usually, if the octet in the wildcard netmask is zero, the corresponding octet in the IP address is also zero.

In a wildcard netmask, a number means match addresses according to how the numbers translate into binary addresses. For example, the wildcard netmask is 255; the wildcard address will only match addresses with the value for this octet that is in the IP address part of the wildcard address. So, if the first octet of the IP address is 192 and the first octet of the wildcard netmask is 255, the wildcard address will only match addresses with 192 in the first octet.

In the above example, the wildcard address 192.168.0.56 255.255.0.255 would match the following IP addresses:

192.168.0.56, 192.168.1.56, 192.168.2.56, ..., 192.168.255.56

The wildcard addresses 192.168.0.56 255.255.0.255 and 192.168.1.56 255.255.0.255 define the same thing since the 0 in the wildcard mask means to match any address in the third octet.

If we use the wildcard address 172.0.20.10 255.0.255.255, it would match the following IP addresses:

172.1.20.10, 172.2.20.10, 172.3.20.10, ..., 172.255.20.10

In a wildcard netmask, a number other than 255 matches multiple addresses for this octet. You can perform a binary conversion to calculate the addresses that would be matched by a given value. For example, to create the IP address and wildcard netmask to match the following network addresses:

192.168.32.0/24

192.168.33.0/24

192.168.34.0/24

192.168.35.0/24

192.168.36.0/24

192.168.37.0/24

192.168.38.0/24

192.168.39.0/24

Table 1 shows how to write the third octet for these networks according to the octet bit position and address value for each bit.

Table 1: Octet bit position and address value for each bit

Decimal	128	64	32	16	8	4	2	1
32	0	0	1	0	0	0	0	0
33	0	0	1	0	0	0	0	1
34	0	0	1	0	0	0	1	0
35	0	0	1	0	0	0	1	1
36	0	0	1	0	0	1	0	0
37	0	0	1	0	0	1	0	1
38	0	0	1	0	0	1	1	0
39	0	0	1	0	0	1	1	1
	M	M	M	M	M	D	D	D

Since the first five bits match, the networks can be summarized into one network (192.168.32.0/21 or 192.168.32.0 255.255.248.0). All eight possible combinations of the three low-order bits are relevant for the network ranges. The wildcard address that would match all of these subnet addresses can be written as 192.168.32.0 255.255.248.0.

Wildcard addresses are similar to routing access list wildcard masks. You add routing access lists containing wildcard masks using the `config router access list` command. However, router access list wildcard masks use the inverse of the masking system used for firewall wildcard addresses. For the router access list wildcard masks, zero (0) means match all IP addresses and one (1) means ignore all IP addresses. So to match IP addresses 192.168.0.56, 192.268.1.56, 192.168.2.56,... 192.168.255.56 you would use the following router access IP address prefix and wildcard mask: 192.168.0.56 0.0.255.0.

Wildcard firewall addresses are configured only in the CLI. The following is an example of how to configure a wildcard firewall address.

```
config firewall address
  edit example_wildcard_address
    set type wildcard
    set wildcard 192.168.0.56 255.255.0.255
  end
```

Virtual IP Addresses

The mapping of a specific IP address to another specific IP address is usually referred to as Destination NAT. FortiOS has a component that is a bit more specialized along this line called a Virtual IP Address, sometimes referred to as a VIP. FortiOS uses a Virtual IP address to map an External IP address to an IP address. This address does not have to be an individual host, it can also be an address range. This mapping can include all TCP/UDP ports or if Port Forwarding is enabled it will only refer to the specific ports configured.

Virtual IP addresses are typically used to NAT external or Public IP addresses to internal or Private IP addresses. Using a Virtual IP address between 2 internal Interfaces made up of Private IP addresses is possible but there is rarely a reason to do so as the 2 networks can just

use the IP addresses of the networks without the need for any address translation. Using a Virtual IP address for traffic going from the inside to the Internet is even less likely to be a requirement, but it is supported.

Something that needs to be considered when there are multiple Public IP addresses on the external interface(s) is that when a Virtual IP address is used without Port Forwarding enabled there is a reciprocal effect as far as traffic flow is concerned. Normally, on a firewall policy where NAT is enabled, for outgoing traffic the internal address is translated to the Public address that is assigned to the FortiGate, but if there is a Virtual IP address with no port forwarding enabled, then the Internal IP address in the Mapped field would be translated to the IP address configured as the External Address in the VIP settings.

Example:

- The assigned External address (WAN1) of the FortiGate unit is 172.12.96.3 with a subnet mask of 255.255.255.128
- There is a Virtual IP address set up to map the external address 172.12.96.127 on WAN1 to the internal IP address of 192.168.1.127
- Port Forwarding is not enabled because you want all allowed traffic going to the external IP address to go to this server.

In this case any outbound traffic from 192.168.1.127 will go out on WAN1 with the IP address of 172.12.96.127 as the source IP address.

In terms of actually using the Virtual IP address, they would be using in the security policies in the same places that other addresses would be used, usually as a Destination Address.



There is another type of address that the term “virtual IP address” commonly refers to which is used in load balancing and other similar configurations. In those cases, a number of devices share a separately created virtual IP address that can be sent to multiple possible devices. In FortiOS these are referred to as Virtual Servers and are configured in the “Load Balance” section.

Virtual IP Groups

Just like other address, Virtual IP addresses can be organized into groups for ease of administration. If you have multiple virtual IPs that are likely to be associated to common firewall policies rather than add them individually to each of the policies you can add the instead. That way, if the members of the group change then any changes made to the group will propagate to all of the polices using that group.

When using a Virtual IP address group the firewall policy will take into account all of the configured parameters of the Virtual IPs: IP addresses, Ports and port types.

IP Pools

IP Pools are a mechanism that allow sessions leaving the FortiGate Firewall to use NAT. An IP pool defines a single IP address or a range of IP addresses to be used as the source address for the duration of the session. These assigned addresses will be used instead of the IP address assigned to that FortiGate interface.



When using IP pools for NATing, there is a limitation that must be taken into account when configuring the pool. If the IP address(es) within the pool are different from the IP address(es) that are assigned to the interface communications based on those IP addresses will fail. For example if the IP addresses assigned to an interface are 172.16.100.1 -172.16.100.14, you cannot choose 10.11.12.50 - 10.11.12.59 for the IP pool.

There are 4 types of IP Pools that can be configured on the FortiGate firewall:

- One-to-One - in this case the only internal address used by the external address is the internal address that it is mapped to.
- Overload - this is the default setting. Internal addresses other than the one designated in the policy can use this address for the purposes of NAT.
- Fixed Port Range - rather than a single address to be used, there is a range of addresses that can be used as the NAT address. These addresses are randomly assigned as the connections are made.
- Port Block Allocation - this setting is used to allocate a block of port numbers for IP pool users. Two variables will also have to be set. The block size can be set from 64 to 4096 and as the name implies describes the number of ports in one block of port numbers. The number of blocks per user determines how many of these blocks will be assigned. This number can range from 1 to 128.



Be careful when calculating the values of the variables. The maximum number of ports that are available on an address is 65,536. If you chose the maximum value for both variables you will get a number far in excess of the available port numbers.

$$4096 \times 128 = 524,288$$

One of the more common examples is when you have an email server behind your FortiGate firewall and the range of IP addresses assigned to you by your ISP is more than one. If an organization is assigned multiple IP addresses it is normally considered a best practice to assign a specific address other than the one used for the Firewall to the mail server. However, when normal NAT is used the address assigned to the firewall is also assigned to any outbound sessions. Anti-spam services match the source IP address of mail traffic that they receive to the MX record on DNS servers as an indicator for spam. If there is a mismatch the mail may not get through so there is a need to make sure that the NATed address assigned matches the MX record.

You can also use the Central NAT table as a way to configure IP pools.

Source IP address and IP pool address matching when using a range

When the source addresses are translated to an IP pool that is a range of addresses, one of the following three cases may occur:

Scenario 1:

The number of source addresses equals that of IP pool addresses

In this case, the FortiGate unit always matches the IP addressed one to one.

If you enable fixed port in such a case, the FortiGate unit preserves the original source port. This may cause conflicts if more than one security policy uses the same IP pool, or the same IP addresses are used in more than one IP pool.

Scenario 2:

The number of source addresses is more than that of IP pool addresses

In this case, the FortiGate unit translates IP addresses using a wrap-around mechanism. If you enable fixed port in such a case, the FortiGate unit preserves the original source port. But conflicts may occur since users may have different sessions using the same TCP 5 tuples.

Scenario 3:

The number of source addresses is fewer than that of IP pool addresses

In this case, some of the IP pool addresses are used and the rest of them are not be used.

ARP Replies

If a FortiGate firewall interface IP address overlaps with one or more IP pool address ranges, the interface responds to ARP requests for all of the IP addresses in the overlapping IP pools. For example, consider a FortiGate unit with the following IP addresses for the port1 and port2 interfaces:

- port1 IP address: 1.1.1.1/255.255.255.0 (range is 1.1.1.0-1.1.1.255)
- port2 IP address: 2.2.2.2/255.255.255.0 (range is 2.2.2.0-2.2.2.255)

And the following IP pools:

- IP_pool_1: 1.1.1.10-1.1.1.20
- IP_pool_2: 2.2.2.10-2.2.2.20
- IP_pool_3: 2.2.2.30-2.2.2.40

The port1 interface overlap IP range with IP_pool_1 is:

$$(1.1.1.0-1.1.1.255) \text{ and } (1.1.1.10-1.1.1.20) = 1.1.1.10-1.1.1.20$$

The port2 interface overlap IP range with IP_pool_2 is:

$$(2.2.2.0-2.2.2.255) \text{ \& } (2.2.2.10-2.2.2.20) = 2.2.2.10-2.2.2.20$$

The port2 interface overlap IP range with IP_pool_3 is:

$$(2.2.2.0-2.2.2.255) \text{ \& } (2.2.2.30-2.2.2.40) = 2.2.2.30-2.2.2.40$$

And the result is:

- The port1 interface answers ARP requests for 1.1.1.10-1.1.1.20
- The port2 interface answers ARP requests for 2.2.2.10-2.2.2.20 and for 2.2.2.30-2.2.2.40

Select Enable NAT in a security policy and then select Dynamic IP Pool. Select an IP pool to translate the source address of packets leaving the FortiGate unit to an address randomly selected from the IP pool. Whether or not the external address of an IP Pool will respond to an ARP request can be disabled. You might want to disable the ability to respond to ARP requests so that these address cannot be used as a way into your network or show up on a port scan.

IP pools and zones

Because IP pools are associated with individual interfaces

IP pools cannot be set up for a zone. IP pools are connected to individual interfaces.

Fixed Port

Some network configurations do not operate correctly if a NAT policy translates the source port of packets used by the connection. NAT translates source ports to keep track of connections for a particular service.

However, enabling the use of a fixed port means that only one connection can be supported through the firewall for this service. To be able to support multiple connections, add an IP pool, and then select Dynamic IP pool in the policy. The firewall randomly selects an IP address from the IP pool and assigns it to each connection. In this case, the number of connections that the firewall can support is limited by the number of IP addresses in the IP pool.

Match-VIP

The match-vip feature allows the FortiGate unit to log virtual IP traffic that gets implicitly dropped. This feature eliminates the need to create two policies for virtual IPs; one that allows the virtual IP, and the other to get proper log entry for DROP rules.

For example, you have a virtual IP security policy and enabled the match-vip feature; the virtual IP traffic that is not matched by the policy is now caught.

The match-vip feature is available only in the CLI. By default, the feature is disabled.

Services and TCP ports

There are a number of different services and protocols in use on the Internet. The most commonly known is HTTP which is used by web servers to transmit requests and responses for unencrypted web pages. These services are set up to listen for requests on a numbered port. These services and protocols can use any port from 1 to 65,535. To keep things simple for everyone a large number of the more commonly used services started using a standardized list of ports. For instance, though it is not required, by default, most web servers listen for HTTP requests on port 80 and by default, web browsers will send HTTP traffic to port 80. If you wish to use another port such as 8080 you would put “:8080” at the end of the URL to indicate that you want the browser to use 8080 instead of the default port.

Example:

Default URL for HTTP traffic when the web server is listening on the standard HTTP port:

`http://fortinet.com`

URL to the same address when the web server is listening for HTTP traffic on port 8080

`http://fortinet.com:8080`

Services represent typical traffic types and application packets that pass through the FortiGate unit. Firewall services define one or more protocols and port numbers associated with each service. Security policies use service definitions to match session types. You can organize related services into service groups to simplify your security policy list.

Many well-known traffic types have been predefined on the FortiGate unit. If there is a service that does not appear on the list you can create a service or edit an existing one. You need to know the ports, IP addresses or protocols of that particular service or application uses, to create a service.



Best Practices

While you can edit a predefined service it is best to leave those ones alone and create a new service and name it something similar such as the same service name with a descriptive identifier appended.

Based on the previous example, instead of the name “HTTP” you could name the service “HTTP8080” or use the application that is using that port, “HTTP-Application”.

Categories

In order to make sorting through the services easier there is a field to categorize the services. The services can be sorted into the following groups:

- Uncategorized
- General
- Web Access
- File Access
- Email
- Network Services
- Authentication
- Remote Access
- Tunnelling
- VoIP, Messaging and Other Applications

Protocol Types

One of the fundamental aspects of a service is the type of protocol that use used to define it. When a service is defined one of the following categories of protocol needs to be determined:

- TCP/UDP/SCTP
- ICMP
- ICMP6
- IP

Depending on which of these protocol categories is choose another set of specifications will can also be defined.

TCP/UDP/SCTP

This is the most commonly used service protocol category. Once this category has been selected the other available options to choose are an address, either IP or FQDN, and the protocol and port number.

The protocol will be TCP, UDP or SCTP.

ICMP or ICMP6

When ICMP or ICMP6 is chosen the available options are the ICMP Type and its code.

IP

When IP is the chosen protocol type the addition option is the Protocol Number.

TCP

Transmission Control Protocol (TCP) is one of the core or fundamental protocols of the Internet. It is part of the Transport Layer of the OSI Model. It is designed to provide reliable delivery of data from a program on one device on the network or Internet to another program on another device on the network or Internet. TCP achieves its reliability because it is a connection based protocol. TCP is stream-oriented. It transports streams of data reliably and in order.

TCP establishes a prior connection link between the hosts before sending data. This is often referred to as the handshake. Once the link is established the protocol uses checks to verify that the data transmitted. If an error check fails the data is retransmitted. This makes sure that

the data is getting to the destination error free and in the correct order so that it can be put back together into a form that is identical to the way they were sent.

TCP is configured more for reliability than for speed and because of this TCP will likely be slower than a connectionless protocol such as UDP. This is why TCP is generally not used for real time applications such as voice communication or online gaming.

Some of the applications that use TCP are:

- World Wide Web (HTTP and HTTPS)
- Email (SMTP, POP3, IMAP4)
- Remote administration (RDP)
- File transfer (FTP)

UDP

User Datagram Protocol (UDP) like TCP is one of the core protocols of the Internet and part of the Transport Layer of the OSI Model. UDP is designed more for speed than reliability and is generally used for different applications than TCP. UDP sends messages, referred to as datagrams across the network or Internet to other hosts without establishing a prior communication link. In other words, there is no handshake.

UDP is an unreliable service as the datagrams can arrive out of order, duplicated or go missing without any mechanism to verify them. UDP works on the assumption that any error checking is done by the application or is not necessary for the function of the application. This way it avoids the overhead that is required to verify the integrity of the data.

This lack of overhead improves the speed of the data transfer and is why UDP is often used by applications that are time sensitive in nature. UDP's stateless nature is also great for applications that answer a large number of small queries from a large number of clients.

Common uses for UDP are:

- Domain Name Resolution (DNS)
- Time (NTP)
- Streaming media (RTSP, RTP and RTCP)
- Telephone of the Internet (VoIP)
- File Transfer (TFTP)
- Logging (SNMP)
- Online games (GTP and OGP)

SCTP

Stream Control Transmission Protocol (SCTP) is part of the Transport Layer of the OSI Model just like TCP and UDP and provides some of the features of both of those protocols. It is message or datagram orientated like UDP but it also ensures reliable sequential transport of data with congestion control like TCP.

SCTP provides the following services:

- Acknowledged error-free non-duplicated transfer of user data
- Data fragmentation to conform to discovered path MTU size
- Sequenced delivery of user messages within multiple streams, with an option for order-of-arrival delivery of individual user messages
- Optional bundling of multiple user messages into a single SCTP packet
- Network-level fault tolerance through supporting of multi-homing at either or both ends of an association
- Congestion avoidance behavior and resistance to flooding and masquerade attacks

SCTP uses multi-streaming to transport its messages which means that there can be several independent streams of messages traveling in parallel between the points of the transmission. The data is sent out in larger chunks of data than is used by TCP just like UDP but the messages include a sequence number within each message in the same way that TCP does so that the data can be reassembled at the other end of the transmission in the correct sequence without the data having to arrive in the correct sequence.

SCTP is effective as the transport protocol for applications that require monitoring and session-loss detection. For such applications, the SCTP path and session failure detection mechanisms actively monitor the connectivity of the session. SCTP differs from TCP in having multi-homing capabilities at either or both ends and several streams within a connection, typically referred to as an association. A TCP stream represents a sequence of bytes; an SCTP stream represents a sequence of messages.

Some common applications of SCTP include supporting transmission of the following protocols over IP networks:

- SCTP is important in 3G and 4G/LTE networks (for example, HomeNodeB = FemtoCells)
- SS7 over IP (for example, for 3G mobile networks)
- SCTP is also defined and used for SIP over SCTP and H.248 over SCTP
- Transport of Public Switched Telephone Network (PSTN) signaling messages over IP networks.

SCTP is a much newer protocol. It was defined by the IETF Signaling Transport (SIGTRAN) working group in 2000. It was introduced by [RFC 3286](#) and more fully define by [RFC 4960](#).

The FortiGate firewall can apply security policies to SCTP sessions in the same way as TCP and UDP sessions. You can create security policies that accept or deny SCTP traffic by setting the service to "ALL". FortiOS does not include pre-defined SCTP services. To configure security policies for traffic with specific SCTP source or destination ports you must create custom firewall services for SCTP.

FortiGate units route SCTP traffic in the same way as TCP and UDP traffic. You can configure policy routes specifically for routing SCTP traffic by setting the protocol number to 132. SCTP policy routes can route SCTP traffic according to the destination port of the traffic if you add a port range to the policy route.

You can configure a FortiGate unit to perform stateful inspection of different types of SCTP traffic by creating custom SCTP services and defining the port numbers or port ranges used by

those services. FortiGate units support SCTP over IPv4. The FortiGate unit performs the following checks on SCTP packets:

- Source and Destination Port and Verification Tag.
- Chunk Type, Chunk Flags and Chunk Length
- Verify that association exists
- Sequence of Chunk Types (INIT, INIT ACK, etc)
- Timer checking
- Four way handshake checking
- Heartbeat mechanism
- Protection against INIT/ACK flood DoS attacks, and long-INIT flooding
- Protection against association hijacking

FortiOS also supports SCTP sessions over IPsec VPN tunnels, as well as full traffic and event logging for SCTP sessions.

Specific Addresses in TCP/UDP/SCTP

In the TCP/UDP/SCTP services it is also possible to set the parameter for a specific IP or Fully Qualified Domain Name address. The IP/FQDN field refers to the destination address of the traffic, not the source. This means for example, that you can set up a custom service that will describe in a policy the TCP traffic over port 80 going to the web site example.com, but you cannot set up a service that describes the TCP traffic over port 80 that is coming from the computer with the address 192.168.29.59.

Protocol Port Values

The source and destination ports for TCP/UDP/SCTP services are important to get correct. If they are reversed the service will not work. The destination port(s) are the ones that refer to the ports that the computer will be listening on. These are the port numbers that most people are familiar with when they associate a port number to a protocol. In most cases the source port will be one that is randomly assigned by the computer that is not being already used by another service.

Most people associate HTTP with port 80. This means that a web-server will be listening on port 80 for any http requests being sent to the computer. The computer that is sending the request can use any port that is not already assigned to another service or communication session. There are 65,535 ports that it can randomly assign, but because the ports from 1 to 1024 are normally used for listening for incoming communications it is usually not in that range. It is unless there is a specific instance when you know that a communication will be coming from a predefined source port it is best practice to set the source port range from 1 to 65,535.

ICMP

The Internet Control Message Protocol (ICMP) is a protocol layered onto the Internet Protocol Suite to provide error reporting flow control and first-hop gateway redirection. It is normally used by the operating systems of networked computers to send connectivity status query, response and error messages. It is assigned protocol number 1. There is a version of the protocol for both IPv4 and for IPv6. It is not designed to be absolutely reliable like TCP.

ICMP is not typically used for transporting data or for end-user network applications with the exception of some diagnostic utilities such as ping and traceroute.

ICMP messages are sent in several situations, for example:

- when a datagram cannot reach its destination,
- time exceeded messages
- redirect messages
- when the gateway does not have the buffering capacity to forward a datagram
- when the gateway can direct the host to send traffic on a shorter route.

Some of the specific ICMP message types are:

- ICMP_ECHO
- ICMP_TIMESTAMP
- ICMP_INFO_REQUEST
- ICMP_ADDRESS

For ICMP error messages, only those reporting an error for an existing session can pass through the firewall. The security policy will allow traffic to be routed, forwarded or denied. If allowed, the ICMP packets will start a new session. Only ICMP error messages of a corresponding security policy is available will be sent back to the source. Otherwise, the packet is dropped. That is, only ICMP packets for a corresponding security policy can traverse the FortiGate unit.

ICMP Types and Codes

ICMP has a number of messages that are identified by the “Type” field. Some of these types have assigned “Code” fields as well. The table below shows the different types of ICMP Types with their associated codes if there are any.

Table 2: ICMP Types and Codes

Type Number	Type Name	Code
0	Echo Reply	
1	Unassigned	
2	Unassigned	

Table 2: ICMP Types and Codes (continued)

Type Number	Type Name	Code
3	Destination Unreachable	0 Net Unreachable 1 Host Unreachable 2 Protocol Unreachable 3 Port Unreachable 4 Fragmentation Needed and Don't Fragment was Set 5 Source Route Failed 6 Destination Network Unknown 7 Destination Host Unknown 8 Source Host Isolated 9 Communication with Destination Network is Administratively Prohibited 10 Communication with Destination Host is Administratively Prohibited 11 Destination Network Unreachable for Type of Service 12 Destination Host Unreachable for Type of Service 13 Communication Administratively Prohibited 14 Host Precedence Violation 15 Precedence cutoff in effect
4	Source Quench	
5	Redirect	0 Redirect Datagram for the Network (or subnet) 1 Redirect Datagram for the Host 2 Redirect Datagram for the Type of Service and Network 3 Redirect Datagram for the Type of Service and Host
6	Alternate Host Address	
7	Unassigned	
8	Echo	
9	Router Advertisement	
10	Router Selection	
11	Time Exceeded	0 Time to Live exceeded in Transit 1 Fragment Reassembly Time Exceeded
12	Parameter Problem	0 Pointer indicates the error 1 Missing a Required Option 2 Bad Length

Table 2: ICMP Types and Codes (continued)

Type Number	Type Name	Code
13	Timestamp	
14	Timestamp Reply	
15	Information Request	
16	Information Reply	
17	Address Mask Request	
18	Address Mask Reply	
19	REserved (for Security)	
20 - 29	Reserved (for Robustness Experiment)	
30	Traceroute	
31	Datagram Conversion Error	
32	Mobile Host Redirect	
33	IPv6 Where-Are-You	
34	IPv6 I-Am-Here	
35	Mobile Registration	
36	Mobile Registration Reply	
37	Domain Name Request	
38	Domain Name Reply	
39	SKIP	
40	Photuris	
41 - 255	Reserved	

ICMPv6

Internet Control Message Protocol version 6 (ICMPv6) is the new implementation of the Internet Control Message Protocol (ICMP) that is part of Internet Protocol version 6 (IPv6). The ICMPv6 protocol is defined in [RFC 4443](#).

ICMPv6 is a multipurpose protocol. It performs such things as:

- error reporting in packet processing
- diagnostic functions
- Neighbor Discovery process
- IPv6 multicast membership reporting

It also designed as a framework to use extensions for use with future implementations and changes.

Examples of extensions that have already been written for ICMPv6:

- Neighbor Discovery Protocol (NDP) - a node discovery protocol in IPv6 which replaces and enhances functions of ARP.
- Secure Neighbor Discovery Protocol (SEND) - an extension of NDP with extra security.
- Multicast Router Discovery (MRD) - allows discovery of multicast routers.

ICMPv6 messages use IPv6 packets for transportation and can include IPv6 extension headers. ICMPv6 includes some of the functionality that in IPv4 was distributed among protocols such as ICMPv4, ARP (Address Resolution Protocol), and IGMP (Internet Group Membership Protocol version 3).

ICMPv6 has simplified the communication process by eliminating obsolete messages.

ICMPv6 messages are subdivided into two classes: error messages and information messages.

Error Messages are divided into four categories:

1. Destination Unreachable
2. Time Exceeded
3. Packet Too Big
4. Parameter Problems

Information messages are divided into three groups:

1. Diagnostic messages
2. Neighbor Discovery messages
3. Messages for the management of multicast groups.

ICMPv6 Types and Codes

ICMPv6 has a number of messages that are identified by the “Type” field. Some of these types have assigned “Code” fields as well. The table below shows the different types of ICMP Types with their associated codes if there are any.

Type codes 0 – 127 are error messages and type codes 128 – 255 are for information messages.

Table 3: ICMPv6 Types and Codes

Type Number	Type Name	Code
0	Reserved	0 - no route to destination 1 - communication with destination administratively prohibited 2 - beyond scope of source address 3 - address unreachable 4 - port unreachable 5 - source address failed ingress/egress policy 6 - reject route to destination 7 - Error in Source Routing Header
1	Destination Unreachable	
2	Packet Too Big	
3	Time Exceeded	0 - hop limit exceeded in transit 1 - fragment reassembly time exceeded
4	Parameter Problem	0 - erroneous header field encountered 1 - unrecognized Next Header type encountered 2 - unrecognized IPv6 option encountered
100	Private Experimentation	
101	Private Experimentation	
102 - 126	Unassigned	
127	Reserved for expansion if ICMPv6 error messages	
128	Echo Request	
129	Echo Replay	
130	Multicast Listener Query	
131	Multicast Listener Report	
132	Multicast Listener Done	
133	Router Solicitation	
134	Router Advertisement	

Table 3: ICMPv6 Types and Codes (continued)

Type Number	Type Name	Code
135	Neighbor Solicitation	
136	Neighbor Advertisement	
137	Redirect Message	
138	Router Renumbering	0 - Router Renumbering Command 1 - Router Renumbering Result 255 - Sequence Number Reset
139	ICMP Node Information Query	0 - The Data field contains an IPv6 address which is the Subject of this Query. 1 - The Data field contains a name which is the Subject of this Query, or is empty, as in the case of a NOOP. 2 - The Data field contains an IPv4 address which is the Subject of this Query. 140 ICMP Node Information Response 0 - A successful reply. The Reply Data field may or may not be empty. 1 - The Responder refuses to supply the answer. The Reply Data field will be empty. 2 - The Qtype of the Query is unknown to the Responder. The Reply Data field will be empty.
140	ICMP Node Information Response	0 - A successful reply. The Reply Data field may or may not be empty. 1 - The Responder refuses to supply the answer. The Reply Data field will be empty. 2 - The Qtype of the Query is unknown to the Responder. The Reply Data field will be empty.
141	Inverse Neighbor Discovery Solicitation Message	
142	Inverse Neighbor Discovery Advertisement Message	
143	Version 2 Multicast Listener Report	
144	Home Agent Address Discovery Request Message	

Table 3: ICMPv6 Types and Codes (continued)

Type Number	Type Name	Code
145	Home Agent Address Discovery Reply Message	
146	Mobile Prefix Solicitation	
147	Mobile Prefix Advertisement	
148	Certification Path Solicitation Message	
149	Certification Path Advertisement Message	
150	ICMP messages utilized by experimental mobility protocols such as Seamoby	
151	Multicast Router Advertisement	
152	Multicast Router Solicitation	
153	Multicast Router Termination	
154	FMIPv6 Messages	
155	RPL Control Message	
156	ILNIPv6 Locator Update Message	
157	Duplicate Address Request	
158	Duplicate Address Confirmation	
159 – 199	Unassigned	
200	Private experimentation	
201	Private experimentation	
255	Reserved for expansion of ICMPv6 informational messages	

IP

Internet Protocol (IP) is the primary part of the Network Layer of the OSI Model that is responsible for routing traffic across network boundaries. It is the protocol that is responsible for addressing. IPv4 is probably the version that most people are familiar with and it has been around since 1974. IPv6 is its current successor and due to a shortage of available IPv4 addresses compared to the explosive increase in the number of devices that use IP addresses, IPv6 is rapidly increasing in use.

When IP is chosen as the protocol type the available option to further specify the protocol is the protocol number. This is used to narrow down which protocol within the Internet Protocol Suite and provide a more granular control.

Protocol Number

IP is responsible for more than the address that it is most commonly associated with and there are a number of associated protocols that make up the Network Layer. While there are not 256 of them, the field that identifies them is a numeric value between 0 and 256.

In the Internet Protocol version 4 (IPv4) [RFC791] there is a field called "Protocol" to identify the next level protocol. This is an 8 bit field. In Internet Protocol version 6 (IPv6) [RFC2460], this field is called the "Next Header" field.

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
0	HOPOPT	IPv6 Hop-by-Hop Option
1	ICMP	Internet Control Message Protocol
2	IGMP	Internet Group Management
3	GGP	Gateway-to-Gateway
4	IPv4	IPv4 encapsulation Protocol
5	ST	Stream
6	TCP	Transmission Control Protocol
7	CBT	CBT
8	EGP	Exterior Gateway Protocol
9	IGP	Any private interior gateway (used by Cisco for their IGRP)
10	BBN-RCC-MON	BBN RCC Monitoring
11	NVP-II	Network Voice Protocol
12	PUP	PUP
13	ARGUS	ARGUS
14	EMCON	EMCON
15	XNET	Cross Net Debugger
16	CHAOS	Chaos

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
17	UDP	User Datagram Protocol
18	MUX	Multiplexing
19	DCN-MEAS	DCN Measurement Subsystems
20	HMP	Host Monitoring
21	PRM	Packet Radio Measurement
22	XNS-IDP	XEROX NS IDP
23	TRUNK-1	Trunk-1
24	TRUNK-2	Trunk-2
25	LEAF-1	Leaf-1
26	LEAF-2	Leaf-2
27	RDP	Reliable Data Protocol
28	IRTP	Internet Reliable Transaction
29	ISO-TP4	ISO Transport Protocol Class 4
30	NETBLT	Bulk Data Transfer Protocol
31	MFE-NSP	MFE Network Services Protocol
32	MERIT-INP	MERIT Internodal Protocol
33	DCCP	Datagram Congestion Control Protocol
34	3PC	Third Party Connect Protocol
35	IDPR	Inter-Domain Policy Routing Protocol
36	XTP	XTP
37	DDP	Datagram Delivery Protocol
38	IDPR-CMTP	IDPR Control Message Transport Proto
39	TP++	TP++ Transport Protocol
40	IL	IL Transport Protocol
41	IPv6	IPv6 encapsulation
42	IPv6	SDRPSource Demand Routing Protocol
43	IPv6-Route	Routing Header for IPv6
44	IPv6-Frag	Fragment Header for IPv6
45	IDRP	Inter-Domain Routing Protocol

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
46	RSVP	Reservation Protocol
47	GRE	General Routing Encapsulation
48	DSR	Dynamic Source Routing Protocol
49	BNA	BNA
50	ESP	Encap Security Payload
51	AH	Authentication Header
52	I-NLSP	Integrated Net Layer Security TUBA
53	SWIPE	IP with Encryption
54	NARP	NBMA Address Resolution Protocol
55	MOBILE	IP Mobility
56	TLSP	Transport Layer Security Protocol using Kryptonnet key management
57	SKIP	SKIP
58	IPv6-ICMP	ICMP for IPv6
59	IPv6-NoNxt	No Next Header for IPv6
60	IPv6-Opts	Destination Options for IPv6
61		any host internal protocol
62	CFTP	CFTP
63		any local network
64	SAT-EXPAK	SATNET and Backroom EXPAK
65	KRYPTOLAN	Kryptolan
66	RVD	MIT Remote Virtual Disk Protocol
67	IPPC	Internet Pluribus Packet Core
68		any distributed file system
69	SAT-MON	SATNET Monitoring
70	VISA	VISA Protocol
71	IPCV	Internet Packet Core Utility
72	CPNX	Computer Protocol Network Executive
73	CPHB	Computer Protocol Heart Beat

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
74	WSN	Wang Span Network
75	PVP	Packet Video Protocol
76	BR-SAT-MON	Backroom SATNET Monitoring
77	SUN-ND	SUN ND PROTOCOL-Temporary
78	WB-MON	WIDEBAND Monitoring
79	WB-EXPAK	WIDEBAND EXPAK
80	ISO-IP	ISO Internet Protocol
81	VMTP	VMTP
82	SECURE-VMTP	SECURE-VMTP
83	VINES	VINES
84	TTP	TTP
84	IPTM	Protocol Internet Protocol Traffic
85	NSFNET-IGP	NSFNET-IGP
86	DGP	Dissimilar Gateway Protocol
87	TCF	TCF
88	EIGRP	EIGRP
89	OSPFIGP	OSPFIGP
90	Sprite-RPC	Sprite RPC Protocol
91	LARP	Locus Address Resolution Protocol
92	MTP	Multicast Transport Protocol
93	AX.25	AX.25 Frames
94	IPIP	IP-within-IP Encapsulation Protocol
95	MICP	Mobile Internetworking Control Pro.
96	SCC-SP	Semaphore Communications Sec. Pro.
97	ETHERIP	Ethernet-within-IP Encapsulation
98	ENCAP	Encapsulation Header
99		any private encryption scheme
100	GMTP	GMTP
101	IFMP	Ipsilon Flow Management Protocol

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
102	PNNI	PNNI over IP
103	PIM	Protocol Independent Multicast
104	ARIS	ARIS
105	SCPS	SCPS
106	QNX	QNX
107	A/N	Active Networks
108	IPComp	IP Payload Compression Protocol
109	SNP	Sitara Networks Protocol
110	Compaq-Peer	Compaq Peer Protocol
111	IPX-in-IP	IPX in IP
112	VRRP	Virtual Router Redundancy Protocol
113	PGM	PGM Reliable Transport Protocol
114		any 0-hop protocol
115	L2TP	Layer Two Tunneling Protocol
116	DDX	D-II Data Exchange (DDX)
117	IATP	Interactive Agent Transfer Protocol
118	STP	Schedule Transfer Protocol
119	SRP	SpectraLink Radio Protocol
120	UTI	UTI
121	SMP	Simple Message Protocol
122	SM	SM
123	PTP	Performance Transparency Protocol
124	ISIS over IPv4	
125	FIRE	
126	CRTP	Combat Radio Transport Protocol
127	CRUDP	Combat Radio User Datagram
128	SSCOPMCE	
129	IPLT	
130	SPS	Secure Packet Shield

Table 4: Protocol Numbers

#	Protocol	Protocol's Full Name
131	PIPE	Private IP Encapsulation within IP
132	SCTP	Stream Control Transmission Protocol
133	FC	Fibre Channel
134	RSVP-E2E-IGNORE	
135	Mobility Header	
136	UDPLite	
137	MPLS-in-IP	
138	manet	
139	HIP	
140	Shim6	
141	WESP	
142	ROHC	
143 – 252	Unassigned	Unassigned
253		Use for experimentation and testing
254		Use for experimentation and testing
255	Reserved	

Further information can be found by researching [RFC 5237](#).

Service Groups

Just like some of the other firewall components, services can also be bundled into groups for ease of administration.

Example Scenario: Using FortiGate services to support Audio/Visual Conferencing



The feature, and the transmitting of data for the purpose of, Tele-conferencing or Audio/Visual Conferencing is covered by a number of standards:

- The IETF standard known as the Binary Floor Control Protocol (BFCP).
- RFC 4582, for SIP-based video devices
- The ITU standard H.239 (for H.323-based video devices)

While these standards have been set up by various authoritative bodies and can take place on different layers of the OSI model, they share common requirements that are addressed by the FortiGate firewall's ability to manage the traffic and the protocols involved. This means that the same ability that make the device RFC 4582 compliant makes it compliant with H.239 as well.

To demonstrate how services and service groups are used we show the setup of a firewall that will need to support the connectivity of a video conferencing unit. The FortiGate does not manipulate or change the content of the traffic but it does allow for the traffic to pass through the device. In this case it allow for only the needed traffic to pass through the device so as to allow the functionality of Audio Visual Conference call but not to allow other traffic through.

The theoretical location for this scenario is a hospital that hosts conferences and lectures from doctors from all over the world, sometimes from multiple locations, using video conferencing technology such as a Polycom Video Conference system. There is a special room set up with dedicated Ethernet connectivity to the Internet. A hospital has a lot of sensitive information going over its network so the setup has to be secure to prevent any chance of penetration.

The approach is fairly simple. The conference room has a dedicated port on the FortiGate (port #7) and its own LAN. We will assume that the interface has already been configured properly. Video conference traffic can come from the Internet to the Polycom in that room and traffic can get out to the Internet, but traffic going to other areas of the hospital network have to go through the FortiGate and traffic going from the Video Conference LAN is thoroughly filtered.

To give an idea of how extensive this can be, we will use an extreme case and include just about all of the services that could be commonly used in one of these setups. The protocols listed here may differ from other setups. It will depend on which features are being used and which equipment is within the network. Always check the documentation that comes with the set up before opening ports into your network.

VIP

In this particular case there is an IP address set aside for the conferencing system so a separate VIP is not needed for every port. One Virtual IP will be created for the system and then only the approved of protocols will be allows through the firewall.

Name	Vid-Conf_Room216
External Interface	wan1
External IP Address/Range	256.87.212.51 – 256.87.212.51
Mapped IP Address/Range	192.168.7.25 – 192.168.7.25
Port Forwarding	not selected

Creating an address for the subnet

In the same way that the VIP was created to identify and direct incoming traffic an address should be created to identify the addresses of computer that will be in the Conference room. This included computers on the LAN as well as the Teleconferencing equipment.

Go to *Firewall Objects* -> *Address* -> *Addresses*

Create New

Fill out the fields with the following information:

Category	Address
Name	Port7_subnet
Type	Subnet
Subnet/IP Range	192.168.7.0/255.255.255.0
Interface	port7
Show in address list	checked

Configuring the services

Services already created:

The following are standard services that have already been created by default:

HTTP	TCP 80
SNMP	TCP 161-162/UDP 161-162
LDAP	TCP 389
HTTPS	TCP 443
SYSLOG	UDP 514

Existing Services to be edited:

There are a few services that have already been created for you, but they need to be expanded to accommodate the list of protocols listed for this scenario.

The default h323 contains:

- TCP 1503
- UDP 1719
- TCP 1720

We need to add:

- TCP1719

The default SIP contains:

- UDP 5060

We need to add:

- TCP 5060

To edit an existing service:

- H323

Go to *Firewall Objects -> Service -> Services*

Scroll down to the section: *VoIP, Messaging & Other Applications*

Select *H323*

Select *Edit*

In the Protocol section add the additional protocol:

Protocol Type	TCP
Destination port /Low	1719

Select *OK* to save

- SIP

Select *SIP*

Select *Edit*

In the Protocol section add the additional protocol:

Protocol Type	TCP
Destination port / Low:	5060

Custom Services that need to be created:

There are a number of possible services that may need to be added from scratch rather than editing existing ones. While it is possible to create a single custom service that contains all of the open ports needed, it make more sense to make this modular in case only a small subset of the service needs to be added to another policy.

- Polycom API

Go to *Firewall Objects -> Service -> Services*

Create New

Fill in the fields of the new service with the following information:

Name	Polycom API
Service Type	Firewall
Category	VoIP, Messaging & Other
Protocol Type	TCP/UDP/SCTP
Protocol	TCP/UDP/SCTP
Protocol	TCP

Destination Port - Low: 24

Destination Port - High: <leave blank>

Select *OK*

- Polycom Endpoints

Go to *Firewall Objects* -> *Service* -> *Services*

Create New

Fill in the fields of the new service with the following information:

Name Polycom Endpoints

Service Type Firewall

Category VoIP, Messaging & Other

Protocol Type TCP/UDP/SCTP

Protocol TCP

Destination - Low: 3230

Destination - High: 3253

Select *OK*

Other Services to add in the same way:

Table 5:

	Category	Protocol & Port #
LDAP secure communications	Authentication	TCP 636
Win 2000 ILS Registration	Network Services	TCP 1002
Gatekeeper discovery	VoIP, Messaging & Other Applications	TCP 1718
Audio Call Control	VoIP, Messaging & Other Applications	TCP 1731
Polycom proprietary Global directory data	VoIP, Messaging & Other Applications	TCP 3601
Polycom People+Content	VoIP, Messaging & Other Applications	TCP 5001
HTTP Server Push	Web Access	TCP 8080

Creating the Service Group

Go to *Firewall Objects* -> *Service* -> *Groups*

Create New

Build the Service group by filling in the fields with the following information

Group Name	A-V_Conference
Type	Firewall
Members (click in the drop down menu to add the following services)	<ul style="list-style-type: none">•HTTP•SNMP•LDAP•HTTPS•SYSLOG•Polycom API•Polycom Endpoints•LDAP secure communications•Win 2000 ILS Registration•Gatekeeper discovery•Audio Call Control•Polycom proprietary Global directory data•Polycom People+Content•HTTP Server Push

Creating the IPS Security Profile

This is by no means the only way to set up this IPS filter, but it is the way that the fictional System Administrator wants it set up. Yours may be different.

Go to *Security Profiles -> Intrusion Protection -> IPS Sensors*.

Create a new sensor

Name	A-V_Conference-incoming
-------------	-------------------------

Select OK

In the newly created sensor, create a new IPS filter.

Sensor Type	Filter Based
Filter Options	Advanced
Severity	<ul style="list-style-type: none">• Critical• High• Medium• Low
Target	<ul style="list-style-type: none">• Server
OS	<ul style="list-style-type: none">• Windows
Application	<ul style="list-style-type: none">• IIS• other

Protocol Use the [Show more...] option	<ul style="list-style-type: none"> • HTTP • LDAP • SIP • SSL • H323
--	--

Packet logging	<ul style="list-style-type: none"> • enabled
-----------------------	---

Based on these filters there should be somewhere in the neighborhood of 750 signatures that the FortiGate will run traffic against in the IPS engine.

Policies

Incoming Policy

A policy has to be made to allow the traffic to come in from the Internet to connect to the Tele-conferencing server equipment.

Go to *Policy* -> *Policy* -> *Policy*.

Create New

Fill out the fields with the following information:

Policy Type	Firewall
Policy Subtype	Address
Incoming Interface	wan1
Source Address	all
Outgoing Interface	port7
Destination Address	Vid-Conf_Room216
Schedule	always
Service	A-V_Conference
Action	ACCEPT
Enable NAT	<not enabled>
Logging Options	Logging is a good idea but how much will depend on storage capabilities.
Security Profiles	Turn on IPS and choose "A-V_Conference-incoming"
Traffic Shaping, Web cache, WAN Optimization, Disclaimer:	The use of these features will depend on your network environment and should be decided by the network architect, as the decision will largely be based on network bandwidth, usage and importance of Video conferencing compared to other traffic.

Select *OK*.

The policy will then need to be put in the correct position in the sequence of the policies. Because it is a rather focused policy it should be acceptable to place it near the top of the policy order sequence.

Outgoing Policy

A policy has to be made to allow the traffic to leave from the subnet in the conference room to the Internet, not only for the traffic for the Tele-conferencing equipment but for normal traffic of users on the Internet such as web research and email. The traffic is outgoing so there is less of a need for an Intrusion Protection System filter, but check with the network architect in case there is a need for using one of the other security profiles.

Go to *Policy* -> *Policy* -> *Policy*.

Create New

Fill out the fields with the following information:

Policy Type	Firewall
Policy Subtype	Address
Incoming Interface	port7
Source Address	Port7_subnet
Outgoing Interface	wan1
Destination Address	all
Schedule	always
Service	any
Action	ACCEPT
Enable NAT	enabled Use Destination Interface Address
Logging Options	Logging is a good idea but how much will depend on storage capabilities.
Security Profiles	<see above>
Traffic Shaping, Web cache, WAN Optimization, Disclaimer:	The use of these features will depend on your network environment and should be decided by the network architect, as the decision will largely be based on network bandwidth, usage and importance of Video conferencing compared to other traffic.

Select *OK*.

The policy will then need to be put in the correct position in the sequence of the policies.

Firewall schedules

Firewall schedules control when policies are in effect. When you add a security policy on a FortiGate unit you need to set a schedule to determine the time frame in which that the policy

will be functioning. While it is not set by default, the normal schedule would be always. This would mean that the policy that has been created is always function and always policing the traffic going through the FortiGate.

The time component of the schedule is based on a 24 hour clock notation or military time as some people would say.

There are two types of schedules: One-time schedules and recurring schedules.

One-Time schedules are in effect only once for the period of time specified in the schedule. This can be useful for testing to limit how long a policy will be in effect in case it is not removed, or it can be used for isolated events such as a conference where you will only need a temporary infrastructure change for a few days.

The time frame for a One-time schedule is configured by using a start time which includes, Year | Month | Day | Hour | Minute and a Stop time which includes the same variables. So while the frequency of the schedule is only once it can last anywhere from 1 minute to multiple years.

Recurring schedules are in effect repeatedly at specified times of specified days of the week. The Recurring schedule is based on a repeating cycle of the days of the week as opposed to every x days or days of the month. This means that you can configure the schedule to be in effect on Tuesday, Thursday, and Saturday but not every 2 days or on odd numbered days of the month.

If a recurring schedule has a stop time that is earlier than the start time, the schedule will take effect at the start time but end at the stop time on the next day. You can use this technique to create recurring schedules that run from one day to the next.

Example

You want to schedule the use of Skype to only between noon (12:00) and 1 p.m. (13:00).

You could create a schedule that allows Skype traffic:

- Starting at Hour:12 and Minute: 00
- Stopping at Hour:13 and Minute: 00
- Set for days of the week: Sunday | Monday |Tuesday |Wednesday | Thursday | Friday | Saturday

Or you could have a schedule that blocks Skype traffic:

- Starting at Hour:13 and Minute: 00 (and goes to the next day)
- Stopping at Hour:12 and Minute: 00
- Set for days of the week: Sunday | Monday |Tuesday |Wednesday | Thursday | Friday | Saturday

Either way is effective for the task but other factors may make one method work better than another in certain situations of it could be just a preference in approach.

Schedule Groups

You can organize multiple firewall schedules into a schedule group to simplify your security policy list. The schedule parameter in the policy configuration does not allow for the entering of multiple schedules into a single policy so if you have a combination of time frames that you want to schedule the policy for then the best approach, rather than making multiple policies is to use a schedule group.

Example

Your Internet policy allows employees to visit Social Media sites from company computers but not during what is considered working hours. The offices are open a few hours before working

hours and the doors are not locked until a few hours after official closing so work hours are from 9 to 5 with a lunch break from Noon to 1:00 p.m.

Your approach is to block the traffic between 9 and noon and between 1:00 p.m. and 5:00 p.m. This means you will need two schedules for a single policy and the schedule group handles this for you.

Schedule groups can contain both recurring and one-time schedules. Schedule groups cannot contain other schedule groups.

Schedule Expiration

The schedule in a security policy enables certain aspects of network traffic to occur for a specific length of time. What it does not do however, is police that time. That is, the policy is active for a given time frame, and as long as the session is open, traffic can continue to flow.

For example, in an office environment, Skype use is allowed between noon and 1pm. During that hour, any Skype traffic continues. As long as that session is open, after the 1pm end time, the Skype conversations can continue, yet new sessions will be blocked. Ideally, the Skype session should close at 1pm.

Using a CLI command you can set the schedule to terminate all sessions when the end time of the schedule is reached. Within the config firewall command enter the command:

```
set schedule-timeout enable
```

By default, this is set to `disable`.

Security profiles

Where security policies provide the instructions to the FortiGate unit for controlling what traffic is allowed through the device, the Security profiles provide the screening that filters the content coming and going on the network. Security profiles enable you to instruct the FortiGate unit about what to look for in the traffic that you don't want, or want to monitor, as it passes through the device.

A security profile is a group of options and filters that you can apply to one or more firewall policies. Security profiles can be used by more than one security policy. You can configure sets of security profiles for the traffic types handled by a set of security policies that require identical protection levels and types, rather than repeatedly configuring those same security profile settings for each individual security policy.

For example, while traffic between trusted and untrusted networks might need strict antivirus protection, traffic between trusted internal addresses might need moderate antivirus protection. To provide the different levels of protection, you might configure two separate profiles: one for traffic between trusted networks, and one for traffic between trusted and untrusted networks.

Security profiles are available for various unwanted traffic and network threats. Each are configured separately and can be used in different groupings as needed. You configure security profiles in the Security Profiles menu and applied when creating a security policy by selecting the security profile type.

There is a separate handbook for the topic of the Security Profiles, but because the Security Profiles are applied through the Firewall policies it makes sense to have at least a basic idea of what the security profile do and how they integrate into the FortiGate's firewall policies. The following is a listing and a brief description of what the security profiles offer by way of functionality and how they can be configured into the firewall policies.

AntiVirus

Antivirus is used as a catch all term to describe the technology for protection against the transmission of malicious computer code sometimes referred to as malware. As anyone who has listened to the media has heard that the Internet can be a dangerous place filled with malware of various flavours. Currently, the malware that is most common in the Internet, in descending order, is Trojan horses, viruses, worms, adware, back door exploits, spyware and other variations. In recent years, not only has the volume of malicious software become greater than would have been believed when it first appeared but the level of sophistication has risen as well.

The Antivirus Filter works by inspecting the traffic that is about to be transmitted through the FortiGate. To increase the efficiency of effort it only inspects the traffic being transmitted via the protocols that it has been configured to check. Before the data moves across the FortiGate firewall from one interface to another it is checked for attributes or signatures that have been known to be associated with malware. If malware is detected, it is removed.

Web Filtering

Malicious code is not the only thing to be wary of on the Internet. There is also the actual content. While the content will not damage or steal information from your computer there is still a number of reasons that would require protection from it.

In a setting where there are children or other sensitive people using the access provided by a connected computer there is a need to make sure that images or information that is not appropriate is not inadvertently displayed to them. Even if there is supervision, in the time it takes to recognize something that is inappropriate and then properly react can expose those we wish to protect. It is more efficient to make sure that the content cannot reach the screen in the first place.

In an organizational setting, there is still the expectation that organization will do what it can to prevent inappropriate content from getting onto the computer screens and thus provoking an Human Resources incident. There is also the potential loss of productivity that can take place if people have unfiltered access to the Internet. Some organizations prefer to limit the amount of distractions available to tempt their workers away from their duties.

The Web filter works primarily by looking at the destination location request for a HTTP(S) request made by the sending computer. If the URL is on a list that you have configured to list unwanted sites, the connection will be disallowed. If the site is part of a category of sites that you have configured to deny connections to the session will also be denied. You can also configure the content filter to check for specific key strings of data on the actual web site and if any of those strings of data appear the connection will not be allowed.

Application Control

Application Control is designed to allow you to determine what applications are operating on your network and to also filter the use of these applications as required. Application control is also for outgoing traffic to prevent the use of applications that are against an organization's policy from crossing the network gateway to other networks. An example of this would be the use of proxy servers to circumvent the restrictions put in place using the Web Filtering.

Intrusion Protection (IPS)

Intrusion Prevention System is almost self explanatory. In the same way that there is malware out on the Internet that the network needs to be protected from there are also people out there that take a more targeted approach to malicious cyber activity. No operating system is perfect and new vulnerabilities are being discovered all of the time. An intrusion prevention system is designed to look for activity or behavior that is consistent with attacks against your network.

When attack like behavior is detected it can either be dropped or just monitored depending on the approach that you would like to take.

As new vulnerabilities are discovered they can be added to the IPS database so that the protection is current.

Email Filtering

Spam or unsolicited bulk email is said to account for approximately 90% of the email traffic on the Internet. Sorting through it is both time consuming and frustrating. By putting an email filter on policies that handle email traffic, the amount of spam that users have to deal with can be greatly reduced.

Data Leak Prevention (DLP)

Data Leak Prevention is used to prevent sensitive information from leaving your network. When people think of security in the cyber-world one of the most common images is that of a hacker penetrating your network and making off with your sensitive information, but the other way that you can lose sensitive data is if someone already on the inside of your network sends it out. This does not have to be an act of industrial espionage. It can just be a case of not knowing the policies of the organization or a lack of knowledge of security or laws concerning privacy.

For instance, a company may have a policy that they will not reveal anyone's Social Security number, but an employee emails a number of documents to another company that included a lengthy document that has a Social Security number buried deep within it. There is not malicious intent but if the information got out there could be repercussions.

If an organization has any information in a digital format that it cannot afford for financial or legal reasons, to leave its network, it makes sense to have Data Leak Prevention in place as an additional layer of protection.

VoIP

Voice over IP is essentially the protocols for transmitting voice or other multimedia communications over Internet Protocol networks such as the Internet. The Security Profiles VoIP options apply the SIP Application Level Gateway (ALG) to support SIP through the FortiGate unit. The SIP ALG can also be used to protect networks from SIP-based attacks.

ICAP

Internet Content Adaptation Protocol (ICAP) off loads HTTP traffic to another location for specialized processing. The purpose of this module when triggered is to send the incoming HTTP traffic over to a remote server to be processed thus taking some of the strain off of the resources of the FortiGate unit. The reasons for the specialized process could be anything from more sophisticated Antivirus to manipulation of the HTTP headers and URLs.

EndPoint Control

EndPoint Control makes sure that certain standards are kept. When a computer on the Internet becomes connected to the FortiGate unit by VPN that computer is now part of the same network and there for needs to be subject to the same levels of protection, not only to protect the computer but the network. In the EndPoint Control section you can set the minimum standards for thins like AntiVirus software and VPN software.

Proxy Option Components

Any time a security profile that requires the use of a proxy is enabled the Proxy Options field will be displayed. Certain inspections defined in security profiles require that the traffic be held in proxy while the inspection is carried out and so the Proxy Options are there to define the parameters of how the traffic will be processed and to what level the traffic will be processed. In the same way that there can be multiple security profiles of a single type there can also be a number of unique Proxy Option profiles so that as the requirements for a policy differ from one policy to the next you can also configure a different Proxy Option profile for each individual policy or you can use one profile repeatedly.

The Proxy Options refer to the handling of the following protocols:

- HTTP
- HTTPS
- FTP
- FTPS
- IMAP
- IMAPS
- POP3
- POP3S
- SMTP
- SMTPS
- DNS
- IM
- NNTP

The configuration for each of these protocols is handled separately.

It should also be noted that these configuration apply to only the Security Profiles Proxy-based processes and not the Flow-based processes.

The use of different proxy profiles and profile options

Just like other components of the FortiGate, there is the option for different Proxy Option profiles so that you can be very granular in your control of the workings of the FortiGate. In the case of the Proxy Option profiles the thing that you will want to focus on is the matching up of the correct profile to a firewall policy that is using the appropriate protocols. If you are creating a Proxy Option profile that is designed for policies that control SMTP traffic into your network you only want to configure the settings that apply to SMTP. You do not need or want to configure the HTTP components.

Oversized File Log

This setting is for those that would like to log the occurrence of oversized files being processed. It does not change how they are processed it only enables the FortiGate unit to log that they were either blocked or allowed through. A common practice is to allow larger files through without antivirus processing. This allows you to get an idea of how often this happens and decide on whether or not to alter the settings relating to the treatment of oversized files.

The setting of the threshold for what is considered to be an oversized file is located in the Oversized File / Email Threshold that is found in some of the protocol options for the Proxy Options.

Invalid Certificate Log

This setting enables the logging of occurrences that have occurred in policies governed by the proxy option profile that this setting is enabled in. As stated elsewhere in this document there can be a number of reasons that a web site may have a certificate that registers as being invalid. Because some administrators decide to allow users to access these sites it makes sense to keep track of when it happens. This does not prevent the accessing of web sites with an invalid certificate. It just allows for logging when it happens.

Port

While each of the protocols listed has a default TCP port that is commonly used, the level of granularity of control on the FortiGate firewall allows that the port used by the protocols can be individually modified in each separate Profile.

Comfort Clients

When proxy-based antivirus scanning is enabled, the FortiGate unit buffers files as they are downloaded. Once the entire file is captured, the FortiGate unit begins scanning the file. During the buffering and scanning procedure, the user must wait. After the scan is completed, if no infection is found, the file is sent to the next step in the process flow. If the file is a large one this part of the process can take some time. In some cases enough time that some users may get impatient and cancel the download.

The comfort client feature to mitigates this potential issue by feeding a trickle of data while waiting for the scan to complete so as to let the user know that processing is taking place and that there hasn't been a failure in the transmission. This slow transfer rate continues until the antivirus scan is complete. Once the file has been successfully scanned without any indication of viruses the transfer will proceed at full speed.

If there is evidence of an infection the FortiGate unit caches the URL and drops the connection. The client does not receive any notification of what happened because the download to the client had already started. Instead, the download stops and the user is left with a partially downloaded file. If the user tries to download the same file again within a short period of time, the cached URL is matched and the download is blocked. The client receives the Infection cache message replacement message as a notification that the download has been blocked. The number of URLs in the cache is limited by the size of the cache.

Client comforting is available for HTTP and FTP traffic. If your FortiGate unit supports SSL content scanning and inspection, you can also configure client comforting for HTTPS and FTPS traffic.



Buffering the entire file allows the FortiGate unit to eliminate the danger of missing an infection due to fragmentation because the file is reassembled before examination. Client comforting can send unscanned and therefore potentially infected content to the client. You should only enable client comforting if you are prepared to accept this risk. Keeping the client comforting interval high and the amount low will reduce the amount of potentially infected data that is downloaded.

Oversized File/Email Threshold

This is another feature that is related to antivirus scanning. The FortiGate unit has a finite amount of resources that can be used to buffer and scan a file. If a large file such as an ISO image or video file was to be downloaded this could not only overwhelm the memory of the FortiGate, especially if there were other large files being downloaded at the same time, but could exceed it as well. For this reason, how to treat large files needs to be addressed.

A threshold is assigned to determine what should be considered an oversized file or email. This can be set at any size from 1 MB to 50 MB. Any file or email over this threshold will not be

processed by the Antivirus Security Profiles. Once a file is determined to be oversized it must be then determined whether to allow it or to block it.

These settings are not a technical decision but a policy one that will depend on your comfort level with letting files into your network. As there often is, there is a compromise between convenience or ease of use and security. If you want to go for a high peace of mind level you can configure the firewall to block oversized files and thus no files would be coming into the network that have not been scanned. If you are looking for optimizing the memory of the FortiGate unit and making sure that everybody is getting the files they want, you can lower the threshold and allow files that are over the threshold.



It should be noted that in terms of probability that malware is more likely to be found in smaller files than in larger files. A number of administrators take this into account when they lower the default threshold so as to lessen the impact on memory if they see the FortiGate unit going into conserve mode on a regular basis.

Chunked Bypass

The HTTP section allows the enabling of “Chunked Bypass”. This refers to the mechanism in version 1.1 of HTTP that allows a web server to start sending chunks of dynamically generated output in response to a request before actually knowing the actual size of the content. Where dynamically generated content is concerned this means that there is a faster initial response to HTTP requests. From a security stand point it means that the content will not be held in the proxy as an entire file before proceeding.

Allow Fragmented Messages

The specifications of RFC 2046 allow for the breaking up of emails and sending the fragments in parallel to be rebuilt and read at the other end by the mail server. It was originally designed to increase the performance over slower connections where larger email messages were involved. It will depend on your mail configuration if this is even possible for your network but outside of Microsoft Outlook and Outlook Express, not many email clients are set up to break up messages like this. The drawback of allowing this feature is that if malware is broken up between multiple fragments of the message the risk is run that it will not be detected by some antivirus configurations because the code may not all be present at the same time to identify.

Append Email Signature

The Append Email Signature is used when an organization would like to ensure that over and above our in this case underneath the existing personal signatures of the sender, all of the emails going out of their network have the appropriate “boilerplate”, for lack of a better term. These appended emails do not replace existing signatures. They are as the feature states, appended to the email.

Examples could include things like:

- Without prior approval the email should not be forwarded.
- Please be environmentally friendly and don't print out emails
- For questions regarding the purchasing of our products please call...

It can be anything that the organization would like as long as it is in text format. The use of this feature usually works best in an environment where there is some standardization of what goes into the personal signatures of the senders so that there is no duplication or contradiction of information in the signatures.

SSL/SSH Inspection

While the profile configuration for this is not found in the Security Profiles section but in the Policy Section, it is set in the policy along with the security profiles. This sort of analysis is some times referred to as deep scanning.

Deep Inspection works along the following lines. If your FortiGate unit has the correct chipset it will be able to scan HTTPS traffic in the same way that HTTP traffic can be scanned. The FortiGate firewall will essentially receive the traffic on behalf of the client and open up the encrypted traffic. Once it is finished it re-encrypts the traffic and sends it on to its intended recipient. It is very similar to a man-in-the-middle attack. By enabling this feature, it allows the FortiGate firewall to filter on traffic that is using the HTTPS protocol.

Sometimes the regular web filter can be circumvented by using https:// instead of http:// in the URL and this would prevent that circumvention. However, because when the encrypted traffic is decrypted it has to be re-encrypted with the FortiGate's certificate rather than the original certificate it can cause errors because the name on the certificate does not match the name on the web site.

At one point deep inspection was something that was either turned on or off. Now individual deep inspection profiles can be created depending on the requirements of the policy. Depending on the Inspection Profile, you can:

- Configure which CA certificate will be used to decrypt the SSL encrypted traffic.
- Configure which SSL protocols will be inspected.
- Configure which ports will be associated with which SSL protocols for the purpose of inspection.
- Configure whether or not to allow invalid SSL certificates.
- Configure whether or not SSH traffic will be inspected.

Allow Invalid SSL Certificate

This setting was something that used to be part of the *Proxy Options*, but now that SSL inspection has its own configuration setting it is configured with those. It might seem like a straight forward decision that the allowing of invalid SSL certificates must be bad and therefore should not be allowed, but there can be some reasons that should be considered. The issues at hand are the reasons to use a SSL certificate and the reasons that a certificate will be considered invalid.

At a purely technical level, a properly formed certificate will encrypt the data so that it can only be read by the intended parties and not be read by anyone sniffing traffic on the network. For this reason, people will often use self-signed certificates. These self signed certificates are free and will encrypt the data just as well as those purchased from any of the big vendors of certificates, but if they are not listed as an approved Certificate Authority (CA) the certificates will be considered invalid.

On the other hand, one of the services the vendors provide is verification of identity of those that purchase their certificates. This means that if you see a valid certificate from a site that identified itself as being from "valid-company.com" that you can be reasonably sure that the site does belong to that company and not a false site masquerading as being part of that company.

Creating a new SSL/SSH Inspection profile

1. Go to *Policy > Policy > SSL/SSH Inspection*.
2. In the Name field give the profile a name.
3. In the Comments field you can optionally include an brief description of the profile.

SSL Inspection Options

4. Use the drop down menu for the CA Certificate field to choose the SSL Certificate to be used by Policies that are associated with this profile.
5. Choose between
 - a. Inspecting all SSL protocol ports -- enable the check box
 - b. Enabling only specific SSL protocol ports -- enable which of the following protocol you intend to inspect:
 - HTTPS
 - SMTPS
 - POP3S
 - IMAPS
 - FTPS

You can optionally edit the TCP/IP port numbers that you expect the traffic to be travelling over.

SSH Inspection Options

6. Choose whether or not to enable SSH Deep Scan. If yes, enable the check box.
Once the check box is enabled a window will appear to be used in the configuring of:
 - SSH - across any port or only the specified one.
 - Exec - *Block, Log* or neither. Select using check boxes.
 - Port-Forward - *Block, Log* or neither. Select using check boxes.
 - SSH-Shell - *Block, Log* or neither. Select using check boxes.
 - X11-Filter - *Block, Log* or neither. Select using check boxes.

Common Options

7. Choose whether to *Allow Invalid SSL Certificates*. If yes, enable the check box.
8. Select *OK*.



The *Enable SSH Deep Scan* feature is enabled by default when creating a new SSL/SSH Inspection profile. There are situations where this feature can cause issues so be sure that you would like it enabled before applying it.

Security policies

One of the foundations upon which a firewall works is the use of policies. These are what bring the other firewall objects and components together into an elegant mechanism for the governing of the traffic going through the network.

This Chapter includes information on the following topics:

- Firewall policies
- Identity Based Policies
- Device Identity Policies
- VPN Policies
- Interface Policies
- One-Arm IDS
- Local-In Policies
- Security Policy 0
- Deny Policies
- Accept Policies
- IPv6 Policies
- Fixed Port
- Endpoint Security
- Traffic Logging
- Quality of Service
- Policy Monitor

Firewall policies

The firewall policy is the axis around which most of the other features of the FortiGate firewall revolve. A large portion of the settings in the firewall at some point will end up relating to or being associated with the firewall policies and the traffic that they govern. Any traffic going through a FortiGate unit has to be associated with a policy. These policies are essentially discrete compartmentalized sets of instructions that control the traffic flow going through the firewall. These instructions control where the traffic goes, how it's processed, if it's processed and even whether or not it's allowed to pass through the FortiGate.

When the firewall receives a connection packet, it analyzes the packet's source address, destination address, and service (by port number). It also registers the incoming interface, the outgoing interface it will need to use and the time of day. Using this information the FortiGate firewall attempts to locate a security policy that matches the packet. If it finds a policy that matches the parameters it then looks at the action for that policy. If it is ACCEPT the traffic is allowed to proceed to the next step. If the Action is DENY or a match cannot be found the traffic is not allowed to proceed.

The 2 basic actions at the initial connection are either ACCEPT or DENY:

- If the Action is ACCEPT, the policy action permits communication sessions. There may be other packet processing instructions, such as requiring authentication to use the policy.

While you may not see it in the configuration there is the implied subset of the ACCEPT Action that include VPN policies, whether they be an IPSec VPN or SSL.

- If the Action is DENY, the policy action blocks communication sessions, and you can optionally log the denied traffic. If no security policy matches the traffic, the packets are dropped. A DENY security policy is needed when it is required to log the denied traffic, also called “violation traffic”.

The policy may contain a number of instructions for the FortiGate firewall in addition to the ACCEPT or DENY actions, some of which are optional. Instructions on how to process the traffic can also include such things as:

- Logging Traffic
- Authentication
- Network Address Translation or Port Address Translation
- Use Virtual IPs or IP Pools
- Caching
- Whether to use address or Identity based rules
- Whether to treat as regular traffic or VPN traffic
- What certificates to use
- Security profiles to apply
- Proxy Options
- Traffic Shaping

As mentioned before, for traffic to flow through the FortiGate firewall there must be a policy that matches its parameters:

- Source Interface
- Destination Interface
- Source Address
- Destination Address
- Service or TCP/IP suite port number
- Schedule and time of the session’s initiation

Without all five of these things matching the traffic will be declined. Each traffic flow requires a policy and the direction is important as well. Just because packets can go from point A to point B on port X does not mean that the traffic can flow from point B to point A on port X. A policy must be configured for each direction.

When designing a policy there is often reference to the traffic flow, but most communication is a two way connection so trying to determine the direction of the flow can be somewhat confusing. If traffic is HTTP web traffic the user sends a request to the web site, but most of the traffic flow will be coming from the web site to the user. Is the traffic flow considered to be from the user to the web site, the web site to the user or in both directions? For the purposes of determining the direction for a policy the important factor is the direction of the initiating communication. The user is sending a request to the web site so this is the initial communication and the web site is just responding to it so the traffic will be from the users network to the Internet.

A case where either side can initiate the communication like between two internal interfaces on the FortiGate unit would be a more likely situation to require a policy for each direction.

What is not expressly allowed is denied

One of the fundamental ideas that can be found in just about any firewall is the rule than anything that is not expressly allowed is by default denied. This is the foundation for any

strategy of protecting your network. Right out of the box, once you have your FortiGate device connected into your network and hooked up with your ISP your network is protected. Nothing is getting out or in so it is not very convenient, but you don't have to worry that between the time you hooked it up and the point that you got all of the policies in place that someone could have gotten in and done something to your resources. The reason that this needs to be kept in mind when designing policies is because you cannot assume that any traffic will be allowed just because it makes sense to do so. If you want any kind of traffic to make it past the FortiGate firewall you need to create a policy that will allow that traffic. To maintain the protection of the network should also make sure that the any policy you create allows only the traffic you intend to go only to where you specifically want it to go and when you want it to go there.

Example

You have a web server on your network that is meant to provide a collaborative work environment web site for your employees and a partner company for a project over the course of the next 3 months.

It is theoretically possible to allow connections into your network to any device on that network for any service and at any time. The problem with this is that we might not want just anybody looking at those resources. Sadly, no matter how much it is wished otherwise, not everybody on the Internet can be trusted. Which means we now have to be very specific in our instructions as to what traffic to allow into the network. Each step that we take towards being more specific as to what we allow means that there is that much more that is not allowed and the level of protection of a resources is directly proportional to the amount of traffic that is not allowed. If somebody can't get at it they can't damage or steal it.

Limiting where the traffic is allowed to go to means that other computers on your network besides the web-server are protected.

- Limiting where the traffic is allowed to come from means that, if feasible, you can limit the systems that can access the web server to just employees or the partner company computers.
- Limiting the services to just web traffic means that a malicious person, even if they were connection from a computer at the partner organization could only use the features of web traffic to do anything malicious.
- Limiting the policy to the time span of the project would mean that even if the IT department forgot to remove the policy after the end of the project than no computer from the other company could be used to do anything malicious through the policy that allowed the traffic.

This is just a very basic example but it shows the underlying principles of how the idea that anything not expressly allowed is by default denied can be used to effectively protect your network.

Policy order

Another important factor in how firewall policies work is the concept of precedence of order or if you prefer a more recognizable term, "first come, first served".

It is highly likely that even after only a relatively small number of policies have been created that there will be some that overlap or are subsets of the parameters that the policies use to determine which policy should be matched against the incoming traffic. When this happens there has to be a method to determine which policy should be applied to the packet. The method which is used by most firewalls it based on the order of the sequence of the policies.

If all of the policies were placed in a sequential list the process to match up the packet would start at the top of the list and work its way down. It would compare information about the packet, specifically these points of information:

1. The interface the packet connected to the FortiGate firewall
2. The source address of the packet

3. The destination address of the packet
4. The interface the packet would need to use to get to the destination address based on the routing table
5. The port the packet is destined for
6. The time that the packet connected to the FortiGate

As soon as the a policy is reached that matched all six (6) of these parameters, the instructions of that policy are applied and the search for any other matching policies is stopped. All subsequent policies are disregarded. Only 1 policy is applied to the packet.

If there is no matching policy among the policies that have been configured for traffic the packet finally drops down to what is always the last policy. It is an implicit policy. One of a few that are referred to by the term “policy0”. This policy denies everything.

The implicit policy is made up of the following settings:

- Incoming Interface: any
- Source Address: any
- Outgoing Interface: any
- Destination Address: any
- Action: DENY

The only setting that is editable in the implicit policy is the logging of violation traffic.

A logical best practice that comes from the knowledge of how this process works is to make sure that the more specific or specialized a policy is, the closer to the beginning of the sequence it should be. The more general a policy is the higher the likelihood that it could include in its range of parameters a more specifically targeted policy. The more specific a policy is, the higher the probability that there is a requirement for treating that traffic in a specific way.

Example

For security reasons there is no FTP traffic allowed out of a specific subnet so there is a policy that states that any traffic coming from that subnet is denied if the service is FTP, so the following policy was created:

Policy #1

Source Interface	Internal1
Source Address	192.168.1.0/24
Outgoing Interface	WAN1
Destination Address	0.0.0.0/0.0.0.0
Service	FTP
Schedule	always
Action	deny

Now as these things usually go it turns out that there has to be an exception to the rule. There is one very secure computer on the subnet that is allowed to use FTP and once the content has been checked it can then be distributed to the other computer on the subnet. So a second firewall policy is created.

Policy #2

Source Interface	Internal1
Source Address	192.168.1.38/32
Outgoing Interface	WAN1
Destination Address	0.0.0.0/0.0.0.0
Service	FTP
Schedule	always
Action	Allow

By default, a policy that has just been created will be placed last in the sequence so that it is less likely to interfere with existing policies before it can be moved to its intended position. If you look at Policy #2 you will notice that it is essentially the same as Policy #1 exempt for the Source Address and the Action. You will also notice that the Source Address of the Policy #2 is a subset of the Source address in policy #1. This means that if nothing further is done, Policy #2 will never see any traffic because the traffic will always be matched by Policy #1 and processed before it has a chance to reach the second policy in the sequence. For both policies to work as intended Policy #2 needs to be moved to before Policy #1 in the sequence.

###

Viewing Firewall Policies

When you first go into the Policy window, found by going to Policy > Policy > Policy, you will see a table with a menu bar across the top. The menu bar will have the following items:

At the top left

- Create New (with a “+” sign on the left and a downward pointing triangle on the right)
- Clone
- Delete
- Column Settings
- Filter Settings

At the top right

- Section View
- Global View

The items at the top right with their radio buttons represent the 2 potential views that the policies can be displayed in.

The Global View shows all of the policies in the order of their sequence. With the default settings you will be able to see the sequence number in a column close to the left side of the table.

The Section view is similar to the Global View except that as the name implies it is divided into sections. By default the sections are based on the paths between the interfaces. These can be referred to as “interface pairings”. For instance, all of the policies referencing traffic from WAN1 to DMZ will be in one section. The policies referencing traffic from DMZ to WAN1 will be in another section.

The sections are collapsible so that you only need to look at the sections with policies you are interested in. It is possible to add customized subsections within the default sections of

interface pairings. This would be useful in a situation where you have a lot of policies and would like to further compartmentalize them by common attributes so that things are easier to find.

The default column headings are:

- [Check box icon]
- Seq.#
- Source
- Destination
- Authentication
- Schedule
- Service
- Action
- Log

The columns that are shown are configurable. All but the first 2 can be removed or their position changed. There are also a number of other columns that display information about the policies that can be added. One of the more useful ones that can be added is the ID column. The reason for adding this one is that policies are referenced by their ID number for simplicity and ease of administration. If you are looking in the CLI you will see that the only designation for a policy is its number and if you wish to change the order of a policy you will be asked to move it before or after another policy by referencing its number.

How “Any” policy can remove the Section View

The FortiGate unit will automatically change the view on the policy list page to Global View whenever a policy containing “any” in the Source interface/zone or Destination interface/zone is created. If the Section View is greyed out it is likely that one or more of the policies has “any” as a Source or Destination interface.

With the use of the “any” the policy should go into multiple sections because it could effectively be any of a number of interface pairings. As mentioned, policies are sectioned by using the interface pairings (for example, port1 -> port2) and each section has its own specific policy order. The order in which a policy is checked for matching criteria to a packet’s information is based solely on the position of the policy within its section or within the entire list of policies as a whole but if the policy is in multiple sections at the same time there is no mechanism for placing the policy in a proper order within all of those sections at the same time because it is a manual process and there is no parameter to compare the precedence of one section or policy over the other. Thus a conflict is created. In order to resolve the conflict the FortiGate firewall removes that aspect of the sections so that there is no need to compare and find precedence between the sections and it therefore has only the Global View to work with.

Security policy configuration extensions

When first creating the policy the configuration form will ask for a choice between the policy types of Firewall or VPN, Firewall being the default. Choosing whether or not to leave the selection as Firewall is straight forward. If the policy is not a policy based VPN policy then it is a Firewall policy type.

There are essentially 2 types of VPN connections, Interface Based and Policy Based. In an Interface Based VPN tunnel a logical interface is created that can be seen as an interface by the policies in the same way that any of the physical interfaces can be seen. Therefore to govern the traffic a regular policy will work. The policy based VPN tunnels work slightly different and therefore need a slightly different policy configuration. For a more detail explanation of the difference between the types of VPN tunnels refer to the VPN documentation found in the VPN handbooks or in the VPN section of the Complete Administration Guide.

Once either the Firewall or the VPN type has been chosen there is then a choice between one of subtypes for each of the Policy types. For the Firewall type of policy the subtypes are:

- Address
- User Identity
- Device Identity

The Address subtype refers to policies where access through the FortiGate firewall is dependant on the source location of the addresses of the devices involved in the traffic matched to the policy.

The User Identity subtype refers to policies where access through the FortiGate firewall is dependant on the users credentials or Identity.

The Device Identity subtype refers to policy where access through the FortiGate firewall is dependant on the specific device being used based on the MAC address of the device or belonging to a group of devices that are based on device types or belonging to custom made groups.

For the VPN type the subtypes are:

- IPSec
- SSL-VPN

As expected the two subtypes are the two different types of VPN tunnels that the FortiGate firewall supports in a policy based configuration.

Identity Based Policies

Identity-based security policies, also known as authentication policies, match traffic that requires a supported authentication protocol to trigger the firewall authentication challenge and successfully authenticate network users. Network users authentication can occur using HTTP, HTTPS, FTP, and Telnet protocols as well as through automatic login using NTLM and FSSO, to bypass user intervention.

Identity-based security policies are usually configured for IPSec or SSL VPN traffic since this type of traffic usually requires authentication from network users.

When configuring identity-based policies, you can use schedules to limit network users authentication sessions. For example, example.com has a schedule policy to use P2P applications between noon and 1:00 pm, and a user authentication timeout of 30

minutes. When a user logs in at 12:15 pm, their authentication time logs them off at 12:45 (30 minutes later). You can configure this type of authentication by using the `scheduletimeout` field in the `config firewall policy` command in the CLI.

Identity-based policy positioning

With identity-based security policies, positioning is extremely important. For a typical security policy, the FortiGate unit matches the source, destination and service of the policy. If matched, it acts on that policy. If not, the FortiGate unit moves to the next policy.

With identity-based policies, once the FortiGate unit matches the source and destination addresses, it processes the identity sub-rules for the user groups and services. That is, it acts on the authentication and completes the remainder of that policy and goes no further in the policy list.

The way identity based policies work is that once `src/dest` are matched, it will process the identity based sub-rules (for lack of a better term) around the user groups and services. It will

never process the rest of your rule base. For this reason, unique security policies should be placed before an identity-based policy.

For example, consider the following policies:

DNS traffic goes through successfully as does any HTTP traffic after being authenticated. However, if there was FTP traffic, it would not get through. As the FortiGate unit processes FTP traffic, it skips rule one since it's matching the source, destination and service. When it moves to rule two it matches the source and destination, it determines there is a match and, sees there are also processes the group/service rules, which requires authentication and acts on those rules. Once satisfied, the FortiGate unit will never go to rule three.

In this situation, where you would want FTP traffic to traverse the FortiGate unit, create a security policy specific to the services you require and place it above the authentication policy.

Identity-based sub-policies

When adding authentication to a security policy, you can add multiple authentication rules, or sub-policies. Within these policies you can include additional security profiles, traffic shaping and so on, to take affect on the selected services.

Figure 1: Authentication sub-policies

These sub-policies work on the same principle as normal security policies, that is, top down until the criteria has been met. As such, if there is no matching policy within the list, the packet can still be dropped even after authentication is successful.

Identity policies an unauthenticated users

One of the previous drawbacks with User Identity policies is that if traffic from an unauthenticated user enters the policy it will be denied by default because it doesn't match up with any of the user group and therefore falls to policy 0 which denies access to any traffic that reaches it. Allowances have been made so that if you are using User Identity based policies you are not forced to authenticate all users and create a subpolicy for all of the users.

When configuring User Identity policies you can select the option to *Skip this policy for unauthenticated user*. This policy will only apply to user traffic where the user has already authenticated with the FortiGate unit. As the name of the option implies, this policy will not apply to unauthenticated users and any traffic from unauthenticated uses that makes it through the sequence to this policy will continue on the next policy.

The command line syntax for using this feature is:

```
config firewall policy
  edit <id>
    set identity-based enable
    set fall-through-unauthenticated enable
  next
end
```

Because of this option, User Identity policies can be placed much higher in the sequence than they once were. Now that the policy will no longer interfere with unauthenticated traffic it can be placed so that non user specific policies will not act upon the traffic before it reaches its intended policy.

Device Identity Policies

Device identity policies are designed to assist in accommodating the BYOD trends.

These policies will share many of the same characteristics and field values as the other firewall policies. The point at which a Device Policy defers from other policies on the FortiGate firewall is that when creating one of these policies the criteria that the authentication will be based on is the MAC address of the device making the connection. With the MAC addresses being unique to a specific networkable device there is a great deal of control that can be exercised with these policies.

In cooperation with the MAC scanning capabilities of the FortiGate it is relatively simple to create a profile that will allow access to the wireless network to personal devices such as smart phones, tablets and personal laptops that are brought into work by employees or even contractors and other guests.

The process of authentication is similar to the processes taking place in the Identity based policies. The FortiGate firewall checks the incoming traffic for parameters such as interfaces, addresses, times and services and then matches them with the values associated with the traffic that is associated with the MAC addresses listed in the policy. If everything matches up correctly traffic is allowed to proceed.

The device addresses can be listed by individual MAC addresses, predefined groups based on device type or custom made groupings of the MAC addresses.

VPN Policies

At one point, if you wanted to have secure digital communications between 2 points a private network would be created. This network would only allow the people that were intended to get the communications on it. This is very straightforward if the 2 points are in the same room or even in the same building. It can all be done physically. If you are supposed to be on the secure network

VPNs are an answer to one of today's biggest concerns, how to make digital communications secure between to points that must communicate over the Internet which anybody can have access to

IPSec Policies

IPSec policies allow IPSec VPN traffic access to the internal network from a remote location. These policies include authentication information that authenticates users and user group or groups. These policies specify the following:

- the FortiGate firewall interface that provides the physical connection to the remote VPN gateway, usually an interface connected to the Internet
- the FortiGate firewall interface that connects to the private network
- IP addresses associated with data that has to be encrypted and decrypted
- optional: a schedule that restricts when the VPN can operate, and services (or types of data) that can be sent.

For a route-based (interface mode) VPN, you do not configure an IPSec security policy. Instead, you configure two regular ACCEPT security policies, one for each direction of communication, with the IPSec virtual interface as the source or destination interface, as appropriate.

SSL VPN Policies

SSL VPN security policies are created for permitting SSL VPN clients, web-mode or tunnel-mode, access to the protected network behind the FortiGate unit. These security policies also contain authentication information that will authenticate the users and user group or groups.

Interface Policies

Interface policies are implemented before the “security” policies and are only flow based.

This feature allows you to attach a set of IPS policies with the interface instead of the forwarding path, so packets can be delivered to IPS before entering firewall. This feature is used for following IPS deployments:

- One-Arm: by defining interface policies with IPS and DoS anomaly checks and enabling sniff-mode on the interface, the interface can be used for one-arm IDS;
- IPv6 IPS: IPS inspection can be enabled through interface IPv6 policy. Only IPS signature scan is supported in FortiOS 4.0. IPv6 DoS protection is not supported;
- Scan traffics that destined to FortiGate;
- Scan and log traffics that are silently dropped or flooded by Firewall or Multicast traffic.

IPS sensors can be assigned to an interface policy. Both incoming and outgoing packets are inspected by IPS sensor (signature).

Here is an example of an interface policy,

```
config firewall interface-policy
  edit 1
    set status enable
    set interface "port14"
    set srcaddr "all"
    set dstaddr "all"
    set service "ALL"
    set application-list-status disable
    set ips-sensor-status enable
    set ips-sensor "default"
    set av-profile-status disable
    set webfilter-profile-status disable
    set spamfilter-profile-status disable
    set dlp-sensor-status disable
    set label "Port 14 Interface Policy"
  next
end
```

DoS Protection

Denial of Service (DoS) policies are primarily used to apply DoS anomaly checks to network traffic based on the FortiGate interface it is entering as well as the source and destination addresses. DoS checks are a traffic anomaly detection feature to identify network traffic that does not fit known or common traffic patterns and behavior. A common example of anomalous traffic is the denial of service attack. A denial of service occurs when an attacking system starts an abnormally large number of sessions with a target system. The large number of sessions slows down or disables the target system, so that legitimate users can no longer use it.

DoS policies are similar to firewall policies except that instead of defining the way traffic is allowed to flow, they keep track of certain traffic patterns and attributes and will stop traffic displaying those attributes. Further, DoS policies affect only incoming traffic on a single interface. You can further limit a DoS policy by source address, destination address, and service.

DoS configurations have been changed a couple of times in the past. In FortiOS 4.0, DoS protection is moved to the interface policy, so when it is enabled, it is the first thing checked

when a packet enters FortiGate. Because of this early detection, DoS policies are a very efficient defence that uses few resources. Denial of service attacks, for example, are detected and its packets dropped before requiring security policy look-ups, antivirus scans, and other protective but resource-intensive operations.

A DoS policy examines network traffic arriving at an interface for anomalous patterns usually indicating an attack. This does not mean that all anomalies experience by the firewall are the result of an intentional attack.

Because an improperly configured DoS anomaly check can interfere with network traffic, no DoS checks are preconfigured on a factory default FortiGate unit. You must create your own before they will take effect. Thresholds for newly created sensors are preset with recommended values that you can adjust to meet the needs of your network.

To create a Denial of Service policy determine if it needs to be an IPv4 or IPv6 policy, then goto:

Policy > Policy > DoS Policy for IPv4.

Policy > Policy > IPv6 DoS Policy for IPv6.



It is important to know normal and expected network traffic before changing the default anomaly thresholds. Setting the thresholds too low could cause false positives, and setting the thresholds too high could allow otherwise avoidable attacks.

Settings used in configuring DoS

Incoming Interface

The interface to which this security policy applies. It will be the that the traffic is coming into the firewall on.

Source Address

This will be the address that the traffic is coming from and must be a address listed in the Address section of the Firewall Objects. This can include the predefined “all” address which covers any address coming in on any interface. Multiple addresses or address groups can be chosen

Destination Address

This will be the address that the traffic is addressed to. In this case it must be an address that is associated with the firewall itself. For instance it could be one of the interface address of the firewall, a secondary IP address or the interface address assigned to a Virtual IP address. Just like with the Source Address this address must be already configured before being used in the DoS policy. Multiple addresses, virtual IPs or virtual IP groups can be chosen.

Service

While the Service field allows for the use of the ALL service some administrators prefer to optimize the resources of the firewall and only check on the services that will be answered on an interface. Multiple services or service groups can be chosen.

Anomalies

The anomalies can not be configured by the user. They are predefined sensors set up for specific patterns of anomalous traffic

The anomalies that have been predefined for use in the DoS Policies are:

Anomaly Name	Description	Recommended Threshold
tcp_syn_flood	If the SYN packet rate of new TCP connections, including retransmission, to one destination IP address exceeds the configured threshold value, the action is executed.	2000 packets per second.
tcp_port_scan	If the SYN packet rate of new TCP connections, including retransmission, from one source IP address exceeds the configured threshold value, the action is executed.	1000 packets per second.
tcp_src_session	If the number of concurrent TCP connections from one source IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.
tcp_dst_session	If the number of concurrent TCP connections to one destination IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.
udp_flood	If the UDP traffic to one destination IP address exceeds the configured threshold value, the action is executed.	2000 packets per second.
udp_scan	If the number of UDP sessions originating from one source IP address exceeds the configured threshold value, the action is executed.	2000 packets per second.
udp_src_session	If the number of concurrent UDP connections from one source IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.
udp_dst_session	If the number of concurrent UDP connections to one destination IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.
icmp_flood	If the number of ICMP packets sent to one destination IP address exceeds the configured threshold value, the action is executed.	250 packets per second.
icmp_sweep	If the number of ICMP packets originating from one source IP address exceeds the configured threshold value, the action is executed.	100 packets per second.
icmp_src_session	If the number of concurrent ICMP connections from one source IP address exceeds the configured threshold value, the action is executed.	300 concurrent sessions
icmp_dst_session	If the number of concurrent ICMP connections to one destination IP address exceeds the configured threshold value, the action is executed.	3000 concurrent sessions
ip_src_session	If the number of concurrent IP connections from one source IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.

Anomaly Name	Description	Recommended Threshold
ip_dst_session	If the number of concurrent IP connections to one destination IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions.
sctp_flood	If the number of Sctp packets sent to one destination IP address exceeds the configured threshold value, the action is executed.	2000 packets per second
sctp_scan	If the number of Sctp sessions originating from one source IP address exceeds the configured threshold value, the action is executed.	1000 packets per second
sctp_src_session	If the number of concurrent Sctp connections from one source IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions
sctp_dst_session	If the number of concurrent Sctp connections to one destination IP address exceeds the configured threshold value, the action is executed.	5000 concurrent sessions

Status

The status field is enabled to enable the sensor for the associated anomaly. In terms of actions performed there is no difference between disabling a sensor and having the action as “Pass” but by disabling sensors that are not being used for blocking or logging you can save some resources of the firewall that can be better used elsewhere.

Logging

Regardless of whether the traffic is blocked or passed through the anomalous traffic will be logged.

Pass

Allows the anomalous traffic to pass through unimpeded.

Block

For Thresholds based on the number of concurrent sessions blocking the anomaly will not allow more than the number of concurrent sessions set as the threshold.

For rate based thresholds where the threshold is measured in packets per second, the Action setting “Block” prevents the overwhelming of the firewall by anomalous traffic in one of 2 ways. Setting which of those 2 ways will be issued is determined in the CLI.

- continuous - blocks any packets that match the anomaly criteria once the threshold has been reached
- periodical - allows matching anomalous traffic up to the rate set by the threshold.

To set the type of block action for the rate based anomaly sensors:

```
config ips global
    set anomaly-mode continuous
    set anomaly-mode periodical
end
```

Threshold

The threshold can be either in terms of concurrent session or in packets per second depending on which sensor is being referred to.

One-Arm IDS

Interface-based policy only defines what and how IPS functions are applied to the packets transmitted by the interface. It works no matter if the port is used in a forwarding path or used as an One-Arm device.

To enable One-Arm IDS, the user should first enable sniff-mode on the interface,

```
config system interface
  edit port2
    set ips-sniffer-mode enable
  next
end
```

Once sniff-mode is turned on, both incoming and outgoing packets will be dropped after IPS inspections. The port can be connected to a hub or a switch's SPAN port. Any packet picked up by the interface will still follow the interface policy so different IPS and DoS anomaly checks can be applied.

IPv6 IPS

IPv6 IPS signature scan can be enabled by interface policy. The user can create an normal IPS sensor and assign it to the IPv6 interface policy.

```
config firewall interface-policy6
  edit 1
    set interface "port1"
    set srcaddr6 "all"
    set dstaddr6 "all"
    set service6 "ANY"
    set ips-sensor-status enable
    set ips-sensor "all_default"
  next
end
```

Traffic Destined to the FortiGate unit

IPS enabled in firewall policies can only inspect the traffic pass through FortiGate unit, not the traffic destined to FortiGate unit. Enabling IPS in interface-policy allows IPS to pick up any packet on the interface so it is able to inspect attacks targeting FGT.

Dropped, Flooded, Broadcast, Multicast and L2 packets

In many evaluation or certification tests, FortiGate firewall is often required to log any packets dropped by the firewall. In most of cases, these packets are of invalid headers so firewall just drops them silently. It is natural to forward all these packets to IPS first so FortiGate firewall is able to generate logs for invalid packets.

Flooded, broadcast and multicast traffics do not reach any of services in the forwarding path. They can be inspected by the interface policy as long as they match the addresses defined.

Potentially, L2 packets can also be sent to IPS for inspection through interface-policy, but it is not enabled in FortiOS 4.0.

GUI and CLI

Now in FortiGate, there are two places that IPS can be enabled, in a firewall policy and in an interface policy. In the firewall policy implementation, IPS sensor can be configured in both CLI and GUI. When adding an IPS sensor to an interface policy it must be done through the CLI. There is no GUI input window for the “Interface Policy”. There is however, a DoS Policy section in the GUI.

Local-In Policies

On the FortiGate unit, there are a number of protocols and traffic that is specific to the internal workings of FortiOS. For many of these traffic sources, you can identify a specific port/IP address for this self-originating traffic. The following traffic can be configured to a specific port/IP address:

- SNMP
- Syslog
- alert email
- FortiManager connection IP
- FortiGuard services
- FortiAnalyzer logging
- NTP
- DNS
- Authorization requests such as RADIUS
- FSSO

Security policies control the flow of traffic through the FortiGate unit. The FortiGate unit also includes the option of controlling internal traffic, that is, management traffic.

Each interface includes an allow access configuration to allow management access for specific protocols. Local policies are set up automatically to allow all users all access. Local-in policies takes this a step further, to enable or restrict the user with that access. This also extends beyond the allow access selection.

Local-in policies are configured in the CLI with the commands:

```
config firewall local-in-policy
  edit <policy_number>
    set intf <source_interface>
    set srcaddr <source_address>
    set dstaddr <destination_address>
    set action {accept | deny}
    set service <service name>
    set schedule <schedule_name>
  end
```

For example, you can configure a local-in policy so that only administrators can access the FortiGate unit on weekends from a specific management computer at 192.168.21.12 using SSH on port 3 (192.168.21.77) using the Weekend schedule which defines the time the of access.

```
config firewall local-in-policy
  edit <1>
    set intf port3
    set srcaddr 192.168.21.12
    set dstaddr 192.168.21.77
    set action accept
    set service SSH
    set schedule Weekend
  end
```

You can also disable a policy should there be a requirement to turn off a policy for troubleshooting or other purpose. To disable a policy enter the commands:

```
config firewall local-in-policy
  edit <policy_number>
    set status disable
  end
```

Use the same commands with a status of enable to use the policy again.

Local-in policies are also supported for IPv6 by entering the command

```
config firewall local-in-policy6.
```

Security Policy 0

Any security policy that is automatically added by the FortiGate unit has a policy ID number of zero (0). The most common reasons the FortiGate unit creates this policy is:

- The IPSec policy for FortiAnalyzer (and FortiManager version 3.0) is automatically added when an IPSec connection to the FortiAnalyzer unit or FortiManager is enabled.
- The policy to allow FortiGuard servers to be automatically added has a policy ID number of zero.
- The (default) drop rule that is the last rule in the policy and that is automatically added has a policy ID number of zero.
- When a network zone is defined within a VDOM, the intra-zone traffic set to allow or block is managed by policy 0 if it is not processed by a configured security policy.

This policy can appear in logs but will never appear in the security policy list, and therefore, can never be repositioned in the list.

When viewing the FortiGate firewall logs, you may find a log field entry indicating policyid=0. The following log message example indicates the log field policyid=0 in bold.

```
2008-10-06 00:13:49 log_id=0022013001 type=traffic subtype=violation
pri=warning vd=root SN=179089 duration=0 user=N/A group=N/A rule=0
policyid=0 proto=17 service=137/udp app_type=N/A status=deny
src=10.181.77.73 srcname=10.181.77.73 dst=10.128.1.161
dstname=10.128.1.161 src_int=N/A dst_int="Internal" sent=0 rcvd=0
src_port=137 dst_port=137 vpn=N/A tran_ip=0.0.0.0 tran_port=0
```

Deny Policies

Deny security policies deny traffic that is coming into the network. The FortiGate unit automatically blocks traffic that is associated with a deny security policy.

Deny security policies are usually configured when you need to restrict specific traffic, for example, SSH traffic. Deny security policies can also help when you want to block a service, such as DNS, but allow a specific DNS server.

Accept Policies

Accept security policies accept traffic that is coming into the network. These policies allow traffic through the FortiGate unit, where the packets are scanned, translated if NAT is enabled, and then sent out to its destination.

Accept security policies are the most common security policies that are created in FortiOS. These security policies are basic policies, such as allowing Internet access, as well as complex policies, such as IPSec VPN.

IPv6 Policies

IPv6 security policies are created both for an IPv6 network, and a transitional network. A transitional network is a network that is transitioning over to IPv6, but must still have access to the Internet or must connect over an IPv4 network.

These policies allow for this specific type of traffic to travel between the IPv6 and IPv4 networks. The IPv6 options for creating these policies is hidden by default. You must enable this feature in *System > Config > Settings*.

Fixed Port

Some network configurations do not operate correctly if a NAT policy translates the source port of packets used by the connection. NAT translates source ports to keep track of connections for a particular service.

From the CLI you can enable `fixedport` when configuring a security policy for NAT policies to prevent source port translation.

```
config firewall policy
  edit <policy-id>
    ...
    set fixedport enable
    ...
  end
```

However, enabling `fixedport` means that only one connection can be supported through the firewall for this service. To be able to support multiple connections, add an IP pool, and then select Dynamic IP pool in the policy. The firewall randomly selects an IP address from the IP pool and assigns it to each connection. In this case, the number of connections that the firewall can support is limited by the number of IP addresses in the

Endpoint Security

Endpoint security enforces the use of the FortiClient End Point Security (FortiClient and FortiClient Lite) application on your network. It can also allow or deny endpoints access to the network based on the application installed on them.

By applying endpoint security to a security policy, you can enforce this type of security on your network. FortiClient enforcement can check that the endpoint is running the most recent version of the FortiClient application, that the antivirus signatures are up-to-date, and that the firewall is enabled. An endpoint is usually often a single PC with a single IP address being used to access network services through a FortiGate unit.

With endpoint security enabled on a policy, traffic that attempts to pass through, the FortiGate unit runs compliance checks on the originating host on the source interface. Non-compliant endpoints are blocked. If someone is browsing the web, the endpoints are redirected to a web portal which explains the non-compliance and provides a link to download the FortiClient application installer. The web portal is already installed on the FortiGate unit, as a replacement message, which you can modify if required.

Endpoint Security requires that all hosts using the security policy have the FortiClient Endpoint Security agent installed. Currently, FortiClient Endpoint Security is available for Microsoft Windows 2000 and later only.

For more information about endpoint security, see the Security Profiles chapter in the FortiOS Handbook.

Traffic Logging

When you enable logging on a security policy, the FortiGate unit records the scanning process activity that occurs, as well as whether the FortiGate unit allowed or denied the traffic according to the rules stated in the security policy. This information can provide insight into whether a security policy is working properly, as well as if there needs to be any modifications to the security policy, such as adding traffic shaping for better traffic performance.

Depending on what the FortiGate unit has in the way of resources, there may be advantages in optimizing the amount of logging taking places. This is why in each policy you are given 3 options for the logging:

- *No Log* - Does not record any log messages about traffic accepted by this policy.
- *Log Security Events* - records only log messages relating to security events caused by traffic accepted by this policy.
- *Log all Sessions* - records all log messages relating to all of the traffic accepted by this policy.

Depending on the the model, if the Log all Sessions option is selected there may be 2 additional options. These options are normally available in the GUI on the higher end models such as the FortiGate 600C or larger.

- *Generate Logs when Session Starts*
- *Capture Packets*

You can also use the CLI to enter the following command to write a log message when a session starts:

```
config firewall policy
  edit <policy-index>
    set logtraffic-start
  end
```

Traffic is logged in the traffic log file and provides detailed information that you may not think you need, but do. For example, the traffic log can have information about an application used (web: HTTP.Image), and whether or not the packet was SNAT or DNAT translated. The following is an example of a traffic log message.

```
2011-04-13
05:23:47
log_id=4
type=traffic
subtype=other
pri=notice
vd=root
status="start"
src="10.41.101.20"
srcname="10.41.101.20"
src_port=58115
dst="172.20.120.100"
dstname="172.20.120.100"
dst_country="N/A"
dst_port=137
tran_ip="N/A"
tran_port=0
tran_sip="10.31.101.41"
tran_sport=58115
service="137/udp"
proto=17
app_type="N/A"
duration=0
rule=1
policyid=1
sent=0
rcvd=0
shaper_drop_sent=0
shaper_drop_rcvd=0
perip_drop=0
src_int="internal"
dst_int="wan1"
SN=97404 app="N/A"
app_cat="N/A"
carrier_ep="N/A"
```

If you want to know more about logging, see the Logging and Reporting chapter in the FortiOS Handbook. If you want to know more about traffic log messages, see the FortiGate Log Message Reference.

Quality of Service

The Quality of Service (QoS) feature allows the management of the level of service and preference given to the various types and sources of traffic going through the firewall so that the traffic that is important to the services and functions connecting through the firewall gets the treatment required to ensure the level of quality that is required.

QoS uses the following techniques:

Traffic policing	Packets are dropped that do not conform to bandwidth limitations
Traffic Shaping	Assigning minimum levels of bandwidth to be allocated to specific traffic flows to guarantee levels of servers or assigning maximum levels of bandwidth to be allocated to specific traffic flows so that they do not impede other flows of traffic.

This helps to ensure that the traffic may consume bandwidth at least at the guaranteed rate by assigning a greater priority queue if the guarantee is not being met. Traffic shaping also ensures that the traffic cannot consume bandwidth greater than the maximum at any given instant in time. Flows that are greater than the maximum rate are subject to traffic policing.

Queuing

Assigning differing levels priority to different traffic flows so that traffic flows that are adversely effected by latency are prevented from being effected by traffic flows that are not subject to the effects of latency. All traffic in a higher priority traffic queue must be completely transmitted before traffic in lower priority queues will be transmitted.

An example of where you would want to use something like this is if you had competing traffic flows of Voice over IP traffic and email traffic. The VoIP traffic is highly susceptible to latency issues. If you have a delay of a few seconds it is quickly noticeable when it is occurring. Email on the other hand can have a time delay of much longer and it is highly unlikely that it will be noticed at all.



By default, the priority given to any traffic is high, so if you want to give one type of traffic priority over all other traffic you will need to lower the priority of all of the other traffic.

Policy Monitor

Once policies have been configured and enabled it is useful to be able to monitor them. To get an overview about what sort of traffic the policies are processing go to Policy > Monitor > Policy Monitor.

The window is separated into two panes.

Upper Pane

The upper pane displays a horizontal bar graph comparing the *Top Policy Usage* based on one of the following criteria:

- Active Sessions
- Bytes
- Packets

The criteria that the displayed graph is based on can be selected from the drop down menu in the upper right corner of the pane. The field name is *Report By*.

The bars of the graph are interactive to an extent and can be used to drill down for more specific information. If you hover the cursor over the bar of the graph a small popup box will appear displaying more detailed information. If the bar of the graph is selected an entirely new window will be displayed using a vertical bar graph to divide the data that made up the first graph by IP address.

For example if the first graph was reporting usage by active sessions it would include a bar for each of the top policies with a number at the end showing how many sessions were currently going through that policy. If one of the bars of the graph was then selected the new bar graph would show the traffic of that policy separated by either *Source Address*, *Destination Address* or *Destination Port*. As in the other window, the selection for the reported criteria is in the upper right corner of the pane. If the parameter was by source address there would be a bar for each of the IP addresses sending a session through the policy and the end of the bar would show how many sessions.

To go back to the previous window of information in the graphs select the Return link in the upper left of the pane.

Lower Pane

The lower pane contains a spreadsheet of the information that the bar graph will derive their information from. The column headings will include:

- Policy ID
- Source Interface/Zone
- Destination Interface/Zone
- Action
- Active Sessions
- Bytes
- Packets

Network defense

This section describes in general terms the means by which attackers can attempt to compromise your network and steps you can take to protect it. The goal of an attack can be as complex as gaining access to your network and the privileged information it contains, or as simple as preventing customers from accessing your web server. Even allowing a virus onto your network can cause damage, so you need to protect against viruses and malware even if they are not specifically targeted at your network.

The following topics are included in this section:

- [Monitoring](#)
- [Blocking external probes](#)
- [Defending against DoS attacks](#)

Monitoring

Monitoring, in the form of logging, alert email, and SNMP, does not directly protect your network. But monitoring allows you to review the progress of an attack, whether afterwards or while in progress. How the attack unfolds may reveal weaknesses in your preparations. The packet archive and sniffer policy logs can reveal more details about the attack. Depending on the detail in your logs, you may be able to determine the attackers location and identity.

While log information is valuable, you must balance the log information with the resources required to collect and store it.

Blocking external probes

Protection against attacks is important, but attackers often use vulnerabilities and network tools to gather information about your network to plan an attack. It is often easier to prevent an attacker from learning important details about your network than to defend against an attack designed to exploit your particular network.

Attacks are often tailored to the hardware or operating system of the target, so reconnaissance is often the first step. The IP addresses of the hosts, the open ports, and the operating systems the hosts are running is invaluable information to an attacker. Probing your network can be as simple as an attacker performing an address sweep or port scan to a more involved operation like sending TCP packets with invalid combinations of flags to see how your firewall reacts.

Address sweeps

An address sweep is a basic network scanning technique to determine which addresses in an address range have active hosts. A typical address sweep involves sending an ICMP ECHO request (a ping) to each address in an address range to attempt to get a response. A response signifies that there is a host at this address that responded to the ping. It then becomes a target for more detailed and potentially invasive attacks.

Address sweeps do not always reveal all the hosts in an address range because some systems may be configured to ignore ECHO requests and not respond, and some firewalls and gateways may be configured to prevent ECHO requests from being transmitted to the destination

network. Despite this shortcoming, Address sweeps are still used because they are simple to perform with software tools that automate the process.

Use the `icmp_sweep` anomaly in a DoS policy to protect against address sweeps.

There are a number of IPS signatures to detect the use of ICMP probes that can gather information about your network. These signatures include `AddressMask`, `Traceroute`, `ICMP.Invalid.Packet.Size`, and `ICMP.Oversized.Packet`. Include ICMP protocol signatures in your IPS sensors to protect against these probes/attacks.

Port scans

Potential attackers may run a port scan on one or more of your hosts. This involves trying to establish a communication session to each port on a host. If the connection is successful, a service may be available that the attacker can exploit.

Use the DoS anomaly check for `tcp_port_scan` to limit the number of sessions (complete and incomplete) from a single source IP address to the configured threshold. If the number of sessions exceed the threshold, the configured action is taken.

Use the DoS anomaly check for `udp_scan` to limit UDP sessions in the same way.

Probes using IP traffic options

Every TCP packet has space reserved for eight flags or control bits. They are used for communicating various control messages. Although space in the packet is reserved for all eight, there are various combinations of flags that should never happen in normal network operation. For example, the SYN flag, used to initiate a session, and the FIN flag, used to end a session, should never be set in the same packet.

Attackers may create packets with these invalid combinations to test how a host will react. Various operating systems and hardware react in different ways, giving a potential attackers clues about the components of your network.

The IPS signature `TCP.Bad.Flags` detects these invalid combinations. The default action is pass though you can override the default and set it to *Block* in your IPS sensor.

Configure packet replay and TCP sequence checking

The anti-replay CLI command allows you to set the level of checking for packet replay and TCP sequence checking (or TCP Sequence (SYN) number checking). All TCP packets contain a Sequence Number (SYN) and an Acknowledgement Number (ACK). The TCP protocol uses these numbers for error free end-to-end communications. TCP sequence checking can also be used to validate individual packets.

FortiGate units use TCP sequence checking to make sure that a packet is part of a TCP session. By default, if a packet is received with sequence numbers that fall out of the expected range, the FortiGate unit drops the packet. This is normally a desired behavior, since it means that the packet is invalid. But in some cases you may want to configure different levels of anti-replay checking if some of your network equipment uses non-RFC methods when sending packets.

Configure the anti-replay CLI command:

```
config system global
    set anti-replay {disable | loose | strict}
end
```

You can set anti-replay protection to the following settings:

- `disable` — No anti-replay protection.
- `loose` — Perform packet sequence checking and ICMP anti-replay checking with the following criteria:
 - The SYN, FIN, and RST bit can not appear in the same packet.
 - The FortiGate unit does not allow more than one ICMP error packet through before it receives a normal TCP or UDP packet.
 - If the FortiGate unit receives an RST packet, and `check-reset-range` is set to `strict`, the FortiGate unit checks to determine if its sequence number in the RST is within the un-ACKed data and drops the packet if the sequence number is incorrect.
- `strict` — Performs all of the loose checking but for each new session also checks to determine if the TCP sequence number in a SYN packet has been calculated correctly and started from the correct value for each new session. Strict anti-replay checking can also help prevent SYN flooding.

If any packet fails a check it is dropped.

Configure ICMP error message verification

Enable ICMP error message verification to ensure an attacker can not send an invalid ICMP error message.

```
config system global
    check-reset-range {disable | strict}
end
```

- `disable` — the FortiGate unit does not validate ICMP error messages.
- `strict` — enable ICMP error message checking.

If the FortiGate unit receives an ICMP error packet that contains an embedded IP(A,B) | TCP(C,D) header, then if FortiOS can locate the A:C->B:D session it checks to make sure that the sequence number in the TCP header is within the range recorded in the session. If the sequence number is not in range then the ICMP packet is dropped. Strict checking also affects how the anti-replay option checks packets.

Protocol header checking

Select the level of checking performed on protocol headers.

```
config system global
    check-protocol-header {loose | strict}
end
```

- `loose` — the FortiGate unit performs basic header checking to verify that a packet is part of a session and should be processed. Basic header checking includes verifying that the layer-4 protocol header length, the IP header length, the IP version, the IP checksum, IP options are correct, etc.
- `strict` — the FortiGate unit does the same checking as above plus it verifies that ESP packets have the correct sequence number, SPI, and data length.

If the packet fails header checking it is dropped by the FortiGate unit.

Evasion techniques

Attackers employ a wide range of tactics to try to disguise their techniques. If an attacker disguises a known attack in such a way that it is not recognized, the attack will evade your

security and possibly succeed. FortiGate security recognizes a wide variety of evasion techniques and normalizes data traffic before inspecting it.

Packet fragmentation

Information sent across local networks and the Internet is encapsulated in packets. There is a maximum allowable size for packets and this maximum size varies depending on network configuration and equipment limitations. If a packet arrives at a switch or gateway and it is too large, the data it carries is divided among two or more smaller packets before being forwarded. This is called fragmentation.

When fragmented packets arrive at their destination, they are reassembled and read. If the fragments do not arrive together, they must be held until all of the fragments arrive. Reassembly of a packet requires all of the fragments.

The FortiGate unit automatically reassembles fragmented packets before processing them because fragmented packets can evade security measures. Both IP packets and TCP packets are reassembled by the IPS engine before examination.

For example, you have configured the FortiGate unit to block access to the example.org web site. Any checks for example.com will fail if a fragmented packet arrives and one fragment contains `http://www.exa` while the other contains `mple.com/`. Viruses and malware can be fragmented and avoid detection in the same way. The FortiGate unit will reassemble fragmented packets before examining network data to ensure that inadvertent or deliberate packet fragmentation does not hide threats in network traffic.

Non-standard ports

Most traffic is sent on a standard port based on the traffic type. The FortiGate unit recognizes most traffic by packet content rather than the TCP/UDP port and uses the proper IPS signatures to examine it. Protocols recognized regardless of port include DHCP, DNP3, FTP, HTTP, IMAP, MS RPC, NNTP, POP3, RSTP, SIP, SMTP, and SSL, as well as the supported IM/P2P application protocols.

In this way, the FortiGate unit will recognize HTTP traffic being sent on port 25 as HTTP rather than SMTP, for example. Because the protocol is correctly identified, the FortiGate unit will examine the traffic for any enabled HTTP signatures.

Negotiation codes

Telnet and FTP servers and clients support the use of negotiation information to allow the server to report what features it supports. This information has been used to exploit vulnerable servers. To avoid this problem, the FortiGate unit removes negotiation codes before IPS inspection.

HTTP URL obfuscation

Attackers encode HTML links using various formats to evade detection and bypass security measures. For example, the URL `www.example.com/cgi.bin` could be encoded in a number of ways to avoid detection but still work properly, and be interpreted the same, in a web browser.

The FortiGate prevents the obfuscation by converting the URL to ASCII before inspection.

Table 6: HTTP URL obfuscation types

Encoding type	Example
No encoding	http://www.example.com/cgi.bin/
Decimal encoding	http://www.example.com/cgi.bin/
URL encoding	http://www.example.com/%43%47%49%2E%42%49%4E%2F
ANSI encoding	http://www.example.com/%u0063%u0067%u0069%u002E%u0062%u0069%u006E/
Directory traversal	http://www.example.com/cgi.bin/test/..

HTTP header obfuscation

The headers of HTTP requests or responses can be modified to make the discovery of patterns and attacks more difficult. To prevent this, the FortiGate unit will:

- remove junk header lines
- reassemble an HTTP header that's been folded onto multiple lines
- move request parameters to HTTP POST body from the URL

The message is scanned for any enabled HTTP IPS signatures once these problems are corrected.

HTTP body obfuscation

The body content of HTTP traffic can be hidden in an attempt to circumvent security scanning. HTTP content can be GZipped or deflated to prevent security inspection. The FortiGate unit will uncompress the traffic before inspecting it.

Another way to hide the contents of HTTP traffic is to send the HTTP body in small pieces, splitting signature matches across two separate pieces of the HTTP body. The FortiGate unit reassembles these 'chunked bodies' before inspection.

Microsoft RPC evasion

Because of its complexity, the Microsoft Remote Procedure Call protocol suite is subject to a number of known evasion techniques, including:

- SMB-level fragmentation
- DCERPC-level fragmentation
- DCERPC multi-part fragmentation
- DCERPC UDP fragmentation
- Multiple DCERPC fragments in one packet

The FortiGate unit reassembles the fragments into their original form before inspection.

Defending against DoS attacks

A denial of service is the result of an attacker sending an abnormally large amount of network traffic to a target system. Having to deal with the traffic flood slows down or disables the target system so that legitimate users can not use it for the duration of the attack.


Any network traffic the target system receives has to be examined, and then accepted or rejected. TCP, UDP, and ICMP traffic is most commonly used, but a particular type of TCP traffic is the most effective. TCP packets with the SYN flag are the most efficient DoS attack tool because of how communication sessions are started between systems.

The “three-way handshake”

Communication sessions between systems start with establishing a TCP/IP connection. This is a simple three step process, sometimes called a “three-way handshake,” initiated by the client attempting to open the connection.

1. The client sends a TCP packet with the SYN flag set. With the SYN packet, the client informs the server of its intention to establish a connection.
2. If the server is able to accept the connection to the client, it sends a packet with the SYN and the ACK flags set. This simultaneously acknowledges the SYN packet the server has received, and informs the client that the server intends to establish a connection.
3. To acknowledge receipt of the packet and establish the connection, the client sends an ACK packet.

Figure 2: Establishing a TCP/IP connection




The three-way handshake is a simple way for the server and client to each agree to establish a connection and acknowledge the other party expressing its intent. Unfortunately, the three-way handshake can be used to interfere with communication rather than facilitate it.

SYN flood

When a client sends a SYN packet to a server, the server creates an entry in its session table to keep track of the connection. The server then sends a SYN+ACK packet expecting an ACK reply and the establishment of a connection.

An attacker intending to disrupt a server with a denial of service (DoS) attack can send a flood of SYN packets and not respond to the SYN+ACK packets the server sends in response. Networks can be slow and packets can get lost so the server will continue to send SYN+ACK packets until it gives up, and removes the failed session from the session table. If an attacker sends enough SYN packets to the server, the session table will fill completely, and further connection attempts will be denied until the incomplete sessions time out. Until this happens, the server is unavailable to service legitimate connection requests.

Figure 3: A single client launches a SYN flood attack




SYN floods are seldom launched from a single address so limiting the number of connection attempts from a single IP address is not usually effective.

SYN spoofing

With a flood of SYN packets coming from a single attacker, you can limit the number of connection attempts from the source IP address or block the attacker entirely. To prevent this simple defense from working, or to disguise the source of the attack, the attacker may spoof the source address and use a number of IP addresses to give the appearance of a distributed denial of service (DDoS) attack. When the server receives the spoofed SYN packets, the SYN+ACK replies will go to the spoofed source IP addresses which will either be invalid, or the system receiving the reply will not know what to do with it.


Figure 4: A client launches a SYN spoof attack



DDoS SYN flood

The most severe form of SYN attack is the distributed SYN flood, one variety of distributed denial of service attack (DDoS). Like the SYN flood, the target receives a flood of SYN packets and the ACK+SYN replies are never answered. The attack is distributed across multiple sources sending SYN packets in a coordinated attack.

Figure 5: Multiple attackers launch a distributed SYN flood



The distributed SYN flood is more difficult to defend against because multiple clients are capable of creating a larger volume of SYN packets than a single client. Even if the server can cope, the volume of traffic may overwhelm a point in the network upstream of the targeted server. The only defence against this is more bandwidth to prevent any choke-points.

Configuring the SYN threshold to prevent SYN floods

The preferred primary defence against any type of SYN flood is the DoS anomaly check for `tcp_syn_flood` threshold. The threshold value sets an upper limit on the number of new incomplete TCP connections allowed per second. If the number of incomplete connections exceeds the threshold value, and the action is set to *Pass*, the FortiGate unit will allow the SYN packets that exceed the threshold. If the action is set to *Block*, the FortiGate unit will block the SYN packets that exceed the threshold, but it will allow SYN packets from clients that send another SYN packet.

The tools attackers use to generate network traffic will not send a second SYN packet when a SYN+ACK response is not received from the server. These tools will not “retry.” Legitimate clients will retry when no response is received, and these retries are allowed even if they exceed the threshold with the action set to *Block*.

SYN proxy

FortiGate units with network acceleration hardware, whether built-in or installed in the form of an add-on module, offer a third action for the `tcp_syn_flood` threshold. Instead of *Block* and *Pass*, you can choose to *Proxy* the incomplete connections that exceed the threshold value.

When the `tcp_syn_flood` threshold action is set to *f*, incomplete TCP connections are allowed as normal as long as the configured threshold is not exceeded. If the threshold is exceeded, the FortiGate unit will intercept incoming SYN packets from clients and respond with a SYN+ACK packet. If the FortiGate unit receives an ACK response as expected, it will “replay” this exchange to the server to establish a communication session between the client and the server, and allow the communication to proceed.

Other flood types

UDP and ICMP packets can also be used for DoS attacks, though they are less common. TCP SYN packets are so effective because the target receives them and maintains a session table entry for each until they time out. Attacks using UDP or ICMP packets do not require the same level of attention from a target, rendering them less effective. The target will usually drop the offending packets immediately, closing the session.

Use the `udp_flood` and `icmp_flood` thresholds to defend against these DoS attacks.

DoS policies

DDoS attacks vary in nature and intensity. Attacks aimed at saturating the available bandwidth upstream of your service can only be countered by adding more bandwidth. DoS policies can help protect against DDoS attacks that aim to overwhelm your server resources.

DoS policy recommendations

- Use and configure DoS policies to appropriate levels based on your network traffic and topology. This will help drop traffic if an abnormal amount is received.
- It is important to set a good threshold. The threshold defines the maximum number of sessions/packets per second of normal traffic. If the threshold is exceeded, the action is triggered. Threshold defaults are general recommendations, although your network may require very different values.
- One way to find the correct values for your environment is to set the action to *Pass* and enable logging. Observe the logs and adjust the threshold values until you can determine the value at which normal traffic begins to generate attack reports. Set the threshold above this value with the margin you want. Note that the smaller the margin, the more protected your system will be from DoS attacks, but your system will also be more likely to generate false alarms.

GUI & CLI - What You May Not Know

The Graphic User Interface (GUI) is designed to be as intuitive as possible but there are always a few things that are left out because to put all of that information on the interface would clutter it up to the point where it wouldn't be graphical and intuitive anymore.

This section is made up of knowledge that will make working with the both of the management interfaces easier because you won't have to find out about things like field limitations through trial and error. Some of it has to do with changing in how navigation in the GUI has changed.

The section includes the topics:

- [Mouse Tricks](#)
- [Changing the default column setting on the policy page](#)
- [Naming Rules and Restrictions](#)
- [Character Restrictions](#)
- [Length of Fields Restrictions](#)
- [Object Tagging and Coloring](#)
- [Numeric Values](#)
- [Selecting options from a list](#)
- [Enabling or disabling options](#)
- [To Enable or Disable Optionally Displayed Features](#)

Mouse Tricks

In previous version of the firmware much of the navigation, editing or choosing of options in the Web-based Manager was carried out by using the mouse in combination with a number of icons visible on the interface. This version of the firmware makes more extensive use of the right or secondary mouse button as well as the "drag and drop" feature. If you are used to the old Web-based Manager interface you will notice that a number of the options at the top of the display window are not there anymore or there are fewer of them.

To get a feel for the new approach the Policy > Policy > Policy window is a noticeable place to see some of these changes in action.

The different view modes are still in the upper right-hand corner as they were before but now there is no column settings link to move or configure the columns of the window. Now if you wish to reposition a column just use the mouse to click on the column heading and drag it to its new position. If you wish to add a new column just right-click on one of the column headings and a drop down menu will appear with the option "Column Settings". Use the right pointing triangle to expand the "Column Settings" option to see a choice of possible columns for the window you are in. Those already selected will be at the top with a checked box and the available new ones will be at the bottom ready to be selected.

By right or secondary clicking the mouse cursor in the cells of the Policy window you will get a drop down menu that is contextual to the column and policy row where you made the click. For example if you right click in the "Schedule" column for the row that is for policy #5 you will get the option to select a schedule for policy #5 along with a number of other configuration options relating to that policy or its position in the sequence of policies.

You will find this approach used much more frequently through out the Web-based Manager, giving it a more modern and intuitive feel once you learn to use the right mouse button rather than finding a link displayed on the page.

Changing the default column setting on the policy page

The Policy > Policy > Policy window is one of the more important ones in the Web based interface and has the capacity to display a lot of information, but displaying all of that information at the same time makes for a very busy screen. If all of the columns are displayed, depending on the screen size you may have to constantly use the scroll bars to see what you need to look at. The default installation shows some of the more commonly used columns but these list may not consist of the columns that you wish to look at or the order that you wish to view them in. For this reason it is possible, through the CLI to override these settings to establish a new default.

The syntax of the command starts with:

```
config system settings
  set gui-default-policy-columns
```

The rest of the command is a space delimited list that depends on the columns you wish to view and the order you wish to view them in. The possible selection is in the following table.

Table 7: Variables for the gui-default-policy-columns command

Variable Name	Column Heading
#	Sequence Number
policyid	Policy ID
srcintf	Source Interface
dstintf	Destination Interface
srcaddr	Source Addresses
dstaddr	Destination Addresses
schedule	Policy Schedule
service	Policy Services
action	Policy Action
logtraffic	Traffic Logging Status
nat	Policy NAT Status
status	Policy Status
authentication	Authentication Groups
count	Policy Traffic Counter
profile	Security Profiles
vpntunnel	VPN Tunnel
comments	Policy Comment

Example:

If you wanted these columns in this order, Policy ID, Source Addresses, Destination Addresses, Security Profiles, Policy Comment. You would enter the command:

```
config system settings
    set gui-default-policy-columns policyid srcaddr dstaddr profile
    comments
```

Naming Rules and Restrictions

The following are the specific rules that are obeyed by the FortiGate.

Duplicate Name Issues:

- A VLAN cannot have the same name as a physical interface.
- An Address must not have the same name as an Address Group.
- An Address or Address Group must not have the same name as a Virtual IP Address.
- A Service cannot have the same name as a Service Group.
- A VLAN must not have the same name as a VDOM.
- A VLAN or VDOM must not have the same name as a Zone.



Try to make each firewall object name as unique as possible so that it cannot be confused with another object.

Character Restrictions

A name can contain numbers (0-9), uppercase and lowercase letters (A-Z, a-z), spaces, and the special characters - and _. Other characters are not allowed

The special characters < > () # " ' are allowed only in the following fields:

- Passwords
- Replacement message
- Firewall policy description
- IPS customized signature
- Antivirus blocked file pattern
- Web Filter banned word
- Spam filter banned word
- interface PPPoE client user name
- modem dialup account user name
- modem dialup telephone number



Where you would normally be tempted to use spaces in a name try using the "-" or "_". There are a few name fields where it is not an issue but most of them will trigger serious and unpredictable issues if there is a space in the name field of the object.

Length of Fields Restrictions

Most name fields accept 35 characters. The exceptions are:

Table 8: Characters allowed in some fields

Field	Characters allowed
VDOM names	12
VLAN name	15
RADIUS server secret	15
LDAP server common name identifier	15
Admin user password	32
Schedule names	32
Local certificate email	60
Modem dialup account user name, password, phone number fields	63
Firewall policy comments	63
RADIUS, LDAP server domain name	63
IPSec phase 1 local/peer ID	63
IPS custom signature name	63
Spam Filter MIME header name	63
Antivirus file block pattern	63
Local certificate organizational unit, organization, locality, state/province fields	127
IPSec phase 1 pre-shared key or certificate name	127
Web Filter banned word, URL, URL exempt, Pattern fields	127
Spam Filter RBL server name, email address, MIME header body	127
LDAP server distinguished name	128
IPS custom signature	511
Replacement message	1024

Object Tagging and Coloring

For ease of administration and searching the features of object tagging and coloring are available. These features can make it easier to find similar objects in an administrative screen or to search based on common assigned criteria.

Tags

The Tag Management menu provides a central location to view, search and manage tags that you created. Tags are keywords or a term that is assigned to a specific configuration that can be used for searching or filtering purposes. With the Tag Management feature you can:

- Search to find a specific tag
- View where a tag is referenced, for example, a single tag could be referenced in a security policy, predefined signature and application
- Go to where the tag is located, for example, a security policy
- View how many tags are currently unused
- Remove tags.

The Tag Management page also provides a way to easily locate a specific object, such as a security policy, because of how tags work. For example, an SSL VPN security policy is tagged with the keywords SSL VPN, remote, and SSL branch office;

1. From the Tag Management page, enter SSL and the tags for that security policy appear;
2. Select one of the tags and within the Object Usage window, select to go to the SSL VPN security policy.
3. You can view detailed information about what object is using a tag by selecting one of the tags in the rectangular area that contains a grey background. The Object Usage window appears, which displays similar information as when you select a number in the Ref. column.



In the Add Tags window, you can select to add existing tags to the security policy or address list; however, these tags belong to predefined signatures and applications as well as to other security policies and address lists so the tags may not be applicable. You should make sure that the tag is valid for its use when applied to a security policy or other object otherwise it becomes redundant.

Coloring

You will sometimes be given the option of changing the color of the icon that will represent the firewall object you are configuring. You can do this by clicking on the [Change] link. You will be given the option of picking one of 32 colors.

Numeric Values

Numeric values are used to configure various sizes, rates, numeric addresses, or other numeric values. For example, a static routing priority of 10, a port number of 8080, or an IP address of 10.10.10.1. Numeric values can be entered as a series of digits without spaces or commas (for example, 10 or 64400), in dotted decimal format (for example the IP address 10.10.10.1) or as in the case of MAC or IPv6 addresses separated by colons (for example, the MAC address 00:09:0F:B7:37:00). Most numeric values are standard base-10 numbers, but some fields (again such as MAC addresses) require hexadecimal numbers.

Most web-based manager numeric value fields make it easy to add the acceptable number of digits within the allowed range. CLI help includes information about allowed numeric value ranges. Both the web-based manager and the CLI prevent you from entering invalid numbers.

Selecting options from a list

If a configuration field can only contain one of a number of selected options, the web-based manager and CLI present you a list of acceptable options and you can select one from the list. No other input is allowed. From the CLI you must spell the selection name correctly.

Enabling or disabling options

If a configuration field can only be on or off (enabled or disabled) the web-based manager presents a check box or other control that can only be enabled or disabled. From the CLI you can set the option to enable or disable.

To Enable or Disable Optionally Displayed Features

There are a number of features in the web-based manager that can be configured to either be displayed if you are likely to use them or disabled if you have no need to see them. The ones that may be relevant to the function of the Firewall are:

- Central NAT Table
- Dynamic Profile
- Explicit Proxy
- Implicit Firewall Policies
- IPv6
- Load Balance
- Local In Policy
- Object Tagging and Coloring

You can enable or disable these features by going to *System > Admin > Settings* or by using the following CLI options:

```
config system global
  set gui-ap-profile {disable | enable}
  set gui-central-nat-table {disable | enable}
  set gui-dns-database {disable | enable}
  set gui-dynamic-profile-display {disable | enable}
  set gui-icap {disable | enable}
  set gui-implicit-id-based-policy {disable | enable}
  set gui-implicit-policy {disable | enable}
  set gui-ipsec-manual-key {enable | disable}
  set gui-ipv6 {enable | disable}
  set gui-lines-per-page <gui_lines>
  set gui-load-balance {disable | enable}
  set gui-object-tags {disable | enable}
  set gui-policy-interface-pairs-view {enable | disable}
  set gui-voip-profile {disable | enable}
end
```

Building firewall objects and policies

The other chapters in the Firewall book have so far been concerned primarily with concepts and abstract ideas that are designed to help you understand what is going on with the firewall and what it can do. Now that we have a good grounding in the “what” it is time to get into the “how”.

This section will provide the instructions for the web-based manager (when available) and the CLI for adding and or editing FortiGate firewall objects and then how to put them together when building a policy to govern the traffic flowing through your network. To give some context, scenarios have been included. The instructions here are concerned with the creation of the objects. The inclusion of these objects into firewall policies is not shown in these instructions.

This chapter includes the instructions for building the following:

- IPv4 Firewall Addresses
- IPv6 Firewall Addresses
- FQDN address
- Changing the TTL of a FQDN address
- New Geography-based Address
- Wildcard Address
- IPv4 Address Group
- IPv6 Address Group
- Multicast Address
- Service Category
- TCP/UDP/SCTP Service
- ICMP Service
- ICMPv6 Service
- Service Group
- Virtual IP address
- IP Pool
- Central NAT Table
- Firewall Schedule - Recurring
- Firewall Schedule - One-time
- Schedule Group
- Proxy Option
- Firewall Address Policy
- Firewall User Identity Policy
- Firewall Device Identity Policy
- DoS Policy

IPv4 Firewall Addresses

Scenario: Mail Server

You need to create an IPv4 address for the Mail Server on Port1 of your internal network.

- These server is on the network off of port1.
- The IP address is 192.168.1.27
- The subnet mask is 255.255.255.0
- There should be a tag for this address being for a server

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information:

Address Name	Mail_Server
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Type	Subnet / IP Range
Subnet / IP Range	192.168.1.27/255.255.255.0
Interface	port1
Add Tags	Server

Select *OK*.

Enter the following CLI command:

```
config firewall address
  edit Mail_Server
    set type ipmask
    set subnet 192.168.1.27 255.255.255.255
    set associated-interface port1
    set tags Server
  end
```

Scenario: First Floor Network

You need to create an IPv4 address for the subnet of the internal network off of Port1.

- These computers are on the network off of port1.
- The subnet is the range from 192.168.1.1 to 192.168.1.255.
- The subnet mask is 255.255.255.0
- There should be a reference to this being the network for the 1st floor of the building.

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information

Address Name	Internal_Subnet_1
Comments	Network for 1st Floor

Color	<Changing this value is optional>
Type	Subnet / IP Range
Subnet / IP Range	192.168.1.0/24
Interface	port1
Add Tags	<Input into this field is optional>

Select *OK*.

Enter the following CLI command:

```
config firewall address
  edit Internal_Subnet_1
    set comment "Network for 1st Floor"
    set type ipmask
    set subnet 192.168.1.0/24
    set associated-interface port1
  end
```

Scenario: Marketing Department

You need to create an IPv4 address for the address range for a group of computers used by the Marketing Department.

- These computers are on the network off of port1.
- The IP addresses for these computers range from 192.168.1.100 to 192.168.1.115

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information

Address Name	Marketing_computers
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Type	Subnet / IP Range
Subnet / IP Range	192.168.1.[100-115]
Interface	port1
Add Tags	<Input into this field is optional>

Select *OK*.

Enter the following CLI command:

```
config firewall address
  edit Internal_Subnet_1
    set type iprange
    set start-ip 192.168.1.100
    set end-ip 192.168.1.115
    set associated-interface port1
  end
```

Verification

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Addresses*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall address
  edit <the name of the address to verify>
    show full-configuration
```

IPv6 Firewall Addresses

Scenario: Mail Server

You need to create an IPv6 address for the Mail Server on Port1 of your internal network.

- These server is on the network off of port1.
- The IP address is 2001:db8:0:2::20/64
- There should be a tag for this address being for a server

Go to *Firewall Objects > Address > Addresses* and select *Create New > IPv6 Address*.

Fill out the fields with the following information

Address Name	Mail_Server
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
IPv6 Address	2001:db8:0:2::20/64
Add Tags	Server

Select *OK*.

Enter the following CLI command:

```
config firewall address6
  edit Mail_Server
    set type ipmask
    set subnet 2001:db8:0:2::20/64
    set associated-interface port1
    set tags Server
  end
```

Scenario: First Floor Network

You need to create an IPv4 address for the subnet of the internal network off of Port1.

- These computers are on the network off of port1.
- The Network uses the IPv6 addresses: fdde:5a7d:f40b:2e9d:xxxx:xxxx:xxxx:xxxx
- There should be a reference to this being the network for the 1st floor of the building.

Go to *Firewall Objects > Address > Addresses* and select *Create New > IPv6 Address*.

Fill out the fields with the following information

Field Name	Field Value
Address Name	Internal_Subnet_1
Comments	Network for 1st Floor
Color	<Changing this value is optional>
Type	Subnet / IP Range
Subnet / IP Range	2001:db8:0:2::/64
Interface	port1
Add Tags	<Input into this field is optional>

Select *OK*.

Enter the following CLI command:

```
config firewall address6
  edit Internal_Subnet_1
    Set comment "Network for 1st Floor"
    set subnet 2001:db8:0:2::/64
  end
```

Verification

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Addresses*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall address6
  edit <the name of the address that you wish to verify>
    Show full-configuration
```

FQDN address

You have to create a policy that will govern traffic that goes to a site that has a number of servers on the Internet. Depending on the traffic or the possibility that one of the servers is down network traffic can go to any one of those sites. The consistent factor is that they all use the same Fully Qualified Domain Name.

- The FQDN of the web site: example.com
- The number of ISP connections off of the FortiGate firewall: 2

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information

Field Name	Field Value
Address Name	BigWebsite.com
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Type	FQDN
FQDN	bigwebsite.com
Interface	any
Add Tags	<Input into this field is optional>

Select *OK*.

Enter the following CLI command:

```
config firewall address
  edit BigWebsite.com
    set type fqdn
    set associated-interface any
    set fqdn bigwebsite.com
  end
```

Verification

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Addresses*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall address
  edit <the name of the address that you wish to verify>
    Show full-configuration
```

Changing the TTL of a FQDN address

To make sure that the FQDN resolves to the most recent active server you have been asked to make sure that the FortiGate has not cached the address for any longer than 10 minutes.

There is no field for the cached time-to-live in the web-based manager. It is only configurable in the CLI. Enter the following commands:

```
config firewall address
  edit BigWebsite.com
    set cache-ttl 600
  end
```

New Geography-based Address

Your company is US based and has information on its web site that may be considered information that is not allowed to be sent to embargoed countries. In an effort to help reduce the possibility of sensitive information going to those countries you have been asked to set up addresses for those countries so that they can be block in the firewall policies.

- One of the countries you have been asked to block is Cuba
- You have been asked to Tag the addresses so that other administrators will know why they have been created

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information

Field Name	Field Value
Address Name	Cuba
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Type	Geography
Country	Cuba
Interface	any
Add Tags	Embargo

Select *OK*.

Enter the following CLI command:

```
config firewall address
edit Cuba
set type geography
set country CN
set interface wan1
end
```

Wildcard Address

The company has a large network with multiple subnets. Each team has its own subnet in the 172.12.x.x range. To help keep things organized the IT department uses the same host address on each subnet for the servers. For instance the gateways are always .1 or .2. mail servers are always .5 and print servers are always .10.

In this case an address needs to be created for the mail servers for the entire company.

The addresses will be 172.12.0.5, 172.12.1.5, 172.12.2.5, etc.

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information

Address Name	Print_Servers
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Type	Subnet / IP Range
Subnet / IP Range	172.12.0.5 / 255.255.0.255
Interface	any

Select *OK*.



There will be a pop up window explaining that the address will automatically be converted to a wildcard address and ask if you would like to continue. When you see the address in the editing window you will notice that the type field shows wildcard even though that was not an option before.

Enter the following CLI command:

```
config firewall address
edit Print_Servers
Set type wildcard
Set wildcard 172.12.0.5 255.255.0.255
end
```

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Addresses*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall address
edit <the name of the address that you wish to verify>
Show full-configuration
```

IPv4 Address Group

Your company has a small division that is in Denmark that has a number of remote users that need to connect to a resource from either home, office or customer sites. The thing that they have in common is that there are all in Denmark. An address group needs to be created that will allow for this.

The preconfigured addresses to use will consist of:

- Denmark - a geography based address
- Denmark_ISP1 - a IP range of address of an ISP that services Denmark
- Denmark_ISP2 - a IP range of address of another ISP that services Denmark
- Denmark_Division - the FQDN of the Denmark office that uses Dynamic DNS

Go to *Firewall Objects > Address > Groups* and select *Create New > Address Group*.

Fill out the fields with the following information

Group Name	Denmark_Users
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Members	Denmark Denmark_ISP1 Denmark_ISP2 Denmark_Division

Select *OK*.

Enter the following CLI command:

```
config firewall addrgrp
edit Denmark_Users
set member Denmark Denmark_ISP1 Denmark_ISP2 Denmark_Division
end
```



If you need to edit out a member of an address group in the CLI you need to

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Groups*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall addgrp
  edit <the name of the address that you wish to verify>
    Show full-configuration
```

IPv6 Address Group

Create IPv6 address groups from existing IPv6 addresses

Your company has 3 internal servers with IPv6 addresses that it would like to group together for the purposes of a number of policies.

The preconfigured addresses to use will consist of:

- Web_Server-1
- Web_Server-2
- Web_Server-3

Go to *Firewall Objects > Address > Groups* and select *Create New > IPv6 Address Group*.

Fill out the fields with the following information

Group Name	Web_Server_Cluster
Comments	<Input into this field is optional>
Color	<Changing this value is optional>
Members	Web_Server-1 Web_Server-2 Web_Server-3

Select *OK*.

Enter the following CLI command:

```
config firewall addrgrp6
  edit Web_Server_Cluster
    set member Web_Server-1 Web_Server-2 Web_Server-3
  end
```

To verify that the addresses were added correctly:

Go to *Firewall Objects > Address > Groups*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall addrgrp6
  edit <the name of the address that you wish to verify>
    Show full-configuration
```

Multicast Address

The company has a large high tech campus that has monitors in many of its meeting rooms. It is common practice for company wide notifications of importance to be done in a streaming video

format with the CEO of the company addressing everyone at once. The video is High Definition quality so takes up a lot of bandwidth. To minimize the impact on the network the network administrators have set things up to allow the use of multicasting to the monitors for these notifications. Now it has to be set up on the FortiGate firewall to allow the traffic.

- The range being used for the multicast is 239.5.0.0 to 239.5.255.255
- The interface on this FortiGate firewall will be on port 4

Go to *Firewall Objects > Address > Addresses* and select *Create New > Address/FQDN*.

Fill out the fields with the following information:

Field	Value
Category	Multicast Address
Name	Meeting_Room_Displays
Color	<optional>
Show in address list	enabled
Multicast IP Range	239.5.0.0-239.5.255.255
Interface	port4
Comments	<optional>

Select *OK*.

Enter the following CLI command:

```
config firewall multicast-address
  edit "meeting_room_display"
    set associated-interface "port9"
    set start-ip 239.5.0.0
    set end-ip 239.5.255.255
    set visibility enable
  next
end
```

To verify that the address range was added correctly:

Go to *Firewall Objects > Address > Groups*. Check that the addresses have been added to the address list and that they are correct.

Enter the following CLI command:

```
config firewall multicast-address
  edit <the name of the address that you wish to verify>
    Show full-configuration
```

Service Category

Add a new category to the list of Service Categories

You plan on adding a number of devices such as web cameras that will allow the monitoring of the physical security of your datacenter. A number of non-standard services will have to be created and you would like to keep them grouped together under the heading of “Surveillance”

Go to *Firewall Objects > Service > Services* and select *Create New > Category*.

Fill out the fields with the following information

Name	Surveillance
Comments	For DataCenter Surveillance Devices

Select *OK*.

Enter the following CLI command:

```
config firewall service category
  Edit Surveillance
  Set comment "For DataCenter Surveillance Devices"
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Service > Services*. Select *Create New > Custom Service*. Go to the *Category* Field and use the drop down menu arrow to open the drop down menu. The new category should be displayed.

Enter the following CLI command:

```
config firewall service category
  show
```

This should bring up all of the categories. Check to see that the new one is displayed.

TCP/UDP/SCTP Service

To create and configure a TCP/UDP/SCTP protocol type service.

You have set up some new web cams at work that send a constant live feed to a security service. Not only do these cameras have a feed that can be sent offsite they can be remotely managed from a browser or an application.

The ports that need to be opened to use all of the features of the web cams are:

- Management by browser - TCP on port 8000
- Real time video feed - UDP on port 4000
- Connection through vendor application - SCTP on port 1600

The IP address of the offsite service is 256.25.56.12 (Not a valid IP address. Used for example only)

- One service will be needed for the incoming connections
- One service will be needed for the outgoing connections

The IT manager would like the service for the outgoing data stream to be tied to the destination of the Surveillance service site so that service can only be used for that one vendor.

To add the incoming service

Go to *Firewall Objects > Service > Services* and select *Create New > Custom Service*.

Fill out the fields with the following information

Name	WebCam_Connection-incoming
Comments	<Input into this field is optional>
Service Type	Firewall
Color	<Changing this value is optional>
Show in Service List	Check in check box
Category	Surveillance
Protocol Type	TCP/UDP/SCTP
IP/FQDN	<Leave blank>

Protocol	Destination Port		Source Port	
	Low	High	Low	High
TCP	8000	8000	1	65535
SCTP	16000	16000	1	65535



The source port range can be left blank as the default is 1 to 65535.

Select *OK*.

Enter the following CLI command:

```
config firewall service custom
edit WebCam_Connection-incoming
Set protocol TCP/UDP/SCTP
Set tcp-portrange 8000
Set sctp-portrange 16000
Set visibility enable
end
```

To add the outgoing service

Go to *Firewall Objects > Service > Services* and select *Create New > Custom Service*.

Fill out the fields with the following information

Name	WebCam_Connection-outgoing
Comments	<Input into this field is optional>
Service Type	Firewall
Color	<Changing this value is optional>

Show in Service List	Check in check box
Category	Surveillance
Protocol Type	TCP/UDP/SCTP
IP/FQDN	256.25.56.12

Protocol	Destination Port		Source Port	
	Low	High	Low	High
TCP	4000	4000	1	65535

Select *OK*.

Enter the following CLI command:

```
config firewall service custom
edit WebCam_Connection-incoming
Set protocol TCP/UDP/SCTP
Set category Surveillance
Set udp-portrange 4000
Set iprange 256.25.56.12
Set visibility enable
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Service > Services*. Check that the services have been added to the service list and that they are correct.

Enter the following CLI command:

```
config firewall service custom
edit <the name of the service that you wish to verify>
Show full-configuration
```

This should bring up all of the details of the service.

ICMP Service

The Security Officer would like to block the use of the traceroute utility through the network. The IT manager insists that ping and other ICMP utility must be allows for the task of diagnosing connectivity, so it is agreed that only traceroute functionality will be blocked.

The ICMP type for traceroute is 30. There is no codes with the type.

Web-based Manager Instructions

Go to *Firewall Objects > Service > Services* and select *Create New > Custom Service*.

Fill out the fields with the following information

Field Name	Field Value
Name	traceroute

Comments	<Input into this field is optional>
Service Type	Firewall
Color	<Changing this value is optional>
Show in Service List	Check in check box
Category	Uncategorized
Protocol Type	ICMP
Type	30
Code	<Leave blank>

Select *OK*.

Enter the following CLI command:

```
config firewall service custom
edit traceroute
set protocol ICMP
set icmp-type 30
set visibility enable
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Service > Services*. Check that the services have been added to the services list and that they are correct.

Enter the following CLI command:

```
config firewall service custom
edit <the name of the service that you wish to verify>
show full-configuration
```

ICMPv6 Service

The IT Manager is doing some diagnostics and would like to temporarily block the successful replies of ICMP Node information Responses between 2 IPv6 networks.

The ICMP type for ICMP Node informations responses is 140. The codes for a successful response is 0.

Web-based Manager Instructions

Go to *Firewall Objects > Service > Services* and select *Create New > Custom Service*.

Fill out the fields with the following information

Field Name	Field Value
Name	diagnostic-test1
Comments	<Input into this field is optional>
Service Type	Firewall

Color	<Changing this value is optional>
Show in Service List	Check in check box
Category	Uncategorized
Protocol Type	ICMP6
Type	140
Code	0

Select *OK*.

Enter the following CLI command:

```
config firewall service custom
edit diagnostic-test1
set protocol ICMP6
set icmptype 140
set icmpcode 0
set visibility enable
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Service > Services*. Check that the services have been added to the services list and that they are correct.

Enter the following CLI command:

```
config firewall service custom
edit <the name of the service that you wish to verify>
show full-configuration
```

Service Group

The company provide email services for a number of different companies. They have a standard list of services that they like to keep open to their customer's email servers, including webmail services. The company prides itself on getting a customer up and going the same day so they use standard templates for everything to make sure nothing is forgotten including the services that are available.

The services include:

- IMAP
- IMAPS
- POP3
- POP3S
- SMTP
- SMTPS
- HTTP
- HTTPS
- Email_Admin - a custom service for administration of the servers

Go to Firewall Objects > Service > Groups and select *Create New*.

Fill out the fields with the following information:

Field	Value
Group Name	Cust_Email_Serv_Template
Comments	(Optional)
Color	(Optional)
Type	Firewall
Members	(click to add...choose from the drop down <ul style="list-style-type: none">• IMAP• IMAPS• POP3• POP3S• SMTP• SMTPS• HTTP• HTTPS• Email_Admin

Select *OK*.

Enter the following CLI command:

```
config firewall service group
  edit Cust_Email_Serv_Template
    set member "IMAP" "IMAPS" "POP3" "POP3S" "SMTP" "SMTPS" "HTTP"
      "HTTPS" "Email_Admin"
  next
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Service > Groups*. Check that the service group has been added to the services list and that it is correct.

Enter the following CLI command:

```
config firewall service group
  edit <the name of the service that you wish to verify>
    show full-configuration
```

Virtual IP address

The company has an web server on the internal network that needs to be accessed from the Internet.

- The internal IP address is 192.168.50.37
- The external IP address is 256.85.94.60 (for example use only. Not a valid IP address)
- The external IP address is assigned by ISP "A" on WAN1
- The port that needs to be mapped is 80

Go to Firewall *Objects* > *Virtual IP*> *Virtual IP* and select *Create New*.

Fill out the fields with the following information.

Field	Value
Name	Web1-VIP
Comments	Virtual IP for the Forum Webserver
Color	<optional>
External Interface	wan1
Type	(This field is only changeable in the CLI
Source Address Filter	<leave blank or default setting>
External IP Address/Range	256.85.94.60
Mapped IP Address/Range	192.168.50.37
Port Forward	enabled
Protocol	TCP
External Service Port	80
Map to Port	80

Select *OK*.

Enter the following CLI command:

```
config firewall vip
  edit Web1-VIP
    set comment "Virtual IP for the Forum Webserver"
    set extintf wan1
    set extip 256.85.94.60
    set mappedip 192.168.50.37
    set portforward enable
    set protocol tcp
    set extport 80
    set mapped port 80
  end
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Virtual IP > Virtual IP*. Check that the virtual IP address has been added to the list and that it is correct.

Enter the following CLI command:

```
config firewall vip
  edit <the name of the vip that you wish to verify>
    show full-configuration
```

VIP Group

The company has only a single external IP address but multiple servers with different functions running on its internal LAN that need to be accessed from the Internet.

- The external IP address of the company on wan1 is 256.34.56.149 (for example use only. Not a valid IP address)
- The webserver is on the internal LAN on 192.168.100.86
- The webserver needs to answer on ports 80 443
- The administration of the FortiGate firewall connects on port 4443 instead of 443
- There is are also a separate email server, FTP server, and Terminal Server for specialised applications.
- 2 Virtual IPs have been created to map 256.34.56.149 to 192.168.100.86 on ports 80 and 443. The names are webserver_80 and webserver_443 respectively.

Go to *Firewall Objects > Virtual IP > Virtual IP* and select *Create New*.

Fill out the fields with the following information.

Field	Value
Group Name	WebServer_Grp
Comments	(Optional)
Color	(Optional)
Interface	wan1

Move the Following “Available VIPs:” to the “Members” field:

- “webserver_80”
- “webserver_443”

Enter the following CLI command:

```
config firewall vipgrp
  edit WebServer_Grp
    set member "webserver_80" "webserver_443"
  next
end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Virtual IP > Group*. Check that the virtual IP address group has been added to the list and that it is correct.

Enter the following CLI command:

```
config firewall vipgrp
  edit <the name of the vip that you wish to verify>
    show full-configuration
```

IP Pool

Your company has an application server on the internal network that sends out regular data updates to an offsite service. In order to make the service site more secure, they only accept connections from predefined IP address. If the external IP address of the FortiGate firewall interface were used that would mean that the service would be accepting sessions from just about any user in the network so a separate IP address need so be assigned for the Network Address Translation.

- The external address that will be used is one that has been assigned to the company by the ISP on WAN2
- The address is 256.100.42.129 (for example use only. Not a valid IP address)

Note: the ARP interface cannot be set in the Web-based Manager but as this is the only path that the traffic will be coming from the outside this should not be an issue. The setting has been included in the CLI instructions so that you will now how to set it in a situation where you want the ARP replies to be answered only on a specific interface.

Go to *Firewall Objects > Virtual IP > IP Pools*

Fill out the fields with the following information:

Field	Value
Name	App_Server1
Comments	Addresses assignment for this server only.
Type	One-to-One
External IP Range/Subnet2	256.100.42.129
ARP Reply	enabled

Select *OK*

Enter the following CLI command:

```
config firewall ippool
  edit App_Server1
    set comments "Addresses assignment for this server only."
    set type one-to-one
    set arp-reply enable
    set arp-intf wan2
    set startip 256.100.42.129
    set endip 256.100.42.129
  end
```

To verify that the category was added correctly:

Go to *Firewall Objects > Virtual IP > IP Pools*

Check that the IP Pool has been added to the list of IP Pools and that the listed settings are correct.

Enter the following CLI command:

```
config firewall ippool
  edit <the name of the IP Pool you wish to verify>
    show full-configuration
```

Central NAT Table

The company has a server on the Development LAN that needs to communicate with a server at a remote site over the Internet. One of the restrictions on the communications between these systems is that the IP address and source port must be specific.

- The traffic going out on to the Internet must be NATed
- The traffic is coming from a server with the IP address 192.168.150.86
- An address called "app-server" has been created for the address 192.168.150.86 on the port1 interface
- The external interface must be 256.23.45.67
- An address called "app-server-ext" has been created for the address 256.23.45.67 on the wan1 interface
- The originating traffic from the server originates in the port range from 2000 to 3000
- The remote site requires that the source TCP port must be within the 12000 to 13000 range

The original address and Translated Address fields require values that are address names that are listed in the address section of Firewall Objects.

Go to *Policy > Policy > Central NAT Table*.

Create a new NAT table

Fill out the fields with the following information:

Field	Value
Source Address	app-server
Translated Address	app-server-ext
Original Source Port	2000
Translated Port	12000-13000

Select *OK*

Enter the following CLI command:

```
config firewall central-nat
  edit 0
    set orig-addr app-server
    set nat-ippool app-server-ext
    set orig-port 2000
    set nat-port 12000-13000
  next
end
```

To verify that the table was added correctly:

Go to *Policy > Policy > Central NAT Table*

Check that the table has been added to the list of Central NAT Tables and that the listed settings are correct.

Enter the following CLI command:

```
config firewall central-nat
  show full-configuration
```

Verify that the listing of tables includes the one that you have just configured, with the correct settings.



When configuring the Central NAT in the GUI you may notice that only those addresses which have been configured to be associated with *any* interface are displayed in the drop down menu for choosing a Source Address and yet the CLI will allow any address to be used, not just those associated with *any* interface. This is because by default the policies in the GUI use a function of cross referencing which addresses are allowed based on which interface is involved in the policy. When combined with the aspect of Central NAT that doesn't restrict to a specific interface. This means the only addresses will be allowed are those associated with the *any* interface. The CLI does not have this cross referencing function which is why the CLI seems less restrictive. However, more care must be taken when using the CLI to make sure that appropriate addresses are used.

Firewall Schedule - Recurring

The Company wants to allow the use of Facebook by employees, but only during none business hours and the lunch break.

- The business hours are 9:00 p.m. to 6:00 p.m.
- The Lunch break is 12:00 p.m. to 1:00 p.m.
- The plan is to create a schedule to cover the morning business hours and the afternoon business hours and block access to the Facebook web site during that time.

Go to *Firewall Objects > Schedule > IP Recurring*.

Create a new schedule

Fill out the fields with the following information:

Select *OK*

Enter the following CLI command:

```
config firewall schedule recurring
edit Morning_Business_Hours
set day monday tuesday wednesday thursday friday
set start 09:00
set end 12:00
end
```

Create a second new schedule.

Field	Value
Name	Afternoon_Business_Hours
Day of the Week	
Sunday	disabled
Monday	enabled
Tuesday	enabled
Wednesday	enabled
Thursday	enabled

Field	Value
Friday	enabled
Saturday	disabled
Start Time: Hour:	13
Minute:	00
Stop Time: Hour:	18
Minute:	00

Select *OK*

Enter the following CLI command:

```
config firewall schedule recurring
edit Afternoon_Business_Hours
set day monday tuesday wednesday thursday friday
set start 13:00
set end 18:00
end
```

To verify that the schedule was added correctly:

Go to *Firewall Objects > Schedule > Recurring*

Check that the schedule with the name you used has been added to the list of recurring schedules and that the listed settings are correct.

Enter the following CLI command:

```
config firewall schedule recurring
edit <the name of the schedule you wish to verify>
show full-configuration
```

Firewall Schedule - One-time

The company wants to change over their web site image to reference the new year. They have decided to take this opportunity to do some hardware upgrades as well. Their web site is business oriented so they have determined that over New Year's Eve there will be very limited traffic.

- They are going to need a maintenance window of 2 hours bracketing midnight on New Year's Eve.

Go to *Firewall Objects > Schedule > One-time*.

Create a new schedule

Fill out the fields with the following information:

	Year	Month	Day	Hour	Minute
Start	2012	12	31	23	00
Stop	2013	1	1	1	00

Select *OK*

Enter the following CLI command:

```
config firewall schedule onetime
  edit maintenance_window
    set start 23:00 2012/12/31
    set end 01:00 2013/01/01
  next
end
```

To verify that the schedule was added correctly:

Go to *Firewall Objects > Schedule > One-time*

Check that the schedule with the name you used has been added to the list of recurring schedules and that the listed settings are correct.

Enter the following CLI command:

```
config firewall schedule onetime
  edit <the name of the schedule you wish to verify>
  show full-configuration
```

Schedule Group

In order to make the administration of the policies easier a group needs to be created.

Go to *Firewall Objects > Schedule > Groups*.

Create a new group

Fill out the fields with the following information:

Field	Value
Group Name	Business_Hours
Available Schedules	Morning_Business_Hours Afternoon_Business_Hours

Use arrows to move schedules from the “Members” field to the “Available Schedules:” field

Select *OK*

Enter the following CLI command:

```
config firewall service group
  edit Business_Hours
    set member Morning_Business_Hours Afternoon_Business _ours
  end
```

To verify that the schedule was added correctly:

Go to *Firewall Objects > Schedule > Groups*

Check that the schedule group with the name you used has been added to the list of schedule groups.

Enter the following CLI command:

```
config firewall service group
  edit <the name of the schedule group you wish to verify>
    show full-configuration
```

Proxy Option

The company will be using a number of the Security Profiles features on various policies but wants to use as few profiles as possible to make administration simpler. The decision has been made to have two profiles, the default one and a single customized one that will be a combination of the settings required to cover the situations that will not be covered by the default profile.

The company profile will have the following parameters:

- There are no FTP servers running on the site so there is no need for FTP.
- The company will use the Fortinet supplied default certificate called “Fortinet_CA_SSLProxy”
- The company will only be doing inspecting of SSL over HTTP, SMTP and IMAP.
- The company has a non-standard IMAP implementation the uses ports 1143 and 1993 for IMAP and IMAPS respectively.
- Deep Scanning is to be enabled on any SSL traffic regardless of port and the traffic logged but nothing is blocked.
- The Comfort Clients is to be used with a ratio of 1 byte for every 15 seconds.
- There is a lot of varied email traffic so there is to be no blocking of emails due to size beyond the settings on the mail servers.
- The Security Officer insists that invalid SSL certificates not be allowed.

Go to Policy > Policy > Proxy Options

Create a new profile

Fill out the fields with the following information:

Field	Value
Name	example_standard
Comments	<optional>

Protocol Port Mapping:

Enable	Protocol	Inspection Ports
enabled	HTTP	Specify and <leave on default setting.>
enabled	SMTP	Specify and <leave on default setting.>
enabled	POP3	Specify and <leave on default setting.>
enabled	IMAP	Specify and 1143
not enabled	FTP	
enabled	NNTP	Specify and <leave on default setting.>

Enable	Protocol	Inspection Ports
enabled	MAPI	<leave on default setting.>
enabled	DNS	<leave on default setting.>

SSL Inspection Options

CA Certificate: "Fortinet_CA_SSLProxy" from drop down menu

Inspect All Ports: Not enabled

Enable	Protocol	Inspection Port(s)
enabled	HTTPS	<leave as default>
enabled	SMTPS	<leave as default>
enabled	POP3S	<leave as default>
enabled	IMAPS	1993
	FTPS	

SSH Inspection Options

Enable SSH Deep Scan: enabled

Protocol	Inspection Ports
SSH	Any
Exec	Block: not enabled Log: enabled
Port-Forward	Block: not enabled Log: enabled
SSH-Shell	Block: not enabled Log: enabled
x11-Filter	Block: not enabled Log: enabled

Common Options

Field	Value
Comfort Clients	enabled
• Interval (Seconds)	15
• Amount(bytes)	1
Block Oversized File/Email	not enabled
• Threshold(MB)	not enabled
Allow Invalid SSL Certificates	not enabled

Web Options

Field	Value
Enabled Chunked Bypass	not enabled
Add Fortinet Bar	not enabled
• Communication Port	<leave as default>

Email Options

Field	Value
Allow Fragmented Messages	not enabled
Append Signature (SMTP)	not enabled
Email Signature Text	not enabled

Select OK

Enter the following CLI command:

```
config firewall profile-protocol-options
edit example_standard
config http
set options clientcomfort no-content-summary
set comfort-interval 15
next
config https
set status enable
set options clientcomfort no-content-summary
set comfort-interval 15
next
config ftp
set status disable
set options clientcomfort no-content-summary splice
set comfort-interval 15
next
config ftps
set options clientcomfort no-content-summary splice
set comfort-interval 15
next
config imap
set ports "1143"
set options fragmail no-content-summary
next
config imaps
set ports "1993"
set status enable
set options fragmail no-content-summary
next
config mapi
set options fragmail no-content-summary
next
config pop3
set options fragmail no-content-summary
next
config pop3s
set status enable
set options fragmail no-content-summary
next
config smtp
set options fragmail no-content-summary splice
next
config smtps
set status enable
set options fragmail no-content-summary splice
next
```

```
config nntp
  set options no-content-summary splice
  next
config ssh
  set inspect-all enable
  set log x11-filter ssh-shell exec port-forward
  next
end
```

Oversized Files

A couple of variations on the example could have to do with the processing of oversized files at a level other than the default setting. The ways that it can be approached are:

1. Set a non default threshold size and block the files
2. Set a non default threshold size and not scan the files over the threshold but allow them to pass through the FortiGate firewall.

In the following instructions:

- We will just use 2 MB as the new threshold.
- In the CLI instructions we will limit the configuration to just the HTTP settings for the purposes of brevity and simplicity.

Option 1

Option 1 can be done in the GUI.

Go to Policy > Policy > Proxy Options

Create a new profile

Fill out the fields with the following information:

Common Options

Field	Value
Comfort Clients	enabled
• Interval (Seconds)	15
• Amount(bytes)	1
Block Oversized File/Email	enabled
• Threshold(MB)	2
Allow Invalid SSL Certificates	not enabled

Select *OK*

Enter the following CLI command:

```
config firewall profile-protocol-options
  edit example_standard
    config http
      set options clientcomfort no-content-summary oversize
      set oversize-limit 2
      set comfort-interval 15
    next
  end
```

Option 2

Option 2 can only be done in the CLI.

Enter the following CLI command:

```
config firewall profile-protocol-options
  edit example_standard
    config http
      set options clientcomfort no-content-summary
      set oversize-limit 2
      set comfort-interval 15
    next
  end
```

Firewall Address Policy

A policy must be created to all traffic from one of the subnets off of the FortiGate out to the Internet.

- The traffic needs to be NATed
- The Internal subnet that needs to be connected is connected to port 1
- The subnet is from 192.168.1.1 to 192.168.1.255
- There is a user defined address for this subnet named “lan_192.168.1.x”
- The policy is for general Internet access over wan1.
- The IT manager would like to keep an eye on the kinds of sites that users are going to so for the time being even allowed traffic will be logged.
- To prevent the spread of malware even the outgoing traffic will be screened for viruses using the “basic_outgoing_av” profile that has already been defined by the IT Manager.
- There is no schedule restriction on access to the Internet so the schedule is the predefined “always”.
- There is no restrictions yet on what protocols are allowed so the predefines services should be used.
- In order to prevent any HR issues a webfilter has been defined by the IT manager that blocks access to inappropriate sites. The profile is called “basic_web_filter”

Go to *Policy > Policy > Policy*.

Create a new policy

Fill out the fields with the following information:

Field	Value
Policy Type	Firewall
Policy Subtype	Address
Incoming Interface	port1
Source Address	lan_192.168.1.x
Outgoing Interface	wan1
Destination Address	all
Schedule	always
Service	ALL
Action	Accept
Enable NAT	enable
Use Destination Interface Address	enable
Log Allowed Traffic	enable
Enable WebCache	not enabled
Enable WAN Optimization	not enabled
Traffic Shaping	enabled

Security Profiles

Security Profiles	Status	Profile Name
AntiVirus	ON	basic_outgoing_av
Web Filter	ON	basic_web_filter
Application Control	OFF	(option should be greyed out)
IPS	OFF	(option should be greyed out)
Email Filter	OFF	(option should be greyed out)
DLP Sensor	OFF	(option should be greyed out)
VoIP	OFF	(option should be greyed out)
ICAP	OFF	(option should be greyed out)

Select **OK**

Enter the following CLI command:

```
config firewall policy
  edit 0
    set srcintf port1
    set dstintf wan1
    set srcaddr an_192.168.1.x
    set dstaddr "all"
    set action accept
    set schedule always
    set service ALL
    set logtraffic enable
    set nat enable
    set natip 0.0.0.0 0.0.0.0
    set utm-status enable
    set av-profile basic_outgoing_av
    set webfilter-profile basic_web_filter
  next
end
```

Firewall User Identity Policy

There is a Server on the Internal LAN that is used as a resource by sales people that are out on the road and at home. The sales people and their administrator are the only ones that are allowed access to the server "SalesServer". Because of the importance of the data on the server it needs to be backed up on a regular bases and to make sure that all of the files are available for backup no one is allowed access during the scheduled backup time.

- Firewall User Group has been created: "sales". This is a group defined for more than one purpose.
- Firewall User has been created: "jsmith", who is the administrator. "jsmith" is not a member of the sales group and can't be placed in it because of other resources that the group has access to.
- A Virtual IP has been defined for the server "SalesServer" mapped from an external address to an internal address on port9. Port forwarding is enabled on TCP port 443 for the application that the sales people use.
- The schedule "Non-Maintenance_Window" has been created (between 2 a.m. and 3 a.m.) by starting the window at 3:00 and stopping at 2:00 (If the stop time is set earlier than the start time, the stop time will be during the next day).
- Because there is access from the Internet to the internal network the company's HTTPS Server IPS profile, called "Protect_HTTPS_Server" will be enabled.

Go to *Policy > Policy > Policy*.

Create a new policy

Fill out the fields with the following information:

Field	Value
Policy Type	Firewall
Policy Subtype	User Identity

Field	Value
Incoming Interface	wan1
Source Address	all
Outgoing Interface	port9
Enable NAT	not enabled
Enable Web cache	not enabled
Enable WAN Optimization	not enabled
Certificate	No Certificate
Firewall	enabled
Fortinet Single Sign-On	not enabled
WiFi Single Sign-on	not enabled
NTLM Authentications	not enabled
Customize Authentication Messages	(optional)
Add tag	(optional)
Comments	(optional)

In the Configure Authentication Rules section, create a new Authentication rule by filling out the fields with the following information.

Field	Value
Destination Address	SalesServer (virtual IP address)
Group(s)	sales
User(s)	jsmith
Schedule	Non-Maintenance_Window
Service	HTTPS
Action	(automatically assigned value of "ACCEPT")
Log Allowed Traffic	(optional)
Traffic Shaping	(optional)

In the Security Profiles Section:

Enable and select the security profiles as follows:

Security Profiles	Status	Profile Name
AntiVirus	OFF	(option should be greyed out)
Web Filter	OFF	(option should be greyed out)
Application Control	OFF	(option should be greyed out)
IPS	ON	Protect_HTTPS_Server
Email Filter	OFF	(option should be greyed out)
DLP Sensor	OFF	(option should be greyed out)
VoIP	OFF	(option should be greyed out)
ICAP	OFF	(option should be greyed out)

Select *OK*

Enter the following CLI command:

```
config firewall policy
  edit 0
    set srcintf "wan1"
    set dstintf "port9"
    set srcaddr "all"
    set action accept
    set identity-based enable
    config identity-based-policy
      edit 1
        set schedule "Non-Maintenance_Window"
        set utm-status enable
        set profile-type single
        set groups "sales"
        set users "jsmith"
        set dstaddr "SalesServer"
        set service "HTTPS"
        set ips-sensor "Protect_HTTPS_Server"
      next
    end
```

Firewall Device Identity Policy

The company is instituting a BYOD pilot project. They are going to be letting employee's personal devices connect through a wireless network. Most will only be allowed only to the Internet but some will have access to the Internal LAN.

- The wireless interface the users will be connecting on is "WiFi".
- The source address has been defined as the DHCP scope assigned to the wireless network, "Internal_wireless".
- The Internal Network is on the interface designated as "LAN"
- There is no need to NAT the traffic.
- The AntiVirus Profile to be used is "Internal-AV", already defined.
- The Application Profile to be used is "Internal-AC", already defined.
- The IPS Profile to be used is "Internal-IPS", already defined.
- The Device group for this policy is "IT_Personnel_phones".
- The IT team is a trusted group that will be accessing practically everything so the schedule will be the predefined "always" and the Service will be the predefined "ALL".
- While the IT team is trusted the company would like to verify that they are compliant with the Endpoint profile so the check for this must be enabled on the policy.

Go to *Policy > Policy > Policy*.

Create a new policy

Fill out the fields with the following information:

Field	Value
Policy Type	Firewall
Policy Subtype	Device Identity
Incoming Interface	wifi
Source Address	all
Outgoing Interface	port9
Enable NAT	not enabled
Customize Authentication Messages	(optional)
Add tag	(optional)
Comments	(optional)

In the Configure Authentication Rules section, create a new Authentication rule by filling out the fields with the following information.

Field	Value
Destination Address	Internal_Network
Device	IT_Personnel_Phones
Compliant with Endpoint Profile	enable
Schedule	always
Service	ALL
Action	(automatically assigned value of "ACCEPT")
Log Allowed Traffic	(optional)
Traffic Shaping	(optional)

In the Security Profile Section:

Enable and select the security profiles as follows:

Security Profiles	Status	Profile Name
AntiVirus	ON	Internal-AV
Web Filter	OFF	(option should be greyed out)
Application Control	ON	Internal-AC
IPS	ON	Internal-IPS
Email Filter	OFF	(option should be greyed out)
DLP Sensor	OFF	(option should be greyed out)
VoIP	OFF	(option should be greyed out)
ICAP	OFF	(option should be greyed out)

Select *OK*

Enter the following CLI command:

```
config firewall policy
  edit 0
    set srcintf "wifi"
    set dstintf "LAN"
    set srcaddr "Internal_wireless"
    set action accept
    set identity-based enable
    set identity-from device
    config identity-based-policy
      edit 1
        set schedule always
        set utm-status enable
        set dstaddr Internal_Network
        set service ALL
        set devices IT_Personnel_phones
        set endpoint-compliance enable
        set av-profile Internal-AV
        set ips-sensor Internal-IPS
        set application-list Internal-AC
      next
    end
```

DoS Policy

The company wishes to protect against Denial of Service attacks. They have chosen some where they wish to block the attacks if the incidence goes above a certain threshold and for some others they are just trying to get a baseline of activity for those types of attacks so they are letting the traffic pass through without action.

- The interface to the Internet is on WAN1
- There is no requirement to specify which addresses are being protected or protected from.
- The protection is to extend to all services.
- The TCP attacks are to be blocked
- The UDP, ICMP, and IP attacks are to be recorded but not blocked.
- The tcp_syn_flood attack's threshold is to be changed from the default to 1000

Go to *Policy > Policy > DoS Policy*.

Create a new policy

Fill out the fields with the following information:

Field	Value
Incoming Interface	wan1
Source Address	all

Field	Value
Destination Addresses	all
Service	ALL

Anomalies

Name	Status	Logging	Action	Threshold
tcp_syn_flood	enabled	enabled	Block	1000
tcp_port_scan	enabled	enabled	Block	<default value>
tcp_src_session	enabled	enabled	Block	<default value>
tcp_dst_session	enabled	enabled	Block	<default value>
udp_flood	enabled	enabled	Pass	<default value>
udp_scan	enabled	enabled	Pass	<default value>
udp_src_session	enabled	enabled	Pass	<default value>
udp_dst_session	enabled	enabled	Pass	<default value>
icmp_flood	enabled	enabled	Pass	<default value>
icmp_sweep	enabled	enabled	Pass	<default value>
icmp_src_session	enabled	enabled	Pass	<default value>
icmp_dst_session	enabled	enabled	Pass	<default value>
ip_src_session	enabled	enabled	Pass	<default value>
ip_dst_session	enabled	enabled	Pass	<default value>
sctp_flood	not enabled	not enabled	Pass	<default value>
sctp_scan	not enabled	not enabled	Pass	<default value>
sctp_src_session	not enabled	not enabled	Pass	<default value>
sctp_dst_session	not enabled	not enabled	Pass	<default value>

Select OK

Enter the following CLI command:

```
config firewall DoS-policy
edit 0
set status enable
set interface ''
config anomaly
edit "tcp_syn_flood"
set status enable
set log enable
set action block
set threshold 1000
next
edit "tcp_port_scan"
set status enable
set log enable
set action block
next
edit "tcp_src_session"
set status enable
set log enable
set action block
next
edit "tcp_dst_session"
set status enable
set log enable
set action block
next
edit "udp_flood"
set status enable
set log enable
next
edit "udp_scan"
set status disable
set status enable
set log enable
next
edit "udp_src_session"
set status enable
set log enable
next
edit "udp_dst_session"
set status enable
set log enable
next
edit "icmp_flood"
set status enable
set log enable
next
```

```
edit "icmp_sweep"  
    set status enable  
    set log enable  
next  
edit "icmp_src_session"  
    set status enable  
    set log enable  
next  
edit "icmp_dst_session"  
    set status enable  
    set log enable  
next  
edit "ip_src_session"  
    set status enable  
    set log enable  
next  
edit "ip_dst_session"  
    set status enable  
    set log enable  
next  
end  
next  
end
```

Multicast forwarding

Multicasting (also called IP multicasting) consists of using a single multicast source to send data to many receivers. Multicasting can be used to send data to many receivers simultaneously while conserving bandwidth and reducing network traffic. Multicasting can be used for one-way delivery of media streams to multiple receivers and for one-way data transmission for news feeds, financial information, and so on.

Also RIPv2 uses multicasting to share routing table information, OSPF uses multicasting to send hello packets and routing updates, Enhanced Interior Gateway Routing Protocol (EIGRP) uses multicasting to send routing information to all EIGRP routers on a network segment and the Bonjour network service uses multicasting for DNS.

A FortiGate unit can operate as a Protocol Independent Multicast (PIM) version 2 router. FortiGate units support PIM sparse mode (RFC 4601) and PIM dense mode (RFC 3973) and can service multicast servers or receivers on the network segment to which a FortiGate unit interface is connected. Multicast routing is not supported in transparent mode (TP mode).



To support PIM communications, the sending/receiving applications and all connecting PIM routers in between must be enabled with PIM version 2. PIM can use static routes, RIP, OSPF, or BGP to forward multicast packets to their destinations. To enable source-to-destination packet delivery, either sparse mode or dense mode must be enabled on the PIM-router interfaces. Sparse mode routers cannot send multicast messages to dense mode routers. In addition, if a FortiGate unit is located between a source and a PIM router, two PIM routers, or is connected directly to a receiver, you must create a security policy manually to pass encapsulated (multicast) packets or decapsulated data (IP traffic) between the source and destination.

A PIM domain is a logical area comprising a number of contiguous networks. The domain contains at least one Boot Strap Router (BSR), and if sparse mode is enabled, a number of Rendezvous Points (RPs) and Designated Routers (DRs). When PIM is enabled on a FortiGate unit, the FortiGate unit can perform any of these functions at any time as configured.

Sparse mode

Initially, all candidate BSRs in a PIM domain exchange bootstrap messages to select one BSR to which each RP sends the multicast address or addresses of the multicast group(s) that it can service. The selected BSR chooses one RP per multicast group and makes this information available to all of the PIM routers in the domain through bootstrap messages. PIM routers use the information to build packet distribution trees, which map each multicast group to a specific RP. Packet distribution trees may also contain information about the sources and receivers associated with particular multicast groups.



When a FortiGate unit interface is configured as a multicast interface, sparse mode is enabled on it by default to ensure that distribution trees are not built unless at least one downstream receiver requests multicast traffic from a specific source. If the sources of multicast traffic and their receivers are close to each other and the PIM domain contains a dense population of active receivers, you may choose to enable dense mode throughout the PIM domain instead.

An RP represents the root of a non-source-specific distribution tree to a multicast group. By joining and pruning the information contained in distribution trees, a single stream of multicast

packets (for example, a video feed) originating from the source can be forwarded to a certain RP to reach a multicast destination.

Each PIM router maintains a Multicast Routing Information Base (MRIB) that determines to which neighboring PIM router join and prune messages are sent. An MRIB contains reverse-path information that reveals the path of a multicast packet from its source to the PIM router that maintains the MRIB.

To send multicast traffic, a server application sends IP traffic to a multicast group address. The locally elected DR registers the sender with the RP that is associated with the target multicast group. The RP uses its MRIB to forward a single stream of IP packets from the source to the members of the multicast group. The IP packets are replicated only when necessary to distribute the data to branches of the RP's distribution tree.

To receive multicast traffic, a client application can use Internet Group Management Protocol (IGMP) version 1 (RFC 1112), 2 (RFC 2236), or 3 (RFC 3376) control messages to request the traffic for a particular multicast group. The locally elected DR receives the request and adds the host to the multicast group that is associated with the connected network segment by sending a join message towards the RP for the group. Afterward, the DR queries the hosts on the connected network segment continually to determine whether the hosts are active. When the DR no longer receives confirmation that at least one member of the multicast group is still active, the DR sends a prune message towards the RP for the group.

FortiOS supports PIM sparse mode multicast routing for IPv6 multicast (multicast6) traffic and is compliant with RFC 4601: Protocol Independent Multicast - Sparse Mode (PIM-SM). You can use the following command to configure IPv6 PIM sparse multicast routing.

```
config router multicast6
    set multicast-routing {enable | disable}
    config interface
        edit <interface-name>
            set hello-interval <1-65535 seconds>
            set hello-holdtime <1-65535 seconds>
        end
    config pim-sm-global
        config rp-address
            edit <index>
                set ipv6-address <ipv6-address>
            end
```

The following diagnose commands for IPv6 PIM sparse mode are also available:

```
diagnose ipv6 multicast status
diagnose ipv6 multicast vif
diagnose ipv6 multicast mroute
```

Dense mode

The packet organization used in sparse mode is also used in dense mode. When a multicast source begins to send IP traffic and dense mode is enabled, the closest PIM router registers the IP traffic from the multicast source (S) and forwards multicast packets to the multicast group address (G). All PIM routers initially broadcast the multicast packets throughout the PIM domain to ensure that all receivers that have requested traffic for multicast group address G can access the information if needed.

To forward multicast packets to specific destinations afterward, the PIM routers build distribution trees based on the information in multicast packets. Upstream PIM routers depend

on prune/graft messages from downstream PIM routers to determine if receivers are actually present on directly connected network segments. The PIM routers exchange state refresh messages to update their distribution trees. FortiGate units store this state information in a Tree Information Base (TIB), which is used to build a multicast forwarding table. The information in the multicast forwarding table determines whether packets are forwarded downstream. The forwarding table is updated whenever the TIB is modified.

PIM routers receive data streams every few minutes and update their forwarding tables using the source (S) and multicast group (G) information in the data stream. Superfluous multicast traffic is stopped by PIM routers that do not have downstream receivers—PIM routers that do not manage multicast groups send prune messages to the upstream PIM routers. When a receiver requests traffic for multicast address G, the closest PIM router sends a graft message upstream to begin receiving multicast packets.

FortiGate units operating in NAT mode can also be configured as multicast routers. You can configure a FortiGate unit to be a Protocol Independent Multicast (PIM) router operating in Sparse Mode (SM) or Dense Mode (DM).

Multicast IP addresses

Multicast uses the Class D address space. The 224.0.0.0 to 239.255.255.255 IP address range is reserved for multicast groups. The multicast address range applies to multicast groups, not to the originators of multicast packets. [Table 9](#) lists reserved multicast address ranges and describes what they are reserved for:

Table 9: Reserved Multicast address ranges

Reserved Address Range	Use	Notes
224.0.0.0 to 224.0.0.255	Used for network protocols on local networks. For more information, see RFC 1700.	In this range, packets are not forwarded by the router but remain on the local network. They have a Time to Live (TTL) of 1. These addresses are used for communicating routing information.
224.0.1.0 to 238.255.255.255	Global addresses used for multicasting data between organizations and across the Internet. For more information, see RFC 1700.	Some of these addresses are reserved, for example, 224.0.1.1 is used for Network Time Protocol (NTP).
239.0.0.0 to 239.255.255.255	Limited scope addresses used for local groups and organizations. For more information, see RFC 2365.	Routers are configured with filters to prevent multicasts to these addresses from leaving the local system.

Creating multicast security policies requires multicast firewall addresses. You can add multicast firewall addresses by going to *Firewall Objects > Address > Addresses* and selecting *Create New > Multicast Address*. The factory default configuration includes multicast addresses for Bonjour(224.0.0.251-224.0.0.251, EIGRP (224.0.0.10-224.0.0.100), OSPF (224.0.0.5-224.0.0.60), all_hosts (224.0.0.1-224.0.0.1), and all_routers (224.0.0.2-224.0.0.2).

PIM Support

A FortiGate unit can be configured to support PIM by going to *Router > Dynamic > Multicast* and enabling multicast routing. You can also enable multicast routing using the `config router multicast` CLI command. When PIM is enabled, the FortiGate unit allocates memory to manage mapping information. The FortiGate unit communicates with neighboring PIM routers to acquire mapping information and if required, processes the multicast traffic associated with specific multicast groups.



The end-user multicast client-server applications must be installed and configured to initiate Internet connections and handle broadband content such as audio/video information.

Client applications send multicast data by registering IP traffic with a PIM-enabled router. An end-user could type in a class D multicast group address, an alias for the multicast group address, or a call-conference number to initiate the session.

Rather than sending multiple copies of generated IP traffic to more than one specific IP destination address, PIM-enabled routers encapsulate the data and use the one multicast group address to forward multicast packets to multiple destinations. Because one destination address is used, a single stream of data can be sent. Client applications receive multicast data by requesting that the traffic destined for a certain multicast group address be delivered to them — end-users may use phone books, a menu of ongoing or future sessions, or some other method through a user interface to select the address of interest.

A class D address in the 224.0.0.0 to 239.255.255.255 range may be used as a multicast group address, subject to the rules assigned by the Internet Assigned Numbers Authority (IANA). All class D addresses must be assigned in advance. Because there is no way to determine in advance if a certain multicast group address is in use, collisions may occur (to resolve this problem, end-users may switch to a different multicast address).

To configure a PIM domain

1. If you will be using sparse mode, determine appropriate paths for multicast packets.
2. Make a note of the interfaces that will be PIM-enabled. These interfaces may run a unicast routing protocol.
3. If you will be using sparse mode and want multicast packets to be handled by specific (static) RPs, record the IP addresses of the PIM-enabled interfaces on those RPs.
4. Enable PIM version 2 on all participating routers between the source and receivers. On FortiGate units, use the `config router multicast` command to set global operating parameters.
5. Configure the PIM routers that have good connections throughout the PIM domain to be candidate BSRs.
6. If sparse mode is enabled, configure one or more of the PIM routers to be candidate RPs.
7. If required, adjust the default settings of PIM-enabled interface(s).

Multicast forwarding and FortiGate units

In both transparent mode and NAT mode you can configure FortiGate units to forward multicast traffic.

For a FortiGate unit to forward multicast traffic you must add FortiGate multicast security policies. Basic multicast security policies accept any multicast packets at one FortiGate

interface and forward the packets out another FortiGate interface. You can also use multicast security policies to be selective about the multicast traffic that is accepted based on source and destination address, and to perform NAT on multicast packets.

In the example shown in [Figure 6](#), a multicast source on the Marketing network with IP address 192.168.5.18 sends multicast packets to the members of network 239.168.4.0. At the FortiGate unit, the source IP address for multicast packets originating from workstation 192.168.5.18 is translated to 192.168.18.10. In this example, the FortiGate unit is not acting as a multicast router.


Multicast forwarding and RIPv2

RIPv2 uses multicast to share routing table information. If your FortiGate unit is installed on a network that includes RIPv2 routers, you must configure the FortiGate unit to forward multicast packets so that RIPv2 devices can share routing data through the FortiGate unit. No special FortiGate configuration is required to share RIPv2 data, you can simply use the information in the following sections to configure the FortiGate unit to forward multicast packets.



RIPv1 uses broadcasting to share routing table information. To allow RIPv1 packets through a FortiGate unit you can add standard security policies. Security policies to accept RIPv1 packets can use the ANY predefined firewall service or the RIP predefined firewall service.

Figure 6: Example multicast network including a FortiGate unit that forwards multicast packets



Configuring FortiGate multicast forwarding

You configure FortiGate multicast forwarding from the Command Line Interface (CLI). Two steps are required:

- Adding multicast security policies
- Enabling multicast forwarding

This second step is only required if your FortiGate unit is operating in NAT mode. If your FortiGate unit is operating in transparent mode, adding a multicast policy enables multicast forwarding.



There is sometimes a confusion between the terms “forwarding” and “routing”. These two functions should not be taking place at the same time.

It is mentioned that multicast-forward should be enabled when the FortiGate unit is in NAT mode and that this will forward any multicast packet to all interfaces. However, this parameter should **NOT** be enabled when the FortiGate unit operates as a multicast router (i.e. with a routing protocol enabled). It should only be enabled when there is no routing protocols activated.

Adding multicast security policies

You need to add security policies to allow packets to pass from one interface to another. Multicast packets require multicast security policies. You add multicast security policies from the CLI using the `config firewall multicast-policy` command. As with unicast security policies, you specify the source and destination interfaces and optionally the allowed address ranges for the source and destination addresses of the packets.

You can also use multicast security policies to configure source NAT and destination NAT for multicast packets.

Keep the following in mind when configuring multicast security policies:

- The matched forwarded (outgoing) IP multicast source IP address is changed to the configured IP address.
- Source and Destination interfaces are optional. If left blank, then the multicast will be forwarded to ALL interfaces.
- Source and Destination addresses are optional. If left un set, then it will mean ALL addresses.
- The `nat` keyword is optional. Use it when source address translation is needed.

Enabling multicast forwarding

Multicast forwarding is enabled by default. In NAT mode you must use the `multicast-forward` keyword of the `system settings` CLI command to enable or disable multicast forwarding. When `multicast-forward` is enabled, the FortiGate unit forwards any multicast IP packets in which the TTL is 2 or higher to all interfaces and VLAN interfaces except the receiving interface. The TTL in the IP header will be reduced by 1. Even though the multicast packets are forwarded to all interfaces, you must add security policies to actually allow multicast packets through the FortiGate. In our example, the security policy allows multicast packets received by the internal interface to exit to the external interface.



Enabling multicast forwarding is only required if your FortiGate unit is operating in NAT mode. If your FortiGate unit is operating in transparent mode, adding a multicast policy enables multicast forwarding.

Enter the following CLI command to enable multicast forwarding:

```
config system settings
    set multicast-forward enable
end
```

If multicast forwarding is disabled and the FortiGate unit drops packets that have multicast source or destination addresses.

You can also use the `multicast-ttl-notchange` keyword of the `system settings` command so that the FortiGate unit does not increase the TTL value for forwarded multicast packets. You should use this option only if packets are expiring before reaching the multicast router.

```
config system settings
    set multicast-ttl-notchange enable
end
```

In transparent mode, the FortiGate unit does not forward frames with multicast destination addresses. Multicast traffic such as the one used by routing protocols or streaming media may need to traverse the FortiGate unit, and should not be interfere with the communication. To

avoid any issues during transmission, you can set up multicast security policies. These types of security policies can only be enabled using the CLI.



The CLI parameter `multicast-skip-policy` must be disabled when using multicast security policies. To disable enter the command

```
config system settings
    set multicast-skip-policy disable
end
```

In this simple example, no check is performed on the source or destination interfaces. A multicast packet received on an interface is flooded unconditionally to all interfaces on the forwarding domain, except the incoming interface.

To enable the multicast policy

```
config firewall multicast-policy
    edit 1
        set action accept
    end
```

In this example, the multicast policy only applies to the source port of WAN1 and the destination port of Internal.

To enable the restrictive multicast policy

```
config firewall multicast-policy
    edit 1
        set srcintf wan1
        set dstintf internal
        set action accept
    end
```

In this example, packets are allowed to flow from WAN1 to Internal, and sourced by the address 172.20.120.129.

To enable the restrictive multicast policy

```
config firewall multicast-policy
    edit 1
        set srcintf wan1
        set srcaddr 172.20.120.129 255.255.255.255
        set dstintf internal
        set action accept
    end
```

This example shows how to configure the multicast security policy required for the configuration shown in [Figure 6 on page 156](#). This policy accepts multicast packets that are sent from a PC with IP address 192.168.5.18 to destination address range 239.168.4.0. The policy allows the

multicast packets to enter the internal interface and then exit the external interface. When the packets leave the external interface their source address is translated to 192.168.18.10

```
config firewall multicast-policy
  edit 5
    set srcaddr 192.168.5.18 255.255.255.255
    set srcintf internal
    set destaddr 239.168.4.0 255.255.255.0
    set dstintf external
    set nat 192.168.18.10
  end
```

This example shows how to configure a multicast security policy so that the FortiGate unit forwards multicast packets from a multicast Server with an IP 10.10.10.10 is broadcasting to address 225.1.1.1. This Server is on the network connected to the FortiGate DMZ interface.

```
config firewall multicast-policy
  edit 1
    set srcintf DMZ
    set srcaddr 10.10.10.10 255.255.255.255
    set dstintf Internal
    set dstaddr 225.1.1.1 255.255.255.255
    set action accept
  edit 2
    set action deny
  end
```

Multicast routing examples


This section contains the following multicast routing configuration examples and information:

- [Example FortiGate PIM-SM configuration using a static RP](#)
- [FortiGate PIM-SM debugging examples](#)
- [Example multicast destination NAT \(DNAT\) configuration](#)
- [Example PIM configuration that uses BSR to find the RP](#)

Example FortiGate PIM-SM configuration using a static RP

The example Protocol Independent Multicast Sparse Mode (PIM-SM) configuration shown in [Figure 7](#) has been tested for multicast interoperability using PIM-SM between Cisco 3750 switches running 12.2 and a FortiGate-800 running FortiOS v3.0 MR5 patch 1. In this configuration, the receiver receives the multicast stream when it joins the group 233.254.200.1.

Figure 7: Example FortiGate PIM-SM topology



The configuration uses a statically configured rendezvous point (RP) which resides on the Cisco_3750_1. Using a bootstrap router (BSR) was not tested in this example. See [“Example PIM configuration that uses BSR to find the RP”](#) on page 176 for an example that uses a BSR.

Configuration steps

The following procedures show how to configure the multicast configuration settings for the devices in the example configuration.

- Cisco_3750_1 router configuration
- Cisco_3750_2 router configuration
- To configure the FortiGate-800 unit
- Cisco_3750_3 router configuration

Cisco_3750_1 router configuration

```
version 12.2
!
hostname Cisco-3750-1
!
switch 1 provision ws-c3750-24ts
ip subnet-zero
ip routing
!
ip multicast-routing distributed
!
spanning-tree mode pvst
no spanning-tree optimize bpdu transmission
spanning-tree extend system-id
!
interface Loopback0
    ip address 169.254.100.1 255.255.255.255
!
interface FastEthernet1/0/23
    switchport access vlan 182
    switchport mode access
!
interface FastEthernet1/0/24
    switchport access vlan 172
    switchport mode access
!
interface Vlan172
    ip address 10.31.138.1 255.255.255.0
    ip pim sparse-mode
    ip igmp query-interval 125
    ip mroute-cache distributed
!
interface Vlan182
    ip address 169.254.82.250 255.255.255.0
    ip pim sparse-mode
    ip mroute-cache distributed
!
ip classless
ip route 0.0.0.0 0.0.0.0 169.254.82.1
ip http server
ip pim rp-address 169.254.100.1 Source-RP
!
ip access-list standard Source-RP
    permit 233.254.200.0 0.0.0.255
```

Cisco_3750_2 router configuration

```
version 12.2
!
hostname Cisco-3750-2
!
switch 1 provision ws-c3750-24ts
ip subnet-zero
ip routing
!
ip multicast-routing distributed
!
spanning-tree mode pvst
no spanning-tree optimize bpdu transmission
spanning-tree extend system-id
!
interface FastEthernet1/0/23
    switchport access vlan 138
    switchport mode access
!
interface FastEthernet1/0/24
    switchport access vlan 182
    witchport mode access
!
interface Vlan138
    ip address 10.31.138.250 255.255.255.0
    ip pim sparse-mode
    ip mroute-cache distributed
!
interface Vlan182
    ip address 169.254.82.1 255.255.255.0
    ip pim sparse-mode
    ip mroute-cache distributed
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.31.138.253
ip route 169.254.100.1 255.255.255.255 169.254.82.250
ip http server
ip pim rp-address 169.254.100.1 Source-RP
!
!
ip access-list standard Source-RP
permit 233.254.200.0 0.0.0.255
```

To configure the FortiGate-800 unit

1. Configure the internal and external interfaces.

- **Internal**

Go to *System > Network > Interfaces*.

Select the internal interface

Verify the following settings:

Type:	Physical Interface
Addressing mode:	Manual
IP/Network Mask:	10.31.138.253 255.255.255.0
Administrative Access:	PING

Select *OK*

- **External**

Go to *System > Network > Interfaces*.

Select the external interface

Verify the following settings:

Type:	Physical Interface
Addressing mode:	Manual
IP/Network Mask:	10.31.130.253 255.255.255.0
Administrative Access:	HTTPS and PING

Select *OK*.

2. Add a firewall addresses.

Go to *Firewall Objects > Address > Addresses*.

- RP

Select *Create New*.

Use the following settings:

Category:	Address
Name:	RP
Type:	Subnet
Subnet/IP Range:	169.254.100.1/32
Interface:	Any

Select *OK*.

- Multicast source subnet

Select *Create New*.

Use the following settings:

Category:	Address
Name:	multicast_source_subnet
Type:	Subnet
Subnet/IP Range:	169.254.82.0/24
Interface:	Any

Select *OK*.

3. Add destination multicast address

Go to *Firewall Objects > Address > Addresses*.

Select *Create New*.

Use the following settings:

Category:	Multicast Address
Name:	Multicast_stream
Type:	Broadcast Subnet
Broadcast Subnet:	233.254.200.0/24
Interface:	Any

Select *OK*.

4. Add standard security policies to allow traffic to reach the RP.

Go to Policy > Policy > Policy

- 1st policy

Select *Create New*

Use the following settings:

Policy Type:	Firewall
Policy Subtype:	Address
Incoming Interfac:	internal
Source Address:	all
Outgoing Interface:	external
Destination Address:	RP
Schedule:	always
Service:	ALL
Action:	ACCEPT

Select *OK*.

- 2nd policy

Select *Create New*

Use the following settings:

Policy Type:	Firewall
Policy Subtype:	Address
Incoming Interfac:	external
Source Address:	RP
Outgoing Interface:	internal
Destination Address:	all
Schedule:	always
Service:	ALL
Action:	ACCEPT

Select *OK*.

5. Add the multicast security policy.
Go to Policy > Policy > Multicast Policy
Select *Create New*
Use the following settings:

Incoming Interface:	external
Source Address:	multicast_source_subnet
Outgoing Interface:	internal
Destination Address:	multicast_stream
Protocol:	Any
Action:	ACCEPT

Select *OK*.

6. Add an access list. (CLI only)

```
config router access-list
  edit Source-RP
    config rule
      edit 1
        set prefix 233.254.200.0 255.255.255.0
        set exact-match disable
      next
    end
```

7. Add some static routes.

Go to *Router > Static > Static Routes*.

- Route 1

Select *Create New*.

Use the following settings:

Destination IP/Mask:	0.0.0.0/0.0.0.0
Device:	internal
Gateway:	10.31.130.250

Select *OK*.

- Route 2

Select *Create New*.

Use the following settings:

Destination IP/Mask:	169.254.0.0/16
Device:	external
Gateway:	10.31.138.250

Select *OK*.

8. Configure multicast routing.

Go to *Router > Dynamic > Multicast*.

Add the following Static Rendezvous Point(s):

- 169.254.100.1
- Route 1

Select *Create New*.

Use the following settings:

Interface:	internal
PIM Mode:	Sparse Mode
DR Priority:	<not needed in this scenario>
RP Candidate:	<not needed in this scenario>
RP Candidate Priority:	<not needed in this scenario>

Select *OK*.

- Route 2

Select *Create New*.

Use the following settings:

Interface:	external
PIM Mode:	Sparse Mode
DR Priority:	
RP Candidate:	
RP Candidate Priority:	

Select *OK*.


Cisco_3750_3 router configuration

```
version 12.2
!
hostname Cisco-3750-3
!
switch 1 provision ws-c3750-24ts
ip subnet-zero
ip routing
!
ip multicast-routing distributed
!
spanning-tree mode pvst
no spanning-tree optimize bpdu transmission
spanning-tree extend system-id
!
interface FastEthernet1/0/23
    switchport access vlan 128
    switchport mode access
!
interface FastEthernet1/0/24
    switchport access vlan 130
    switchport mode access
!
interface Vlan128
    ip address 10.31.128.130 255.255.255.252
    ip pim sparse-mode
    ip mroute-cache distributed
!
interface Vlan130
    ip address 10.31.130.250 255.255.255.0
    ip pim sparse-mode
    ip mroute-cache distributed
!
ip classless
ip route 0.0.0.0 0.0.0.0 10.31.130.1
ip http server
ip pim rp-address 169.254.100.1 Source-RP
!
!
ip access-list standard Source-RP
    permit 233.254.200.0 0.0.0.255
```

FortiGate PIM-SM debugging examples

Using the example topology shown in [Figure 8](#) you can trace the multicast streams and states within the three FortiGate units (FGT-1, FGT-2, and FGT-3) using the debug commands described in this section. The command output in this section is taken from FortiGate unit when the multicast stream is flowing correctly from source to receiver.

Figure 8: PIM-SM debugging topology



Checking that the receiver has joined the required group

From the last hop router, FGT-3, you can use the following command to check that the receiver has correctly joined the required group.

```
FGT-3 # get router info multicast igmp groups
IGMP Connected Group Membership
Group Address      Interface          Uptime    Expires    Last Reporter
239.255.255.1     port3             00:31:15 00:04:02  10.167.0.62
```

Only 1 receiver is displayed for a particular group, this is the device that responded to the IGMP query request from the FGT-3. If a receiver is active the expire time should drop to approximately 2 minutes before being refreshed.

Checking the PIM-SM neighbors

Next the PIM-SM neighbors should be checked. A PIM router becomes a neighbor when the PIM router receives a PIM hello. Use the following command to display the PIM-SM neighbors of FGT-3.

```
FGT-3 # get router info multicast pim sparse-mode neighbour
Neighbor          Interface          Uptime/Expires    Ver    DR
Address Priority/Mode
10.132.0.156      port2             01:57:12/00:01:33 v2     1 /
```

Checking that the PIM router can reach the RP

The rendezvous point (RP) must be reachable for the PIM router (FGT-3) to be able to send the *,G join to request the stream. This can be checked for FGT-3 using the following command:

```
FGT-3 # get router info multicast pim sparse-mode rp-mapping
PIM Group-to-RP Mappings
Group(s): 224.0.0.0/4, Static
RP: 192.168.1.1
Uptime: 07:23:00
```

Viewing the multicast routing table (FGT-3)

The FGT-3 unicast routing table can be used to determine the path taken to reach the RP at 192.168.1.1. You can then check the stream state entries using the following commands:

```
FGT-3 # get router info multicast pim sparse-mode table
IP Multicast Routing Table

(*,*,RP) Entries: 0
(*,G) Entries: 1
(S,G) Entries: 1
(S,G,rpt) Entries: 1
FCR Entries: 0
```

(*,*,RP) Entries	This state may be reached by general joins for all groups served by a specified RP.
(*,G) Entries	State that maintains the RP tree for a given group.
(S,G) Entries	State that maintains a source-specific tree for source S and group G.
(S,G,rpt) Entries	State that maintains source-specific information about source S on the RP tree for G. For example, if a source is being received on the source-specific tree, it will normally have been pruned off the RP tree.
FCR	The FCR state entries are for tracking the sources in the <*, G> when <S, G> is not available for any reason, the stream would typically be flowing when this state exists.

Breaking down each entry in detail:

```
(*, 239.255.255.1)
RP: 192.168.1.1
RPF nbr: 10.132.0.156
RPF idx: port2
Upstream State: JOINED
Local:
    port3
Joined:
Asserted:
FCR:
```

The RP will always be listed in a *,G entry, the RPF neighbor and interface index will also be shown. In this topology these are the same in all downstream PIM routers. The state is active so the upstream state is joined.

In this case FGT-3 is the last hop router so the IGMP join is received locally on port3. There is no PIM outgoing interface listed for this entry as it is used for the upstream PIM join.

```
(10.166.0.11, 239.255.255.1)
RPF nbr: 10.132.0.156
RPF idx: port2
SPT bit: 1
Upstream State: JOINED
Local:
Joined:
Asserted:
Outgoing:
    port3
```

This is the entry for the SPT, no RP IS listed. The S, G stream will be forwarded out of the stated outgoing interface.

```
(10.166.0.11, 239.255.255.1, rpt)
RP: 192.168.1.1
RPF nbr: 10.132.0.156
RPF idx: port2
Upstream State: NOT PRUNED
Local:
Pruned:
Outgoing:
```

The above S, G, RPT state is created for all streams that have both a S, G and a *, G entry on the router. This is not pruned in this case because of the topology, the RP and source are reachable over the same interface.

Although not seen in this scenario, assert states may be seen when multiple PIM routers exist on the same LAN which can lead to more than one upstream router having a valid forwarding state. Assert messages are used to elect a single forwarder from the upstream devices.

Viewing the PIM next-hop table

The PIM next-hop table is also very useful for checking the various states, it can be used to quickly identify the states of multiple multicast streams

```
FGT-3 # get router info multicast pim sparse-mode next-hop
Flags: N = New, R = RP, S = Source, U = Unreachable
Destination      Type  Nexthop  Nexthop      Nexthop  Metric  Pref
      Refcnt
              Num    Addr
-----
10.166.0.11      ..S.  1        10.132.0.156  9 21     110    3
192.168.1.1     .R..  1        10.132.0.156  9 111    110    2
```

Viewing the PIM multicast forwarding table

Also you can check the multicast forwarding table showing the ingress and egress ports of the multicast stream.

```
FGT-3 # get router info multicast table

IP Multicast Routing Table
Flags: I - Immediate Stat, T - Timed Stat, F - Forwarder installed
Timers: Uptime/Stat Expiry
Interface State: Interface (TTL threshold)

(10.166.0.11, 239.255.255.1), uptime 04:02:55, stat expires 00:02:25
Owner PIM-SM, Flags: TF
  Incoming interface: port2
  Outgoing interface list:
    port3 (TTL threshold 1)
```

Viewing the kernel forwarding table

Also the kernel forwarding table can be verified, however this should give similar information to the above command:

```
FGT-3 # diag ip multicast mroute
grp=239.255.255.1 src=10.166.0.11 intf=9 flags=(0x10000000)[  ]
  status=resolved
  last_assert=2615136 bytes=1192116 pkt=14538 wrong_if=0 num_ifs=1
  index(ttl)=[6(1),]
```

Viewing the multicast routing table (FGT-2)

If you check the output on FGT-2 there are some small differences:

```
FGT-2 # get router info multicast pim sparse-mode table
IP Multicast Routing Table

(*,*,RP) Entries: 0
(*,G) Entries: 1
(S,G) Entries: 1
(S,G,rpt) Entries: 1
FCR Entries: 0

(*, 239.255.255.1)
RP: 192.168.1.1
RPF nbr: 0.0.0.0
RPF idx: None
Upstream State: JOINED
  Local:
  Joined:
    external
  Asserted:
FCR:
```

The *,G entry now has a joined interface rather than local because it has received a PIM join from FGT-3 rather than a local IGMP join.

```
(10.166.0.11, 239.255.255.1)
RPF nbr: 10.130.0.237
RPF idx: internal
SPT bit: 1
Upstream State: JOINED
Local:
Joined:
    external
Asserted:
Outgoing:
    external
```

The S,G entry shows that we have received a join on the external interface and the stream is being forwarded out of this interface.

```
(10.166.0.11, 239.255.255.1, rpt)
RP: 192.168.1.1
RPF nbr: 0.0.0.0
RPF idx: None
Upstream State: PRUNED
Local:
Pruned:
Outgoing:
    External
```

The S,G,RPT is different from FGT-3 because FGT-2 is the RP, it has pruned back the SPT for the RP to the first hop router.

Viewing the multicast routing table (FGT-1)

FGT-1 again has some differences with regard to the PIM-SM states, there is no *,G entry because it is not in the path of a receiver and the RP.

```
FGT-1_master # get router info multicast pim sparse-mode table
IP Multicast Routing Table

(*,*,RP) Entries: 0
(*,G) Entries: 0
(S,G) Entries: 1
(S,G,rpt) Entries: 1
FCR Entries: 0
```

Below the S,G is the SPT termination because this FortiGate unit is the first hop router, the RPF neighbor always shows as 0.0.0.0 because the source is local to this device. Both the joined and outgoing fields show as external because the PIM join and the stream is egressing on this interface.

```
(10.166.0.11, 239.255.255.1)
RPF nbr: 0.0.0.0
RPF idx: None
SPT bit: 1
Upstream State: JOINED
```

```
Local:
Joined:
    external
Asserted:
Outgoing:
    external
```

The stream has been pruned back from the RP because the end-to-end SPT is flowing, there is no requirement for the stream to be sent to the RP in this case.

```
(10.166.0.11, 239.255.255.1, rpt)
RP: 0.0.0.0
RPF nbr: 10.130.0.156
RPF idx: external
Upstream State: RPT NOT JOINED
Local:
Pruned:
Outgoing:
```

Example multicast destination NAT (DNAT) configuration

The example topology shown in [Figure 9](#) and described below shows how to configure destination NAT (DNAT) for two multicast streams. Both of these streams originate from the same source IP address, which is 10.166.0.11. The example configuration keeps the streams separate by creating 2 multicast NAT policies.

In this example the FortiGate units in [Figure 9](#) have the following roles:


- FGT-1 is the RP for dirty networks, 233.0.0.0/8.
- FGT-2 performs all firewall and DNAT translations.
- FGT-3 is the RP for the clean networks, 239.254.0.0/16.
- FGT-1 and FGT-3 are functioning as PM enabled routers and could be replaced can be any PIM enabled router.

This example only describes the configuration of FGT-2.

FGT-2 performs NAT so that the receivers connected to FGT-3 receive the following translated multicast streams.

- If the multicast source sends multicast packets with a source and destination IP of 10.166.0.11 and 233.2.2.1; FGT-3 translates the source and destination IPs to 192.168.20.1 and 239.254.1.1
- If the multicast source sends multicast packets with a source and destination IP of 10.166.0.11 and 233.3.3.1; FGT-3 translates the source and destination IPs to 192.168.20.10 and 239.254.3.1

Figure 9: Example multicast DNAT topology



To configure FGT-2 for DNAT multicast

1. Add a loopback interface. In the example, the loopback interface is named `loopback`.

```
config system interface
  edit loopback
    set vdom root
    set ip 192.168.20.1 255.255.255.0
    set type loopback
  next
end
```

2. Add PIM and add a unicast routing protocol to the loopback interface as if it was a normal routed interface. Also add static joins to the loopback interface for any groups to be translated.

```
config router multicast
  config interface
    edit loopback
      set pim-mode sparse-mode
      config join-group
        edit 233.2.2.1
        next
        edit 233.3.3.1
        next
      end
    next
  next
```

3. In this example, to add firewall multicast policies, different source IP addresses are required so you must first add an IP pool:

```
config firewall ippool
  edit Multicast_source
    set endip 192.168.20.20
    set interface port6
    set startip 192.168.20.10
  next
end
```

4. Add the translation security policies.

Policy 2, which is the source NAT policy, uses the actual IP address of port6. Policy 1, the DNAT policy, uses an address from the IP pool.

```
config firewall multicast-policy
  edit 1
    set dnat 239.254.3.1
    set dstaddr 233.3.3.1 255.255.255.255
    set dstintf loopback
    set nat 192.168.20.10
    set srcaddr 10.166.0.11 255.255.255.255
    set srcintf port6
  next
  edit 2
    set dnat 239.254.1.1
    set dstaddr 233.2.2.1 255.255.255.255
    set dstintf loopback
    set nat 192.168.20.1
    set srcaddr 10.166.0.11 255.255.255.255
    set srcintf port6
  next
end
```

5. Add a firewall multicast policy to forward the stream from the loopback interface to the physical outbound interface.

This example is an any/any policy that makes sure traffic accepted by the other multicast policies can exit the FortiGate unit.

```
config firewall multicast-policy
  edit 3
    set dstintf port7
    set srcintf loopback
  next
end
```

Example PIM configuration that uses BSR to find the RP


This example shows how to configure a multicast routing network for a network consisting of four FortiGate-500A units (FortiGate-500A_1 to FortiGate-500A_4, see [Figure 10](#)). A multicast sender is connected to FortiGate-500A_2. FortiGate-500A_2 forwards multicast packets in two directions to reach Receiver 1 and Receiver 2.

The configuration uses a Boot Start Router (BSR) to find the Rendezvous Points (RPs) instead of using static RPs. Under interface configuration, the loopback interface `lo0` must join the `236.1.1.1` group (source).

This example describes:

- [Commands used in this example](#)
- [Configuration steps](#)
- [Example debug commands](#)

Figure 10: PIM network topology using BSR to find the RP



Commands used in this example

This example uses CLI commands for the following configuration settings:

- [Adding a loopback interface \(lo0\)](#)
- [Defining the multicast routing](#)
- [Adding the NAT multicast policy](#)

Adding a loopback interface (lo0)

Where required, the following command is used to define a loopback interface named lo0.

```
config system interface
  edit lo0
    set vdom root
    set ip 1.4.50.4 255.255.255.255
    set allowaccess ping https ssh snmp http telnet
    set type loopback
  next
end
```

Defining the multicast routing

In this example, the following command syntax is used to define multicast routing. The example uses a Boot Start Router (BSR) to find the Rendezvous Points (RPs) instead of using static RPs. Under interface configuration, the loopback interface lo0 must join the 236.1.1.1 group (source).

```
config router multicast
  config interface
    edit port6
      set pim-mode sparse-mode
    next
    edit port1
      set pim-mode sparse-mode
    next
    edit lo0
      set pim-mode sparse-mode
      set rp-candidate enable
      config join-group
        edit 236.1.1.1
        next
      end
      set rp-candidate-priority 1
    next
  end
set multicast-routing enable
config pim-sm-global
  set bsr-allow-quick-refresh enable
  set bsr-candidate enable
  set bsr-interface lo0
  set bsr-priority 200
end
end
```

Adding the NAT multicast policy

In this example, the incoming multicast policy does the address translation. The NAT address should be the same as the IP address of the of loopback interface. The DNAT address is the translated address, which should be a new group.

```
config firewall multicast-policy
  edit 1
    set dstintf port6
    set srcintf lo0
  next
  edit 2
    set dnat 238.1.1.1
    set dstintf lo0
    set nat 1.4.50.4
    set srcintf port1
  next
```

Configuration steps

In this sample, FortiGate-500A_1 is the RP for the group 228.1.1.1, 237.1.1.1, 238.1.1.1, and FortiGate-500A_4 is the RP for the other group which has a priority of 1. OSPF is used in this example to distribute routes including the loopback interface. All firewalls have full mesh security policies to allow any to any.

- In the FortiGate-500A_1 configuration, the NAT policy translates source address 236.1.1.1 to 237.1.1.1
- In the FortiGate-500A_4, configuration, the NAT policy translates source 236.1.1.1 to 238.1.1.1
- Source 236.1.1.1 is injected into network as well.

The following procedures include the CLI commands for configuring each of the FortiGate units in the example configuration.

To configure FortiGate-500A_1

1. Configure multicast routing.

```
config router multicast
  config interface
    edit port5
      set pim-mode sparse-mode
    next
    edit port4
      set pim-mode sparse-mode
    next
    edit lan
      set pim-mode sparse-mode
    next
    edit port1
      set pim-mode sparse-mode
    next
    edit lo999
      set pim-mode sparse-mode
    next
```

```

    edit lo0
        set pim-mode sparse-mode
        set rp-candidate enable
        set rp-candidate-group 1
    next
end
set multicast-routing enable
config pim-sm-global
    set bsr-candidate enable
    set bsr-interface lo0
end
end

```

2. Add multicast security policies.

```

config firewall multicast-policy
    edit 1
        set dstintf port5
        set srcintf port4
    next
    edit 2
        set dstintf port4
        set srcintf port5
    next
    edit 3
    next
end

```

3. Add router access lists.

```

config router access-list
    edit 1
        config rule
            edit 1
                set prefix 228.1.1.1 255.255.255.255
                set exact-match enable
            next
            edit 2
                set prefix 237.1.1.1 255.255.255.255
                set exact-match enable
            next
            edit 3
                set prefix 238.1.1.1 255.255.255.255
                set exact-match enable
            next
        end
    next
end

```

To configure FortiGate-500A_2

1. Configure multicast routing.

```
config router multicast
  config interface
    edit "lan"
      set pim-mode sparse-mode
    next
    edit "port5"
      set pim-mode sparse-mode
    next
    edit "port2"
      set pim-mode sparse-mode
    next
    edit "port4"
      set pim-mode sparse-mode
    next
    edit "lo_5"
      set pim-mode sparse-mode
      config join-group
        edit 236.1.1.1
        next
      end
    next
  end
  set multicast-routing enable
end
```

2. Add multicast security policies.

```
config firewall multicast-policy
  edit 1
    set dstintf lan
    set srcintf port5
  next
  edit 2
    set dstintf port5
    set srcintf lan
  next
  edit 4
    set dstintf lan
    set srcintf port2
  next
  edit 5
    set dstintf port2
    set srcintf lan
  next
  edit 7
    set dstintf port1
    set srcintf port2
  next
  edit 8
```

```

        set dstintf port2
        set srcintf port1
    next
edit 9
    set dstintf port5
    set srcintf port2
next
edit 10
    set dstintf port2
    set srcintf port5
next
edit 11
    set dnat 237.1.1.1
    set dstintf lo_5
    set nat 5.5.5.5
    set srcintf port2
next
edit 12
    set dstintf lan
    set srcintf lo_5
next
edit 13
    set dstintf port1
    set srcintf lo_5
next
edit 14
    set dstintf port5
    set srcintf lo_5
next
edit 15
    set dstintf port2
    set srcintf lo_5
next
edit 16
next
end

```

To configure FortiGate-500A_3

1. Configure multicast routing.

```

config router multicast
config interface
    edit port5
        set pim-mode sparse-mode
    next
    edit port6
        set pim-mode sparse-mode
    next
    edit lo0
        set pim-mode sparse-mode

```

```

        set rp-candidate enable
        set rp-candidate-priority 255
    next
    edit lan
        set pim-mode sparse-mode
    next
end
set multicast-routing enable
config pim-sm-global
    set bsr-candidate enable
    set bsr-interface lo0
end
end

```

2. Add multicast security policies.

```

config firewall multicast-policy
    edit 1
        set dstintf port5
        set srcintf port6
    next
    edit 2
        set dstintf port6
        set srcintf port5
    next
    edit 3
        set dstintf port6
        set srcintf lan
    next
    edit 4
        set dstintf lan
        set srcintf port6
    next
    edit 5
        set dstintf port5
        set srcintf lan
    next
    edit 6
        set dstintf lan
        set srcintf port5
    next
end

```

To configure FortiGate-500A_4

1. Configure multicast routing.

```
config router multicast
  config interface
    edit port6
      set pim-mode sparse-mode
    next
    edit lan
      set pim-mode sparse-mode
    next
    edit port1
      set pim-mode sparse-mode
    next
    edit lo0
      set pim-mode sparse-mode
      set rp-candidate enable
      config join-group
        edit 236.1.1.1
        next
      end
      set rp-candidate-priority 1
    next
  end
set multicast-routing enable
config pim-sm-global
  set bsr-allow-quick-refresh enable
  set bsr-candidate enable
  set bsr-interface lo0
  set bsr-priority 1
end
end
```

2. Add multicast security policies.

```
config firewall policy
  edit 1
    set srcintf lan
    set dstintf port6
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
  next
  edit 2
    set srcintf port6
    set dstintf lan
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
```

```
    set service ANY
next
edit 3
    set srcintf port1
    set dstintf port6
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 4
    set srcintf port6
    set dstintf port1
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 5
    set srcintf port1
    set dstintf lan
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 6
    set srcintf lan
    set dstintf port1
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 7
    set srcintf port1
    set dstintf port1
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 8
    set srcintf port6
```

```

    set dstintf lo0
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 9
    set srcintf port1
    set dstintf lo0
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
edit 10
    set srcintf lan
    set dstintf lo0
    set srcaddr all
    set dstaddr all
    set action accept
    set schedule always
    set service ANY
next
end

```

Example debug commands

You can use the following CLI commands to view information about and status of the multicast configuration. This section includes `get` and `diagnose` commands and some sample output.

```

get router info multicast pim sparse-mode table 236.1.1.1
get router info multicast pim sparse-mode neighbor

```

Neighbor Address	Interface	Uptime/Expires	Ver	DR	Priority/
83.97.1.2	port6	02:22:01/00:01:44	v2	1 / DR	

```

diagnose ip multicast mroute
grp=236.1.1.1 src=19.2.1.1 intf=7 flags=(0x10000000)[ ]
status=resolved
    last_assert=171963 bytes=1766104 pkt=1718 wrong_if=1
num_ifs=2
    index(ttl)=[6(1),10(1),]
grp=236.1.1.1 src=1.4.50.4 intf=10 flags=(0x10000000)[ ]
status=resolved
    last_assert=834864 bytes=4416 pkt=138 wrong_if=0 num_ifs=2
    index(ttl)=[7(1),6(1),]
grp=238.1.1.1 src=1.4.50.4 intf=10 flags=(0x10000000)[ ]
status=resolved
    last_assert=834864 bytes=1765076 pkt=1717 wrong_if=0
num_ifs=1

```

```
index(ttl)=[7(1),]
```

```
get router info multicast igmp groups
```

```
IGMP Connected Group Membership
```

Group Address	Interface	Uptime	Expires	Last Reporter
236.1.1.1	lan	00:45:48	00:03:21	10.4.1.1
236.1.1.1	lo0	02:19:31	00:03:23	1.4.50.4

```
get router info multicast pim sparse-mode interface
```

Address	Interface	VIFindex	Ver/ Mode	Nbr Count	DR	DR Prior
10.4.1.2	lan	2	v2/S	0	1	10.4.1.2
83.97.1.1	port6	0	v2/S	1	1	83.97.1.2
1.4.50.4	lo0	3	v2/S	0	1	1.4.50.4

```
get router info multicast pim sparse-mode rp-mapping
```

```
PIM Group-to-RP Mappings
```

```
This system is the Bootstrap Router (v2)
```

```
Group(s): 224.0.0.0/4
```

```
RP: 1.4.50.4
```

```
Info source: 1.4.50.4, via bootstrap, priority 1
```

```
Uptime: 02:20:32, expires: 00:01:58
```

```
RP: 1.4.50.3
```

```
Info source: 1.4.50.3, via bootstrap, priority 255
```

```
Uptime: 02:20:07, expires: 00:02:24
```

```
Group(s): 228.1.1.1/32
```

```
RP: 1.4.50.1
```

```
Info source: 1.4.50.1, via bootstrap, priority 192
```

```
Uptime: 02:18:24, expires: 00:02:06
```

```
Group(s): 237.1.1.1/32
```

```
RP: 1.4.50.1
```

```
Info source: 1.4.50.1, via bootstrap, priority 192
```

```
Uptime: 02:18:24, expires: 00:02:06
```

```
Group(s): 238.1.1.1/32
```

```
RP: 1.4.50.1
```

```
Info source: 1.4.50.1, via bootstrap, priority 192
```

```
Uptime: 02:18:24, expires: 00:02:06
```

```
get router info multicast pim sparse-mode bsr-info
```

```
PIMv2 Bootstrap information
```

```
This system is the Bootstrap Router (BSR)
```

```
BSR address: 1.4.50.4
```

```
Uptime: 02:23:08, BSR Priority: 1, Hash mask length: 10
```

```
Next bootstrap message in 00:00:18
```

```
Role: Candidate BSR
```

```
State: Elected BSR
```

```
Candidate RP: 1.4.50.4(lo0)
```

```
Advertisement interval 60 seconds
```

```
Next Cand_RP_advertisement in 00:00:54
```

Index

A

- ACCEPT 74
- addresses 31
- Allow Invalid SSL Certificate 72
- AntiVirus 67
- Application Control 67
- Application Layer Firewalls 14

B

- Boot Strap Router (BSR) 151

C

- Central NAT Table 24
- Chunked Bypass 71
- Comfort Clients 70

D

- Data Leak Prevention 68
- dense mode 152
- DENY 74
- Designated Routers (DRs) 151
- DLP 68

E

- Email Filtering 68
- Email Signature 71
- EndPoint Control 68

F

- Firewall policies 74
- Firewall schedules 64
- Fixed Port 39
- FQDN Addressing 33
- Fragmented Messages 71

G

- Geography Based Addressing 33

I

- ICAP 68
- ICMP 41, 44
- ICMP Types 45
- ICMP6 41
- ICMPv6 47
- IGMP
 - RFC 1112 152
 - RFC 2236 152
 - RFC 3376 152
- Intrusion Protection 67
- Invalid Certificate Log 70
- IP 41

- IP address
 - multicasting 153

- IPS 67

M

- multicast
 - dense mode 152
 - IGMP 152
 - RFC 3973 151
 - RFC 4601 151
- multicast-enable command 157
- multicasting
 - debugging example 168
 - enabling 157
 - IP addresses 153
 - RIPv2 155
 - security policies 157

N

- NAT 64 25
- NAT 66 25
- NAT/Route Mode 28
- Network Layer or Packet Filter Firewalls 13

O

- Oversized File Log 69
- Oversized File/Email Threshold 70

P

- policies
 - multicast 157
- Policy order 76
- policy6_list 16
- Protocol Independent Multicast (PIM) 151
- Protocol Types 41
- Proxy Servers 14

Q

- Quality of Service 28
- Queuing 29

R

- Rendezvous Points (RPs) 151
- RFC 1112 152
- RFC 2236 152
- RFC 3286 43
- RFC 3376 152
- RFC 3973 151
- RFC 4601 151
- RFC 4960 43
- RIPv2 155

S

- Schedule Expiration 66
- Schedule groups 65
- SCTP 42
- security policies
 - multicast 157
- Service Categories 41
- Stateful Firewalls 13
- Stateless Firewalls 13

T

- TCP 41
- TCP/UDP/SCTP 41
- Traffic policing 28

- Traffic Shaping 29
- Transparent Mode 28

U

- UDP 42
- Unified Threat Management 15
- UTM profiles 66
- UTM Proxy Option Components 69
- UTM scanning process 27

V

- VoIP 68

W

- Web Filtering 67

