



FortiOS™ Handbook
Managing Devices for FortiOS 5.0



FortiOS™ Handbook Managing Devices for FortiOS 5.0

October 31, 2013

01-505-122870-20131031

Copyright© 2013 Fortinet, Inc. All rights reserved. Fortinet®, FortiGate®, and FortiGuard®, are registered trademarks of Fortinet, Inc., and other Fortinet names herein may also be trademarks of Fortinet. All other product or company names may be trademarks of their respective owners. Performance metrics contained herein were attained in internal lab tests under ideal conditions, and performance may vary. Network variables, different network environments and other conditions may affect performance results. Nothing herein represents any binding commitment by Fortinet, and Fortinet disclaims all warranties, whether express or implied, except to the extent Fortinet enters a binding written contract, signed by Fortinet's General Counsel, with a purchaser that expressly warrants that the identified product will perform according to the performance metrics herein. For absolute clarity, any such warranty will be limited to performance in the same ideal conditions as in Fortinet's internal lab tests. Fortinet disclaims in full any guarantees. Fortinet reserves the right to change, modify, transfer, or otherwise revise this publication without notice, and the most current version of the publication shall be applicable.

Technical Documentation	docs.fortinet.com
Knowledge Base	kb.fortinet.com
Customer Service & Support	support.fortinet.com
Training Services	training.fortinet.com
FortiGuard	fortiguard.com
Document Feedback	techdocs@fortinet.com

Contents

- Introduction..... 4**
 - Before you begin..... 4
- Managing “bring your own device” 5**
 - Device monitoring 5
 - Device Groups 6
 - Creating a custom device group..... 7
 - Controlling access with a MAC Address Access Control List 8
 - Device policies 8
 - Creating device policies 10
- Endpoint Protection 12**
 - Endpoint Protection overview 12
 - User experience 12
 - FortiGate endpoint registration limits..... 13
 - Configuration overview 14
 - Changing the FortiClient installer download location 14
 - Creating a FortiClient profile 15
 - Enabling Endpoint Protection in security policies 17
 - Configuring endpoint registration over a VPN 18
 - Endpoint registration on an IPsec VPN..... 18
 - Endpoint registration on the SSL VPN..... 18
 - Synchronizing endpoint registrations 18
 - Monitoring endpoints 19
 - Modifying the Endpoint Protection replacement messages..... 19
- Vulnerability Scan 20**
 - Configuring vulnerability scans 20
 - Running a vulnerability scan and viewing scan results..... 22
 - Requirements for authenticated scanning and ports scanned 22
 - Microsoft Windows hosts - domain scanning 23
 - Microsoft Windows hosts - local (non-domain) scanning..... 24
 - Windows firewall settings 24
 - Unix hosts 24
- Index 27**

Introduction

Welcome and thank you for selecting Fortinet products for your network protection.

This chapter contains the following topics:

- [Before you begin](#)
- [How this guide is organized](#)

Before you begin

Before you begin using this guide, please ensure that:

- You have administrative access to the web-based manager and/or CLI.
- The FortiGate unit is integrated into your network.
- The operation mode has been configured.
- The system time, DNS settings, administrator password, and network interfaces have been configured.
- Firmware, FortiGuard Antivirus and FortiGuard Antispam updates are completed.
- Any third-party software or servers have been configured using their documentation.

While using the instructions in this guide, note that administrators are assumed to be super_admin administrators unless otherwise specified. Some restrictions will apply to other administrators.

How this guide is organized

This FortiOS Handbook chapter contains the following sections:

[Managing “bring your own device”](#) describes device monitoring, devices, device groups, and device policies. The administrator can monitor all types of devices and control their access to network resources.

[Endpoint Protection](#) describes how you can enforce the use of FortiClient Endpoint Control and apply an endpoint profile to users' devices. Endpoint profiles include real-time antivirus protection, application control, web category filtering, and VPN provisioning.

[Vulnerability Scan](#) describes how perform network vulnerability scanning to look for security weaknesses in your servers and workstations.

Managing “bring your own device”

FortiOS can control network access for different types of personal mobile devices that your employees bring onto your premises. You can:

- identify and monitor the types of devices connecting to your networks, wireless or wired
- use MAC address based access control to allow or deny individual devices
- create policies based on device type
- enforce endpoint control on devices that can run FortiClient Endpoint Control software

Device monitoring

The FortiGate unit can monitor your networks and gather information about the devices operating on those networks. Collected information includes:

- MAC address
- IP address
- operating system
- hostname
- user name
- how long ago the device was detected and on which FortiGate interface

You can go to *User & Device > Device > Device Definitions* to view this information.

Device	OS	User	Hostname	IP Address	Custom Group	FortiClient State	Last Seen	Alias
18:03:73:b6:f9:e9				172.20.120.100		N/A	2 minutes ago (wan1)	
00:0b:82:17:a2:de						N/A	yesterday (wan1)	
18:03:73:89:1b:25			Marc-PC	172.20.120.235		N/A	2 minutes ago (wan1)	
78:7b:cb:d8:36:68				172.20.120.71		N/A	1 second ago (wan1)	
00:09:0f:fe:d0:67				172.20.120.136		N/A	1 minute ago (wan1)	
00:26:ab:9b:9e:63				172.20.120.111		N/A	6 minutes ago (wan1)	
a8:20:66:14:fa:da			wd-mh	172.20.120.226		N/A	5 seconds ago (wan1)	
c4:2c:03:21:a9:8e				172.20.120.83		N/A	7 seconds ago (wan1)	
00:0c:29:ba:54:2e				172.20.120.54		N/A	3 minutes ago (wan1)	
00:09:0f:4e:70:b1				172.20.120.122		N/A	yesterday (wan1)	
Bob	iPhone / iOS	A		10.10.82.4		N/A		Bob
Jcoles-mac	Mac OS X / 10.x			172.20.120.51	Employees	N/A	1 second ago (wan1)	Jcoles-mac
00:0c:29:92:7f:4a				172.20.120.52		N/A	24 seconds ago (wan1)	
00:0c:29:73:1e:df				172.20.120.13		N/A	1 minute ago (wan1)	
00:09:0f:15:04:86						N/A	1 minute ago (wan1)	
f0:4d:a2:f1:d3:4a				172.20.120.36		N/A	11 seconds ago (wan1)	
00:24:e8:e0:98:66			akaye-notebook	172.20.120.223		N/A	yesterday (wan1)	
f0:4d:a2:f1:d6:60				172.20.120.46		N/A	1 minute ago (wan1)	
c4:2c:03:21:af:04				172.20.120.14		N/A	1 second ago (wan1)	
00:09:0f:99:4b:e4			FG100D3G12804410			N/A	yesterday (wan1)	
00:0c:29:df:22:b0			bill-0b2i3pig5	172.20.120.222		N/A	yesterday (wan1)	
00:0c:29:93:6d:bd			FortiGate-VM			N/A	yesterday (wan1)	
00:09:0f:35:6d:41			FAP22B3U11022065	172.20.120.230		N/A	yesterday (wan1)	
f0:4d:a2:f1:bf:a3				172.20.120.26		N/A	yesterday (wan1)	
00:09:0f:67:2d:58	Android / 2.2, 2.3			172.20.120.2		N/A	1 minute ago (wan1)	

Device monitoring is enabled separately on each interface. Device detection is intended for devices directly connected to your LAN ports. If enabled on a WAN port, device detection may be unable to determine some devices' operating system.

To configure device monitoring

1. Go to *System > Network > Interfaces*.
2. Edit the interface that you want to monitor devices on.
3. In *Device Management*, select *Detect and Identify Devices*.
4. Select *OK*.
5. Repeat steps 2 through 4 for each interface that will monitor devices.

To assign an alias to a detected device or change device information

1. Go to *User & Device > Device > Device Definitions*.
2. Double-click the device entry or right-click it and select *Edit*.
3. Enter an *Alias* such as the user's name to identify the device.
This step is compulsory. The alias replaces the MAC address in the device list.
4. Change other information as needed.
5. Select *OK*.

To add a device manually

1. Go to *User & Device > Device > Device Definitions* and select *Create New*.
2. Enter the following information.
 - Alias (required)
 - MAC address
 - Device Type
3. Optionally, select *Custom Groups* or enter *Comments*.
4. Select *OK*.

Device Groups

Device Groups are used in device policies to specify which devices match the policy. FortiOS automatically adds detected devices of well-known device types to predefined device groups. You can also create custom device groups so that you can create a different policy for devices that you know than for devices in general.

Go to *User & Device > Device > Device Groups* to view the list of device groups. To view all groups, select *Show Empty Groups* at the top right of the list.

Table 1: Predefined Device Groups

Group	Devices
All	All devices.
Android Phone	All Android-based phones in the Device Visibility database.
Android Tablet	Tablets running Android OS.
BlackBerry Phone	All BlackBerry-based phones in the Device Visibility database.
BlackBerry PlayBook	All BlackBerry PlayBook devices in the Device Visibility database.
Collected Emails	All devices from which FortiOS has collected a user email address.
Fortinet Device	FortiGate, FortiManager, FortiAnalyzer, FortiMail, etc.

Table 1: Predefined Device Groups

Group	Devices
Gaming Console	All Gaming consoles listed in the Device Visibility database. This includes Xbox, PS2, PS3, Wii, PSP.
IP Phone	All IP phones.
iPad	All IOS-based tablets in the Device Visibility database.
iPhone	All IOS-based phones in the Device Visibility database.
Linux PC	PCs running a Linux-based OS.
Mac	Apple Macintosh computers.
Media Streaming	Media streaming devices such as Apple TV.
Router/NAT Device	Router.
Windows PC	PCs running a Windows OS.
Windows Phone	All Windows OS based phones.
Windows Tablet	All Windows-based tablets.
Other Network Device	All other network devices not categorized under any other group.

Creating a custom device group

In addition to the predefined device groups, you can create custom device groups, where you choose the member devices.

For ease of identifying devices, Fortinet recommends that you assign each device an Alias. For previously detected devices, you can edit the existing device definition to assign an alias. For devices that have not yet been detected, you can add a device definition if you know the device's MAC address. At that time you can also assign an alias for the device.

To create a custom device group and add devices to it

1. Go to *User & Device > Device > Device Groups* and select *Create New*.
2. Enter a *Name* for the group, Employees for example.
3. Click in the *Members* field and click a device to add. Repeat to add other devices.
4. Select *OK*.

The devices are added to the custom device group.

Controlling access with a MAC Address Access Control List

A MAC Address Access Control List is best used to handle exceptions. If you want to limit network access to a larger group such as your employees, it is better to create a custom device group and specify that group in your device-based security policies.

A MAC Address Access Control List functions as either a list of blocked devices or a list of allowed devices. This is determined by the *Unknown MAC Address* entry.

- By default, unknown MAC addresses are allowed: *Action* is *Assign IP*. You add an entry for each MAC address that you want to block and set its *Action* to *Block*.
- If you want to restrict access to a limited set of devices, you set the *Unknown MAC Address* entry to *Block* and add an entry for each allowed MAC address with *Action* set to *Assign IP*.

To create a MAC Address Access Control List

1. In the SSID or other interface configuration, select *Enable DHCP Server*.
2. Enter the required *Address Range* and *Netmask*.
3. Expand *Advanced*.
4. In *MAC Address Access Control List*, select *Create New* and enter the device's *MAC Address*.
5. Select *Assign IP* to allow the device or *Block* to block the device and then select *OK*.
6. Repeat Steps 4 and 5 for each additional MAC address entry.
7. If needed, edit the *Unknown MAC Address* entry to set the correct *Action*.

Device policies

Policies based on device identity enable you to implement policies according to device type. For example:

- Gaming consoles cannot connect to the company network or the Internet.
- Personal tablet and phone devices can connect to the Internet but not to company servers.
- Company-issued laptop computers can connect to the Internet and company servers. Web filtering and antivirus are applied.
- Employee laptop computers can connect to the Internet, but web filtering is applied. They can also connect to company networks, but only if FortiClient Endpoint Security is installed to protect against viruses.

Figure 1 and Figure 2 show these policies implemented for WiFi to the company network and to the Internet.

Figure 1: Device policies for WiFi access to the company network

Edit Policy

Policy Type: Firewall VPN

Policy Subtype: Address User Identity Device Identity

Incoming Interface: wifi (SSID: fortinet)

Source Address: all

Outgoing Interface: internal

Enable NAT

Use Destination Interface Address Fixed Port

Use Dynamic IP Pool

Configure Authentication Rules

Destination Address	Device	Endpoint Compliance	Service	Schedule	UTM Security	Traffic Shaping	Logging	Action
all	Gaming Console	-	ALL	always	-	⊗	⊗	⊗ DENY
all	Android Phone Android Tablet BlackBerry Phone BlackBerry PlayBook iPad iPhone	-	ALL	always	-	⊗	⊗	⊗ DENY
all	company laptop	⊗	ALL	always	🛡️	⊗	⊗	✅ ACCEPT
all	employee laptop	✅	ALL	always	-	⊗	⊗	✅ ACCEPT
all	employee laptop	-	ALL	always	-	⊗	⊗	⊗ Captive Portal - Enforce FortiClie

Customize Authentication Messages

Comments: 0/255

OK **Cancel**

Figure 2: Device policies for WiFi access to the Internet

Edit Policy

Policy Type: Firewall VPN

Policy Subtype: Address User Identity Device Identity

Incoming Interface: wifi (SSID: fortinet)

Source Address: all

Outgoing Interface: wan1

Enable NAT

Use Destination Interface Address Fixed Port

Use Dynamic IP Pool

Configure Authentication Rules

Destination Address	Device	Endpoint Compliance	Service	Schedule	UTM Security	Traffic Shaping	Logging	Action
all	Gaming Console	-	ALL	always	-	⊗	⊗	⊗ DENY
all	Android Phone Android Tablet BlackBerry Phone BlackBerry PlayBook iPad iPhone	⊗	ALL	always	-	⊗	⊗	✅ ACCEPT
all	company laptop	⊗	ALL	always	🛡️	⊗	⊗	✅ ACCEPT
all	employee laptop	⊗	ALL	always	🛡️	⊗	⊗	✅ ACCEPT

Customize Authentication Messages

Comments: 0/255

OK **Cancel**

The next section explains device policy creation in detail.

Creating device policies

Device-based security policies are similar to policies based on user identity:

- The policy enables traffic to flow from one network interface to another.
- NAT can be enabled.
- Authentication rules can allow or deny specific devices or device groups.
- UTM protection can be applied.

To create a device identity policy

1. Go to *Policy > Policy > Policy* and select *Create New*.
2. In *Policy Subtype*, select *Device Identity*.
3. Choose *Incoming Interface*, *Source Address*, and *Outgoing Interface* as you would for any security policy.
4. Select *Enable NAT* if appropriate.
You are now ready to create authentication rules.

To create an authentication rule


1. Select *Create New*.
2. Enter *Destination*, *Schedule*, and *Service* as you would for any security policy.
3. In *Device*, select the devices or device groups to which this policy applies.
You can select multiple devices or groups.
4. Select *Compliant with Endpoint Profile* if you want to enforce use of FortiClient Endpoint Security by the client devices. This is available here only if Action is ACCEPT. See [“Adding endpoint protection”](#) next.
5. Select either ACCEPT or DENY as the policy Action.
6. Configure *UTM Security Profiles* as you would for any security policy.
7. Select *OK*.
8. Select *OK* again to complete creation of the security policy.

Adding endpoint protection

Optionally, you can require that users’ devices have FortiClient Endpoint Security software installed. The software provides FortiOS more detailed information about the applications being used. FortiOS pushes a FortiClient profile out to the FortiClient software, configuring network protection such as antivirus, application control, and web category filtering. Devices without an up-to-date installation of FortiClient software are restricted to a captive portal from which the user can download a FortiClient installer.

If you have already created an ACCEPT rule for particular device groups, you simply edit this rule and enable *Compliant with Endpoint Profile*. Then select the device policy option that directs FortiClient-compatible devices to a captive portal.

Figure 3: Authentication rule with Endpoint compliance and captive portal enabled



Destination Address	Device	Endpoint Compliance	Service	Schedule	UTM Security	Traffic Shaping	Logging	Action
all	employee laptop	✓	ALL	always	-	⊗	⊗	✓ ACCEPT
all	All	-	ALL	always	-	⊗	⊗	⊗ DENY

Customize Authentication Messages

Device Policy Options

- Attempt to detect all Unknown device types before implicit deny
- Redirect all non-compliant/unregistered FortiClient compatible devices to a captive portal
 - Windows PCs
 - Mac OSX
 - iPhone/iPad
 - Android

For more information, see [“Endpoint Protection”](#) on page 12.

Setting Device Policy Options

1. Optionally, enable *Attempt to detect all Unknown device types before implicit deny*.
2. *Redirect all non-compliant/unregistered FortiClient compatible devices to a captive portal* enables the captive portal. Select which device platforms to include.
3. Optionally, enable *Prompt Email Address Collection Portal for all devices*. This requests an email address from the device user. See [“Guest access in a retail environment”](#) on page 994.

Endpoint Protection

This section describes the Endpoint Protection feature and how to configure it.

The following topics are included in this section:

- [Endpoint Protection overview](#)
- [Configuration overview](#)
- [Creating a FortiClient profile](#)
- [Enabling Endpoint Protection in security policies](#)
- [Configuring endpoint registration over a VPN](#)
- [Monitoring endpoints](#)
- [Modifying the Endpoint Protection replacement messages](#)

Endpoint Protection overview

Endpoint Protection enforces the use of up-to-date FortiClient Endpoint Security software on endpoints (workstation computers and mobile devices). It pushes a FortiClient profile to the FortiClient application, specifying security settings, including:

- Real-time antivirus protection - on or off
- FortiClient web category filtering based on web filters defined in a FortiGate web filter profile
- FortiClient application control (application firewall) using application sensors defined in the FortiGate application control feature
- Endpoint vulnerability scanning daily, weekly, or monthly

The FortiClient profile can also specify:

- VPN configurations
- Uploading of logs to the FortiGate unit hourly or daily
- Configuration profile (.mobileconfig file for iOS)
- Dashboard banner

You enable Endpoint Security in device identity security policies by enabling *Compliant with FortiClient Profile*. Optionally, the security policy can redirect non-compliant endpoints to a captive portal to download FortiClient software. Otherwise, non-compliant endpoints are blocked.


User experience

Endpoint Protection applies to users attempting to make a connection that is controlled by a firewall policy that specifies a FortiClient profile. The user of a non-compliant endpoint using a web browser receives a replacement message HTML page from the FortiGate unit. The message explains the non-compliance. Depending on the FortiClient profile, the user may be allowed to continue or is blocked from further access. For information about modifying these replacement pages, see [“Modifying the Endpoint Protection replacement messages” on page 19](#).

FortiClient non-compliance

If the authentication rule in a device identity policy requires endpoint protection, a device without the latest version of FortiClient Endpoint Security installed is denied access. Optionally, the user is redirected to a captive and sees a message like this:

Figure 4: Default FortiClient non-compliance message for Windows



After installing FortiClient Endpoint Security, the user will receive an invitation to register with the FortiGate unit. If the user accepts the invitation, the FortiClient profile is sent to the device's FortiClient application. Now the user can pass the authentication rule and connect to the network. FortiClient Endpoint Security registered with a FortiGate unit does not need to be separately licensed with FortiGuard.

The FortiGate unit can also register endpoints who connect over the Internet through a VPN. The user can accept an invitation to register with the FortiGate unit. See [“Configuring endpoint registration over a VPN”](#) on page 18.

FortiGate endpoint registration limits

To view the number of endpoints that are registered and the total that can be registered, go to *System > Dashboard > Status*. Under *License Information*, find *FortiClient Software*. You will see a line like “Registered/Allowed 4 of 10”. This means that there are four registered endpoints and a total of ten are allowed.

When the registration limit is reached, the next FortiClient-compatible device will not be able to register with the FortiGate unit. The user sees a message in FortiClient application about this. The FortiClient profile is not sent to client and the client cannot connect through the FortiGate unit.

For all FortiGate models, the maximum number of registered endpoints is ten. For all models except 20C and 40C, you can purchase an endpoint license to increase this capacity:

To add an endpoint license - web-based manager

1. Go to *System > Dashboard > Status*.
2. In the *License Information* widget, under *FortiClient Software*, select *[Enter License]*, enter the license key, and select *OK*.

Table 2: Maximum registered endpoints with endpoint license

Model type	Max Registered Endpoints
Desktop	200
Rack - 1U	2000
Rack - 2U+	8000

Configuration overview

Endpoint Protection requires that all hosts using the firewall policy have the FortiClient Endpoint Security application installed. Make sure that all hosts affected by this policy are able to install this application. Currently, FortiClient Endpoint Security is available for Microsoft Windows (2000 and later) and Apple Mac OSX only.

To set up Endpoint Protection, you need to

- Enable Central Management by the FortiGuard Analysis & Management Service if you will use FortiGuard Services to update the FortiClient application or antivirus signatures. You do not need to enter account information. See “Centralized Management” in the System Administration chapter of the FortiOS Handbook.
- By default, the FortiGuard service provides the FortiClient installer. If you prefer to host it on your own server, see “[Changing the FortiClient installer download location](#)” on page 14.
- In Security Profiles, configure application sensors and web filters profiles as needed to monitor or block applications. See the Security Profiles Guide chapter of the FortiOS Handbook for details.
- Create a FortiClient profile or use a predefined profile. See “[Creating a FortiClient profile](#)” on page 15. Enable the application sensor and web category filtering profiles that you want to use.
- Enable *Compliant with FortiClient Profile* in the authentication rules of Device Identity security policies that the endpoints will use.
- Optionally, configure the FortiGate unit to support endpoint registration by IPsec or SSL VPN.

Changing the FortiClient installer download location

By default, FortiClient installers are downloaded from the FortiGuard network. You can also host these installers on a server for your users to download. In that case, you must configure FortiOS with this custom download location. For example, to set the download location to a customer web server with address `custom.example.com`, enter the following command:

```
config endpoint-control settings
    set download-location custom
    set download-custom-link "http://custom.example.com"
end
```

Creating a FortiClient profile

Each FortiClient profile is assigned to particular device groups, user groups, or individual users. When *Compliant with FortiClient Profile* is selected in an authentication rule, all users of that rule must have FortiClient Endpoint Security installed. The FortiGate unit pushes the FortiClient profile settings to the FortiClient application on the client.

To create a FortiClient profile - web-based manager

1. If you will use the Application Firewall feature, go to *Security Profiles > Application Control > Application Sensors* to create the Application Sensors that you will need.
2. If you will use Web Category Filtering, go to *Security Profiles > Web Filter > Profiles* to create the web filter profile that you will need.
3. Go to *User & Device > Endpoint Protection > FortiClient Profiles*.

The list of FortiClient profiles is displayed.

4. Select *Create New* or select an existing profile and *Edit* it.
5. In *Assign Profile To*, select one or more device groups, user groups, and users to which this FortiClient profile applies. You can also select user groups and users. This is not available for the default profile.
6. Enter the *FortiClient Configuration Deployment* settings for *Windows and Mac*:

Antivirus Protection	ON — enable the FortiClient realtime AntiVirus feature.
Web Category Filtering	ON — enable web category filtering. Select the web filter profile to use.
Disable Web Category Filtering when protected by this FortiGate	Disables FortiClient web category filtering when client traffic is filtered by the FortiGate unit. Selected by default.
Client VPN Provisioning	Enable to configure the FortiClient VPN client. Enter the VPN configuration details.
Application Firewall	ON — enable application control. Select the application sensor to use.
Endpoint Vulnerability Scan on Client	ON — FortiGate unit will perform vulnerability scan on client. Select the desired schedule.
Initiate Scan After Client Registration	Enables scan following registration, regardless of schedule. Selected by default.
Upload logs to FortiAnalyzer /FortiManager	ON — FortiClient software will upload its logs to the specified FQDN or IP address. Select the desired schedule.
Use FortiManager for client software/signature update	ON — FortiClient software obtain AV signatures and software updates from the specified FQDN or IP address. <i>Failover to FDN when FortiManager is not available</i> is enabled by default.
Dashboard Banner	ON — Display dashboard banner.

7. Enter the *FortiClient Configuration Deployment* settings for *iOS*:

Web Category Filtering	ON — enable web category filtering. Select the web filter profile to use.
Disable Web Category Filtering when protected by this FortiGate	Disables FortiClient web category filtering when client traffic is filtered by the FortiGate unit. Selected by default.
Client VPN Provisioning	Enable to configure the FortiClient VPN client. You can enter multiple VPN configurations by selecting the “+” button.
VPN Name	Enter a name to identify this VPN configuration in the FortiClient application.
Type	Select <i>IPsec</i> or <i>SSL-VPN</i> . If you select <i>IPsec</i> , select a <i>VPN Configuration File</i> that contains the required IPsec VPN configuration. The Apple iPhone Configuration Utility produces .mobileconfig files which contain configuration information for an iOS device. If you select <i>SSL-VPN</i> , enter the VPN configuration details.
Distribute Configuration Profile	ON — Distribute configuration information to iOS devices running FortiClient Endpoint Security. Select <i>Browse</i> and locate the file to be distributed. The Apple iPhone Configuration Utility produces .mobileconfig files which contain configuration information for an iOS device.

8. Enter the *FortiClient Configuration Deployment* settings for *Android*:

Web Category Filtering	ON — enable web category filtering. Select the web filter profile to use.
Disable Web Category Filtering when protected by this FortiGate	Disables FortiClient web category filtering when client traffic is filtered by the FortiGate unit. Selected by default.
Client VPN Provisioning	Enable to configure the FortiClient VPN client. You can enter multiple VPN configurations by selecting the “+” button.
VPN Name	Enter a name to identify this VPN configuration in the FortiClient application.
Type	Select <i>IPsec</i> or <i>SSL-VPN</i> . Enter the VPN configuration details.

9. Select *Apply*.

To create a FortiClient profile - CLI

This example creates a profile for Windows and Mac computers.

```
config endpoint-control profile
  edit ep-profile1
    set device-groups mac windows-pc
    config forticlient-winmac-settings
      set forticlient-av enable
      set forticlient-wf enable
      set forticlient-wf-profile default
    end
  end
end
```

Enabling Endpoint Protection in security policies

Endpoint Protection is applied to any traffic where the controlling firewall policy has Endpoint Security enabled. The device group to which the device belongs determines which FortiClient profile is applied. The policy searches the list of FortiClient profiles starting from the top and applies the first profile assigned to the device group.

To enable Endpoint Protection - web-based manager

1. Go to *Policy > Policy > Policy* and edit the device identity firewall policy where you want to enable Endpoint Protection.
2. Create or edit an authentication rule.
3. Select *Compliant with FortiClient profile*.
4. Select *OK*.

To configure the firewall policy - CLI

In this example, the LAN connects to Port 2 and the Internet is connected to Port 1. a FortiClient profile is applied.

```
config firewall policy
  edit 0
    set srcintf port2
    set dstintf port1
    set srcaddr LANUsers
    set dstaddr all
    set action accept
    set identity-based enable
    set identity-from device
    set nat enable
    config identity-based-policy
      edit 1
        set schedule always
        set service ALL
        set devices all
        set endpoint-compliance enable
      end
    end
end
```

Configuring endpoint registration over a VPN

FortiGate units can register FortiClient-equipped endpoints over either an interface-based IPsec VPN or a tunnel-mode SSL VPN. After the user authenticates, the FortiGate unit sends the FortiClient application the IP address and port to be used for registration. If the user accepts the FortiGate invitation to register, registration proceeds and the FortiClient profile is downloaded to the client.

Users without FortiClient Endpoint Security connecting to the SSL VPN through a browser can be redirected to a captive portal to download and install the FortiClient software. The security policy must enable *Redirect all non-compliant/unregistered FortiClient compatible devices to a captive portal*, but not select any specific device types.

Endpoint registration on an IPsec VPN

You can enable endpoint registration when you configure the FortiClient VPN or you can enable it on an existing FortiClient VPN.

To enable endpoint registration while configuring the VPN

- Enable *Allow Endpoint Registration* on the Network page of the VPN Wizard when creating the FortiClient VPN.

To enable endpoint registration on an existing VPN

1. Go to *System > Network > Interfaces* and edit the VPN's tunnel interface.
The tunnel is a subinterface of the physical network interface.
2. In *Administrative Access*, make sure that *FCT-Access* is enabled.
3. Select *OK*.

Endpoint registration on the SSL VPN

To enable endpoint registration on the SSL VPN

1. Go to *VPN > SSL > Portal*.
2. Make sure *Enable Tunnel Mode* is enabled.
3. Optionally, enable *Include FortiClient Download*.
Users who access the VPN with a browser will be able to download FortiClient Endpoint Security for their device.
4. Select *Apply*.
5. Go to *VPN > SSL > Config*, make sure *Allow Endpoint Registration (Tunnel Mode Only)* is enabled, then select *Apply*.

This procedure does not include all settings needed to configure a working SSL VPN.

Synchronizing endpoint registrations

To support roaming users in a network with multiple FortiGate units, you need to configure synchronization of the endpoint registration databases between the units. The registered endpoints are then recognized on all of the FortiGate units. This is configured in the CLI. For

example, to synchronize this FortiGate unit's registered endpoint database with another unit named `other1` at IP address 172.20.120.4, enter:

```
config endpoint-control forticlient-registration-sync
  edit other1
    set peer-ip 172.20.120.4
  end
```

Monitoring endpoints

Go to *User & Device > Monitor > FortiClient* to monitor endpoints.

Modifying the Endpoint Protection replacement messages

If the security policy has *Redirect all non-compliant/unregistered FortiClient compatible devices to a captive portal* enabled, users of non-compliant devices are redirected to a captive portal that is defined by the *Endpoint NAC Download Portal* replacement message. There are different portals for Android, iOS, Mac, Windows, and "other" devices. Optionally, you can modify them.

To modify the Endpoint NAC Download Portal

1. Go to *System > Config > Replacement Message Group* and select *Extended View*.
2. In the *Endpoint Control* section select the message that you want to edit.
The replacement message and its HTML code appear in a split screen in the lower half of the page.
3. Modify the text as needed and select *Save*.

Vulnerability Scan

The Network Vulnerability Scan helps you to protect your network assets (servers and workstations) by scanning them for security weaknesses. You can scan on-demand or on a scheduled basis. Results are viewable on the FortiGate unit, but results are also sent to an attached FortiAnalyzer unit. The FortiAnalyzer unit can collect the results of vulnerability scans from multiple FortiGate units at different locations on your network, compiling a comprehensive report about network security.

This section describes how to configure a single FortiGate unit for network scanning and how to view the results of the scan.

The following topics are included in this section:

- [Configuring vulnerability scans](#)
- [Running a vulnerability scan and viewing scan results](#)
- [Requirements for authenticated scanning and ports scanned](#)

Configuring vulnerability scans

You can configure the scan schedule and the assets to be scanned.

To configure scanning - web-based manager

1. Go to *User & Device > Vulnerability Scan > Scan Definition*.
2. Beside *Schedule* select *Change* to set the scan schedule and mode:

Recurrence	Select <i>Daily</i> , <i>Weekly</i> , or <i>Monthly</i> and configure the details for the option you have selected.
Suspend Scan between	Set a time during which the scan should be paused if its running.
Vulnerability Scan Mode	Quick — check only the most commonly used ports Standard — check the ports used by most known applications Full — check all TCP and UDP ports For a detailed list of the TCP and UDP ports examined by each scan mode, see Table 3 on page 25 .

3. Select *Apply* to save the schedule and scan type.
4. Select *Create New* under *Asset Definitions* to select the devices on the network to scan.

An asset can be a single server or workstation computer on your network or a range of addresses on your network. You must add assets to the vulnerability scan before you can run a scan.

To scan an entire network or part of a network you can just add the appropriate IP address range to the asset configuration. You can also add the IP addresses of Windows and Linux computers to include the user names and passwords for these machines. The vulnerability scanner will use these credentials to log into the computers and do more detailed vulnerability scanning.

Even if the asset is an address range you can add Windows and Linux credentials. The vulnerability scanner will attempt to log into all network device it finds using these credentials.

5. Enter the following information and select *OK*:

Name	Enter a name for this asset.
Type	Select <i>IP Address</i> to add a single IP address. Select <i>Range</i> to add a range of IP addresses to scan.
IP Address	Enter the IP address of the asset. (<i>Type is IP Address.</i>)
Range	Enter the start and end of the IP address range. (<i>Type is Range.</i>)
Enable Scheduled Vulnerability Scanning	Select to allow this asset to be scanned according to the schedule. Otherwise the asset is not scanned during a scheduled vulnerability scan.
Windows Authentication	Select to use authentication on a Windows operating system. Enter the username and password in the fields provided. For more information, see “Requirements for authenticated scanning and ports scanned” on page 22.
Unix Authentication	Select to use authentication on a Unix operating system. Enter the username and password in the fields provided. For more information, see “Requirements for authenticated scanning and ports scanned” on page 22.

6. Select *Apply* to save the configuration.

To configure scanning - CLI

To configure, for example, a standard scan to be performed every Sunday at 2:00am, you would enter:

```
config netscan settings
  set scan-mode standard
  set schedule enable
  set time 02:00
  set recurrence weekly
  set day-of-week sunday
end
```

To add an asset - CLI

This example adds a single computer to the Asset list:

```
config netscan assets
  edit 0
    set name "server1"
    set addr-type ip
    set start-ip 10.11.101.20
    set auth-windows enable
    set win-username admin
    set win-password zxcvbnm
```

```
    set scheduled enable
end
```

This example adds an address range to the Asset list. Authentication is not used:

```
config netscan assets
  edit 0
    set name "fileservers"
    set addr-type range
    set start-ip 10.11.101.160
    set end-ip 10.11.101.170
    set scheduled enable
  end
```

Running a vulnerability scan and viewing scan results

To run a vulnerability scan - web-based manager

1. Go to *User & Device > Vulnerability Scan > Scan Definition* and select *Start Scan*.
When the scan is running you can pause or stop it at any time. You can also watch the progress of the scan.
2. When the scan is complete go to *User & Device > Vulnerability Scan > Vulnerability Result* to view the results of the scan.

To run a vulnerability scan - CLI

Use the following CLI commands:

```
execute netscan start scan
execute netscan status
execute netscan pause
execute netscan resume
execute netscan stop
```

To view vulnerability scan results

1. To view vulnerability scan results go to *User & Device > Vulnerability Scan > Vulnerability Result*.
2. Select any log entry to view log details.

Requirements for authenticated scanning and ports scanned

The effectiveness of an authenticated scan is determined by the level of access the FortiGate unit obtains to the host operating system. Rather than use the system administrator's account, it might be more convenient to set up a separate account for the exclusive use of the vulnerability scanner with a password that does not change.

The following sections detail the account requirements for various operating systems.

Microsoft Windows hosts - domain scanning

The user account provided for authentication must

- have administrator rights
- be a Security type of account
- have global scope
- belong to the Domain Administrators group
- meet the Group Policy requirements listed below:

Group Policy - Security Options

In the Group Policy Management Editor, go to Computer Configuration > Windows Settings > Security Settings > Local Policies > Security Options.

Setting	Value
Network access: Sharing and security model for local accounts	Classic
Accounts: Guest account status	Disabled
Network access: Let Everyone permissions apply to anonymous users	Disabled

Group Policy - System Services

In the Group Policy Management Editor, go to Computer Configuration > Windows Settings > Security Settings > System Services.

Setting	Value
Remote registry	Automatic
Server	Automatic
Windows Firewall	Automatic

Group Policy - Administrative Templates

In the Group Policy Management Editor, go to Computer Configuration > Administrative Templates > Network > Network Connections > Windows Firewall > Domain Profile.

Setting	Value
Windows Firewall: Protect all network connections	Disabled

or

Setting	Value
Windows Firewall: Protect all network connections	Enabled
Windows Firewall: Allow remote administration exception	Enabled
Allow unsolicited messages from ¹	*

Windows Firewall: Allow file and printer sharing exception	Enabled
Allow unsolicited messages from ¹	*
Windows Firewall: Allow ICMP exceptions	Enabled
Allow unsolicited messages from ¹	*

¹Windows prompts you for a range of IP addresses. Enter either “*” or the IP address of the Fortinet appliance that is performing the vulnerability scan.

Microsoft Windows hosts - local (non-domain) scanning

The user account provided for authentication must

- be a local account
- belong to the Administrators group

The host must also meet the following requirements:

- Server service must be enabled. (Windows 2000, 2003, XP)
- Remote Registry Service must be enabled.
- File Sharing must be enabled.
- Public folder sharing must be disabled. (Windows 7)
- Simple File Sharing (SFS) must be disabled. (Windows XP)

Windows firewall settings

- Enable the *Remote Administration Exception* in Windows Firewall. (Windows 2003, Windows XP)
- Allow *File and Print sharing* and *Remote Administration* traffic to pass through the firewall. Specify the IP address or subnet of the Fortinet appliance that is performing the vulnerability scan. (Windows Vista, 2008)
- For each of the active *Inbound Rules* in the *File and Printer Sharing* group, set the *Remote IP address* under *Scope* to either *Any IP address* or to the IP address or subnet of the Fortinet appliance that is performing the vulnerability scan. (Windows 7)

Unix hosts

The user account provided for authentication must be able at a minimum to execute these commands:

- The account must be able to execute “uname” in order to detect the platform for packages.
- If the target is running Red Hat, the account must be able to read /etc/redhat-release and execute “rpm”.
- If the target is running Debian, the account must be able to read /etc/debian-version and execute “dpkg”.

Table 3: Ports scanned in each scan mode

Scan Type	Ports scanned
Standard Scan	<p>TCP: 1-3, 5, 7, 9, 11, 13, 15, 17-25, 27, 29, 31, 33, 35, 37-39, 41-223, 242-246, 256-265, 280-282, 309, 311, 318, 322-325, 344-351, 363, 369-581, 587, 592-593, 598, 600, 606-620, 624, 627, 631, 633-637, 666-674, 700, 704-705, 707, 709-711, 729-731, 740-742, 744, 747-754, 758-765, 767, 769-777, 780-783, 786, 799-801, 860, 873, 886-888, 900-901, 911, 950, 954-955, 990-993, 995-1001, 1008, 1010-1011, 1015, 1023-1100, 1109-1112, 1114, 1123, 1155, 1167, 1170, 1207, 1212, 1214, 1220-1222, 1234-1236, 1241, 1243, 1245, 1248, 1269, 131t3-1314, 1337, 1344-1625, 1636-1774, 1776-1815, 1818-1824, 1901-1909, 1911-1920, 1944-1951, 1973, 1981, 1985-2028, 2030, 2032-2036, 2038, 2040-2049, 2053, 2065, 2067, 2080, 2097, 2100, 2102-2107, 2109, 2111, 2115, 2120, 2140, 2160-2161, 2201-2202, 2213, 2221-2223, 2232-2239, 2241, 2260, 2279-2288, 2297, 2301, 2307, 2334, 2339, 2345, 2381, 2389, 2391, 2393-2394, 2399, 2401, 2433, 2447, 2500-2501, 2532, 2544, 2564-2565, 2583, 2592, 2600-2605, 2626-2627, 2638-2639, 2690, 2700, 2716, 2766, 2784-2789, 2801, 2908-2912, 2953-2954, 2998, 3000-3002, 3006-3007, 3010-3011, 3020, 3047-3049, 3080, 3127-3128, 3141-3145, 3180-3181, 3205, 3232, 3260, 3264, 3267-3269, 3279, 3306, 3322-3325, 3333, 3340, 3351-3352, 3355, 3372, 3389, 3421, 3454-3457, 3689-3690, 3700, 3791, 3900, 3984-3986, 4000-4002, 4008-4009, 4080, 4092, 4100, 4103, 4105, 4107, 4132-4134, 4144, 4242, 4321, 4333, 4343, 4443-4454, 4500-4501, 4567, 4590, 4626, 4651, 4660-4663, 4672, 4899, 4903, 4950, 5000-5005, 5009-5011, 5020-5021, 5031, 5050, 5053, 5080, 5100-5101, 5145, 5150, 5190-5193, 5222, 5236, 5300-5305, 5321, 5400-5402, 5432, 5510, 5520-5521, 5530, 5540, 5550, 5554-5558, 5569, 5599-5601, 5631-5632, 5634, 5678-5679, 5713-5717, 5729, 5742, 5745, 5755, 5757, 5766-5767, 5800-5802, 5900-5902, 5977-5979, 5997-6053, 6080, 6103, 6110-6112, 6123, 6129, 6141-6149, 6253, 6346, 6387, 6389, 6400, 6455-6456, 6499-6500, 6515, 6558, 6588, 6660-6670, 6672-6673, 6699, 6767, 6771, 6776, 6831, 6883, 6912, 6939, 6969-6970, 7000-7021, 7070, 7080, 7099-7100, 7121, 7161, 7174, 7200-7201, 7300-7301, 7306-7308, 7395, 7426-7431, 7491, 7511, 7777-7778, 7781, 7789, 7895, 7938, 7999-8020, 8023, 8032, 8039, 8080-8082, 8090, 8100, 8181, 8192, 8200, 8383, 8403, 8443, 8450, 8484, 8732, 8765, 8886-8894, 8910, 9000-9001, 9005, 9043, 9080, 9090, 9098-9100, 9400, 9443, 9535, 9872-9876, 9878, 9889, 9989-10000, 10005, 10007, 10080-10082, 10101, 10520, 10607, 10666, 11000, 11004, 11223, 12076, 12223, 12345-12346, 12361-12362, 12456, 12468-12469, 12631, 12701, 12753, 13000, 13333, 14237-14238, 15858, 16384, 16660, 16959, 16969, 17007, 17300, 18000, 18181-18186, 18190-18192, 18194, 18209-18210, 18231-18232, 18264, 19541, 20000-20001, 20011, 20034, 20200, 20203, 20331, 21544, 21554, 21845-21849, 22222, 22273, 22289, 22305, 22321, 22555, 22800, 22951, 23456, 23476-23477, 25000-25009, 25252, 25793, 25867, 26000, 26208, 26274, 27000-27009, 27374, 27665, 29369, 29891, 30029, 30100-30102, 30129, 30303, 30999, 31336-31337, 31339, 31554, 31666, 31785, 31787-31788, 32000, 32768-32790, 33333, 33567-33568, 33911, 34324, 37651, 40412, 40421-40423, 42424, 44337, 47557, 47806, 47808, 49400, 50505, 50766, 51102, 51107, 51112, 53001, 54321, 57341, 60008, 61439, 61466, 65000, 65301, 65512</p> <p>UDP: 7, 9, 13, 17, 19, 21, 37, 53, 67-69, 98, 111, 121, 123, 135, 137-138, 161, 177, 371, 389, 407, 445, 456, 464, 500, 512, 514, 517-518, 520, 555, 635, 666, 858, 1001, 1010-1011, 1015, 1024-1049, 1051-1055, 1170, 1243, 1245, 1434, 1492, 1600, 1604, 1645, 1701, 1807, 1812, 1900, 1978, 1981, 1999, 2001-2002, 2023, 2049, 2115, 2140, 2801, 3024, 3129, 3150, 3283, 3527, 3700, 3801, 4000, 4092, 4156, 4569, 4590, 4781, 5000-5001, 5036, 5060, 5321, 5400-5402, 5503, 5569, 5632, 5742, 6073, 6502, 6670, 6771, 6912, 6969, 7000, 7300-7301, 7306-7308, 7778, 7789, 7938, 9872-9875, 9989, 10067, 10167, 11000, 11223, 12223, 12345-12346, 12361-12362, 15253, 15345, 16969, 20001, 20034, 21544, 22222, 23456, 26274, 27444, 30029, 31335, 31337-31339, 31666, 31785, 31789, 31791-31792, 32771, 33333, 34324, 40412, 40421-40423, 40426, 47262, 50505, 50766, 51100-51101, 51109, 53001, 61466, 65000</p>

Table 3: Ports scanned in each scan mode

Scan Type	Ports scanned
Full Scan	All TCP and UDP ports (1-65535)
Quick Scan	TCP: 11, 13, 15, 17, 19-23, 25, 37, 42, 53, 66, 69-70, 79-81, 88, 98, 109-111, 113, 118-119, 123, 135, 139, 143, 220, 256-259, 264, 371, 389, 411, 443, 445, 464-465, 512-515, 523-524, 540, 548, 554, 563, 580, 593, 636, 749-751, 873, 900-901, 990, 992-993, 995, 1080, 1114, 1214, 1234, 1352, 1433, 1494, 1508, 1521, 1720, 1723, 1755, 1801, 2000-2001, 2003, 2049, 2301, 2401, 2447, 2690, 2766, 3128, 3268-3269, 3306, 3372, 3389, 4100, 4443-4444, 4661-4662, 5000, 5432, 5555-5556, 5631-5632, 5634, 5800-5802, 5900-5901, 6000, 6112, 6346, 6387, 6666-6667, 6699, 7007, 7100, 7161, 7777-7778, 8000-8001, 8010, 8080-8081, 8100, 8888, 8910, 9100, 10000, 12345-12346, 20034, 21554, 32000, 32768-32790 UDP: 7, 13, 17, 19, 37, 53, 67-69, 111, 123, 135, 137, 161, 177, 407, 464, 500, 517-518, 520, 1434, 1645, 1701, 1812, 2049, 3527, 4569, 4665, 5036, 5060, 5632, 6502, 7778, 15345

Index

A

adding, configuring defining
endpoint profile 15

B

blocking of users
Endpoint Control 14

D

default password 4

E

endpoint
configuring a profile 15
Endpoint Control
blocked users 14
monitoring endpoints 19
Endpoint Protection
modifying download portal 19
Endpoint Protection portal
modifying replacement pages 19
endpoints
monitoring 19

F

firewall policies
and Endpoint Control 17

FortiClient

download location 14
required version 14

FortiGuard

Antispam 4
Antivirus 4
as source of antivirus signatures 14
as source of application signatures 14
as source of FortiClient installer 14

M

mode, operation 4

O

operation mode 4

P

password
administrator 4

V

vulnerability scan
configuring scans 22
viewing results 22

W

warning to install FortiClient 13